Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ochoos CWA75C3077

Ochoos Remote Control Instruction Manual for Panasonic Air Conditioners (Model CWA75C3077)

Introduction

This manual provides instructions for the Ochoos CWA75C3077 remote control, designed for use with various Panasonic air conditioner models, including CS-RE12JKR. Please read this manual carefully before using the remote control to ensure proper operation and to maximize its lifespan.



Image: Front view of the Ochoos CWA75C3077 remote control. It features a display screen at the top, power button, temperature adjustment buttons, mode selection, fan speed, air swing, and timer controls.

Setup

Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

Note: Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.

Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating. Ensure there are no obstructions between the remote and the unit.

Button Functions

- **OFF/ON Button:** Press to turn the air conditioner ON or OFF.
- **MODE Button:** Press repeatedly to cycle through the operating modes:
  - *AUTO:* The unit automatically selects the operating mode based on the room temperature.
  - *HEAT:* Heats the room.
  - *COOL:* Cools the room.
  - *DRY:* Dehumidifies the room.
  - *FAN:* Circulates air without heating or cooling.
- **TEMP ▲ / ▼ Buttons:** Press the up arrow to increase the temperature setting, and the down arrow to decrease it.
- **FAN SPEED Button:** Press to adjust the fan speed (e.g., Low, Medium, High, Auto).
- **AIR SWING Button:** Activates or deactivates the automatic vertical air swing function.
- **TIMER Button:** Used to set the ON/OFF timer for the air conditioner.
- **SELECT Button:** Used in conjunction with the TIMER button to confirm selections.
- **SET/CANCEL Button:** Used to set or cancel timer settings.
- **CHECK Button:** For checking operational status or error codes (refer to your air conditioner's main manual for details).
- **ERROR RESET Button:** Resets error indicators.
- **RESET Button:** Resets the remote control to factory default settings. Use a pointed object (like a pen tip) to press this recessed button.

Maintenance

Cleaning the Remote Control

- Wipe the remote control with a soft, dry cloth.
- Do not use liquid cleaners, abrasive cleaners, or chemical sprays, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote control's display becomes dim or when the remote no longer operates the air conditioner reliably. Follow the battery installation steps outlined in the "Setup" section.

Important: Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.

Troubleshooting

- **Remote control not responding:**
  - Check if the batteries are inserted correctly and are not depleted. Replace if necessary.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Confirm that the remote is pointed directly at the air conditioner.
- **Limited operating range:**
  - The maximum effective range is approximately 10 meters. Ensure you are within this range.
  - Strong light sources (e.g., direct sunlight, fluorescent lights) can interfere with the infrared signal. Try operating in a different environment.
  - Replace batteries if they are low.
- **Display is dim or blank:**
  - Replace the batteries.

Specifications

Model Number	CWA75C3077
Communication Type	Infrared (IR)
Frequency	433 MHz
Maximum Range	10 meters
Power Source	2 x AAA Batteries
Dimensions	8 x 4 x 1.2 cm (approximately)
Weight	100 grams (approximately)
Compatible Devices	Panasonic Air Conditioners (e.g., CS-RE12JKR, CS-RE12HKE, CS-RE12JKE, CS-RE15JKE, CS-RE9GKE, CS-UE12GKE, CS-UE9GKE series)

Warranty and Support

For warranty information and customer support, please refer to the documentation provided by your retailer or the original manufacturer of the remote control. Keep your purchase receipt as proof of purchase.

If you experience issues not covered in this manual, please contact the seller or manufacturer for assistance.

© 2023 Ochoos. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07R6X6Y8Y

More documents and user manuals: **https://manuals.plus/**