STANLEY SXWTD-FT584

Stanley SXWTD-FT584 Foldable Hand Truck User Manual

Model: SXWTD-FT584

1. Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and care of your Stanley SXWTD-FT584 Foldable Hand Truck. Please read this manual thoroughly before using the product and retain it for future reference. This hand truck is designed for transporting goods efficiently and conveniently.

2. Safety Information

WARNING: Failure to follow these safety instructions may result in injury or property damage.

- Always ensure the hand truck is fully unfolded and locked into position before loading.
- Do not exceed the maximum load capacity of 132.3 pounds (60 kg).
- Distribute the load evenly on the platform. Secure unstable loads with the included elastic cord.
- Use caution when transporting loads up or down stairs, ramps, or uneven surfaces.
- Keep hands and feet clear of moving parts, especially during folding and unfolding.
- Do not use the hand truck for transporting people.
- Inspect the hand truck for damage or wear before each use. Do not use if damaged.
- Store the hand truck in a dry, safe place when not in use.

3. Product Overview

The Stanley SXWTD-FT584 is a compact and lightweight foldable hand truck designed for easy transport and storage. Its key features include:

- Compact, lightweight design for portability.
- Opens and closes in a few seconds for quick deployment and storage.
- Key plastic stress points are made of durable nylon, with other plastic parts made of polypropylene for longevity.
- Includes an elastic cord to secure loads during transport.



Figure 1: The Stanley SXWTD-FT584 Foldable Hand Truck in its compact, folded state, ready for storage or transport.

4. Setup and Unfolding

To prepare your hand truck for use:

1. Place the folded hand truck on a flat, stable surface.
2. Grasp the handle and pull upwards. The wheels and platform will automatically extend.
3. Ensure all locking mechanisms are engaged and the platform is fully extended and stable before loading any items.


STANLEY

Figure 2: A user demonstrating the compact nature of the hand truck, easily fitting into a vehicle.

5. Operating Instructions

Follow these steps for safe and effective operation:

1. **Loading:** Tilt the hand truck slightly backward and slide the platform under the item to be moved. Center the load on the platform.
2. **Securing the Load:** Use the included elastic cord to secure the item to the hand truck frame, preventing it from shifting or falling during transport.
3. **Transporting:** Tilt the hand truck backward until the load is balanced over the wheels. Push or pull the hand truck using the handle. Maintain a firm grip and control.
4. **Unloading:** Once at the destination, tilt the hand truck forward to gently lower the item onto the ground. Remove the elastic cord and slide the hand truck away.

Folding for Storage:

1. Ensure the hand truck is empty.
2. Push the release mechanism (if applicable, refer to product diagram) or gently push the platform upwards. The handle will retract, and the wheels will fold inward.
3. Ensure it is fully folded and compact before storing.

6. Maintenance

Regular maintenance ensures the longevity and safe operation of your hand truck:

- **Cleaning:** Wipe down the hand truck with a damp cloth after use, especially if exposed to dirt or moisture. Avoid harsh chemicals.
- **Lubrication:** Periodically check the wheel axles and folding mechanisms. Apply a small amount of silicone-based lubricant if movement becomes stiff.
- **Inspection:** Regularly inspect all bolts, rivets, and moving parts for tightness and wear. Replace any worn or damaged components immediately.
- **Storage:** Store the hand truck in a clean, dry environment to prevent rust and material degradation.

7. Troubleshooting

Problem	Possible Cause	Solution
Hand truck does not unfold/fold smoothly.	Dirt or debris in mechanism; lack of lubrication; bent component.	Clean mechanism thoroughly. Apply silicone lubricant. Inspect for damage; if bent, contact support.
Wheels are stiff or squeaky.	Dirt in wheel bearings; lack of lubrication.	Clean wheels and axles. Apply lubricant to axles.
Load feels unstable during transport.	Load not centered; load not secured; exceeding weight capacity.	Re-center and secure the load with the elastic cord. Reduce load weight if exceeding capacity.

8. Specifications

Feature	Detail
Brand	STANLEY
Model Number	SXWTD-FT584
Material	Plastic (Durable Nylon for stress points, Polypropylene for other parts)
Color	Gelb (Yellow)
Item Weight	7.79 pounds (3.54 Kilograms)
Style	Foldable
Product Dimensions (Unfolded)	40.16"L x 16.14"W x 16.14"H (approx. 102cm H x 38.5cm W x 27cm D)
Wheel Type	Polypropylene
Load Capacity	132.3 Pounds (60 kg)
Number of Wheels	6
UPC	621457322400



Figure 3: Dimensional diagram of the hand truck.

9. Warranty and Support

For warranty information, technical support, or to purchase replacement parts, please contact STANLEY customer service. Refer to the official STANLEY website or your purchase documentation for specific contact details and warranty terms applicable to your region.

You can often find support information on the officialSTANLEY Store on Amazon.

© 2023 STANLEY. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question