Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aquasonic VK-UX1H-ZRU8

Aquasonic Vibe Series Ultra-Whitening Toothbrush

Model: VK-UX1H-ZRU8

Brand: Aquasonic

Introduction

The Aquasonic Vibe Series Ultra-Whitening Toothbrush is an advanced electric toothbrush designed for comprehensive oral care. It features a powerful 40,000 VPM motor, wireless charging, and multiple brushing modes to provide an effective and comfortable brushing experience. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

What's in the Box

- 1 Satin Rose Gold Smart Toothbrush
- 8 DuPont engineered brush heads
- 1 Custom travel case
- User manual (this document)
- Warranty card



Image: The complete Aquasonic Vibe Series package, showing the Satin Rose Gold toothbrush handle, eight replacement brush heads, and the protective travel case.

Setup

1. **Initial Charge:** Before first use, fully charge the toothbrush. Place the toothbrush handle onto the wireless charging base. The indicator light will show charging status. A full charge can last up to 4 weeks with typical use (2 minutes, twice a day).
2. **Attach Brush Head:** Align the brush head with the metal shaft on the toothbrush handle and push down firmly until it clicks into place. Ensure it is securely attached.



Image: An X-ray view of the Aquasonic Vibe Series toothbrush, highlighting its internal components such as the 40,000 VPM motor, powerful lithium-ion battery, and smart chip for timers and auto shut-off.

Operating Instructions

The Aquasonic Vibe Series toothbrush features 4 distinct brushing modes and smart timers for optimal cleaning.

- **Power On/Off:** Press the top button to turn the toothbrush on or off.
- **Change Modes:** With the toothbrush on, press the bottom button to cycle through the four modes:
  - **Clean:** Standard brushing mode for daily plaque removal.
  - **Soft:** Gentle mode suitable for sensitive teeth and gums.
  - **Whiten:** Helps remove daily surface stains for brighter teeth.
  - **Massage:** Delivers vibrating microbursts to gently stimulate gums.
- **Smart Timer:** The toothbrush features a built-in smart timer that pauses every 30 seconds to signal you to move to a different quadrant of your mouth. It automatically shuts off after 2 minutes, indicating the dentist-recommended brushing time has been completed.



Image: Close-up of the Aquasonic Vibe Series toothbrush handle, illustrating the four custom brushing modes: Clean, Soft, Whiten, and Massage.



Image: A visual representation of the toothbrush head in action, demonstrating its 40,000 vibrations per minute technology effectively whitening teeth and removing up to 10x more plaque than a manual toothbrush.

Maintenance

- **Cleaning the Toothbrush:** After each use, rinse the brush head thoroughly under running water. Wipe the handle with a damp cloth. The toothbrush handle is IPX7 rated waterproof, allowing for easy rinsing.
- **Brush Head Replacement:** For optimal hygiene and brushing effectiveness, replace the brush head every 3 months, or sooner if the bristles become frayed. Each package includes 8 DuPont brush heads, providing over 2 years of supply.
- **Charging:** Recharge the toothbrush when the battery indicator light shows low power. Place it on the wireless charging base. Avoid overcharging by removing it once fully charged, though the system is designed to prevent damage from continuous charging.



Image: A display of eight DuPont engineered brush heads and the premium travel case, emphasizing the value and longevity provided with the Aquasonic Vibe Series toothbrush.

Troubleshooting

Problem	Possible Cause	Solution
Toothbrush does not turn on.	Battery is depleted.	Place the toothbrush on the charging base and allow it to charge for several hours. Ensure the charging base is connected to a power source.
Weak vibration or reduced performance.	Low battery or worn brush head.	Recharge the toothbrush. If fully charged, replace the brush head.

Problem	Possible Cause	Solution
Toothbrush stops before 2 minutes.	This is normal operation for the smart timer.	The toothbrush is designed to automatically shut off after 2 minutes of brushing. This indicates the recommended brushing time has been completed.
Brush head feels loose.	Brush head not properly attached.	Remove the brush head and re-attach it firmly until it clicks into place.

Specifications

- **Model Number:** VK-UX1H-ZRU8
- **Vibrations Per Minute (VPM):** 40,000
- **Battery Type:** Lithium-Ion (included)
- **Charging:** Wireless
- **Brushing Modes:** 4 (Clean, Soft, Whiten, Massage)
- **Timer:** Smart vibration timers (30-second quadrant timer, 2-minute auto shut-off)
- **Waterproof Rating:** IPX7
- **Brush Head Material:** DuPont engineered bristles
- **Item Firmness:** Soft
- **Power Source:** Battery Powered
- **Dimensions:** 8.46 x 3.31 x 2.83 inches
- **Weight:** 14.39 ounces

Safety Information

Please read all safety information before using the Aquasonic Vibe Series toothbrush.

- **Choking Hazard:** Keep out of reach of children.
- **Disassembly:** Do not attempt to disassemble the toothbrush.
- **Intended Use:** Not intended for use other than oral hygiene.
- **Children:** Supervision is recommended for children under 12 years of age.
- **Brush Head Replacement:** Replace brush head every 3 months to maintain hygiene and effectiveness.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

Warranty and Support

Your Aquasonic Vibe Series toothbrush comes with a warranty. Please refer to the included warranty card for specific terms and conditions regarding coverage and duration.

For customer support, technical assistance, or warranty claims, please contact Aquasonic customer service. Contact information can typically be found on the warranty card or the official Aquasonic website. Aquasonic is committed to providing state-of-the-art dental technology and superior customer service.

You can also visit the official Aquasonic store for more information and support:Aquasonic Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07R8WGDKF

More documents and user manuals: **https://manuals.plus/**