Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LASIKA WF062

LASIKA WF062 Unisex Grey Dial Polyurethane Band Watch User Manual

Model: WF062 | Brand: LASIKA

1. Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your LASIKA WF062 Unisex Grey Dial Polyurethane Band Watch. Please read this manual carefully to ensure proper use and to maximize the lifespan of your watch. Keep this manual for future reference.

2. Product Overview

The LASIKA WF062 is a digital quartz watch designed for unisex use, featuring a grey dial and a durable polyurethane band. It offers a clear digital display and essential timekeeping functions.

2.1 Key Features

- Digital Display
- Quartz Movement
- Polyurethane Band with Tang Buckle
- Water Resistant Design
- Light Function for illumination

2.2 Watch Components



Figure 1: Front View of LASIKA WF062 Watch. This image displays the watch face, highlighting the digital time display, day of the week, and date. The watch features a black polyurethane band with blue accents and silver-colored buttons on the sides. The brand "LASIKA" is visible above the display, and "W-F62" is below.



Figure 2: Side View with Buttons. This image provides a closer look at the watch's side profile, clearly showing the four control buttons. On the left, the 'LIGHT' and 'MODE' buttons are visible. On the right, the 'START' and 'RESET' buttons are shown. The blue accents on the band are also prominent.



Figure 3: Watch Case Back. This image shows the stainless steel back of the watch, secured by screws. Engravings on the case back typically include the brand name "LASIKA" and water resistance information, confirming the watch's durability.

- **Display:** Shows time, date, day of the week, and other functions.
- **LIGHT Button:** Activates the backlight for visibility in low light conditions.
- **MODE Button:** Cycles through different modes (Time, Alarm, Stopwatch).
- **START Button:** Used to start/stop stopwatch, adjust settings.
- **RESET Button:** Used to reset stopwatch, confirm settings.
- **Case:** Durable plastic case.
- **Band:** Flexible polyurethane band with a tang buckle for secure fit.

3. Setup

3.1 Setting Time and Date

1. From the normal time display, press the **MODE** button repeatedly until the time setting mode is activated (usually indicated by flashing digits).
2. Use the **START** button to adjust the flashing digit (hours, minutes, year, month, day).
3. Press the **RESET** button to move to the next digit or setting.
4. Once all settings are correct, press the **MODE** button to exit the setting mode and return to the normal time display.

3.2 Setting Alarm

1. Press the **MODE** button until you reach the Alarm mode.
2. Press the **START** button to adjust the hour, then **RESET** to move to minutes.
3. Use the **START** button to set the desired alarm time.
4. Press the **MODE** button to confirm and exit.
5. To turn the alarm on/off, typically press the **START** button while in Alarm mode. An alarm icon will appear/disappear.

4. Operating Instructions

4.1 Using the Backlight

Press the **LIGHT** button (usually on the top left) to illuminate the display for a few seconds. This feature is useful in dark environments.

4.2 Stopwatch Function

1. Press the **MODE** button until you reach the Stopwatch mode. The display will show "00:00:00".
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **RESET** button to clear the stopwatch to "00:00:00".
5. Press the **MODE** button to exit Stopwatch mode.

5. Maintenance

5.1 Cleaning Your Watch

Wipe the watch case and band with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid using chemical cleaners, as they may damage the watch's materials.

5.2 Water Resistance

The LASIKA WF062 watch is water resistant. This means it can withstand splashes, rain, and brief immersion in water. **Do not press any buttons while the watch is submerged in water.** Avoid hot water, steam, or prolonged exposure to water, as this can compromise the water resistance seals.

5.3 Battery Replacement

When the display becomes dim or functions become erratic, it may be time to replace the battery. Battery replacement should ideally be performed by a qualified watch technician to ensure the water resistance seal is properly maintained.

6. Troubleshooting

- **Display is blank or dim:** The battery may be low or depleted. Replace the battery.
- **Time is incorrect:** Re-set the time following the instructions in Section 3.1. Ensure you are in the correct 12/24-hour format if applicable.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though not specified for this model). If the issue persists, a battery replacement might resolve it, or there could be an internal malfunction.
- **Water inside the watch:** Immediately take the watch to a professional for inspection and repair to prevent further damage. Avoid exposing the watch to water if seals are compromised.

7. Specifications

Brand	LASIKA
Model Number	WF062
Watch Type	Casual Digital Watch
Targeted Group	Unisex
Movement	Quartz
Display Type	Digital
Dial Color	Grey
Case Material	Plastic
Band Material	Polyurethane
Clasp Type	Tang Buckle
Water Resistant	Yes (refer to Section 5.2 for details)
Package Dimensions	7.8 x 7.4 x 0.4 cm
Item Weight	80 g

8. Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

© 2023 LASIKA. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07R99B23Y

More documents and user manuals: **https://manuals.plus/**