Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Karcher UR 1308

Karcher UR 1308 Alarm Clock Radio Instruction Manual

Model: UR 1308

1. Introduction

Thank you for purchasing the Karcher UR 1308 Alarm Clock Radio. This compact device combines a CD player, FM radio, dual alarm functions, and a convenient USB charging port, making it an ideal companion for your bedside table. This manual provides detailed instructions to help you set up, operate, and maintain your new alarm clock radio.

2. Safety Instructions

Please read these safety instructions carefully before using the device and keep them for future reference. Incorrect use may result in electric shock, fire, or other hazards.

- **Power Source:** Use only the specified power adapter. Ensure the voltage matches the requirements of your region.
- **Water and Moisture:** Do not expose the device to rain, moisture, or dripping/splashing liquids. Do not place objects filled with liquids, such as vases, on the device.
- **Ventilation:** Ensure adequate ventilation. Do not block ventilation openings. Place the device on a stable, flat surface.
- **Heat:** Keep the device away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Unplug the device before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Batteries:** Follow polarity markings when inserting backup batteries. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries responsibly.
- **Servicing:** Do not attempt to service the device yourself. Refer all servicing to qualified service personnel.

3. Package Contents

Please check that all items are present in the packaging:

- Karcher UR 1308 Alarm Clock Radio Unit
- AC Power Adapter
- Instruction Manual

If any items are missing or damaged, please contact your retailer.

4. Product Overview

Familiarize yourself with the various parts and controls of your Karcher UR 1308.



Figure 4.1: Top-down view of the Karcher UR 1308, highlighting the CD player and main control panel.



Figure 4.2: Front view of the Karcher UR 1308, showcasing the clear LED time display and speaker design.



Figure 4.3: Angled view of the Karcher UR 1308, providing a closer look at the USB charging port and control buttons on the top panel.

Control Panel Layout:

- **USB Charging Port:** For charging external devices.
- **ALARM 1** / **ALARM 2 Buttons:** To set and activate/deactivate alarms.
- **VOL -** / **VOL +** **Buttons:** Adjust volume.
- **CLOCK** / **PROG Button:** Set time and program CD tracks.
- **SOURCE Button:** Select input source (CD, FM Radio).
- **PHONES Jack:** 3.5mm headphone output.
- **TUNING -** / **TUNING +** **Buttons:** Tune radio frequencies.
- **PLAY MODE Button:** Select CD play modes (repeat, random).
- **SLEEP** / **TIME Button:** Set sleep timer and adjust time.
- **MEMO** / **INFO Button:** Save radio presets and display information.
- **DIMMER** / **SNOOZE Button:** Adjust display brightness and activate snooze.
- **LED Display:** Shows time, alarm status, and current mode.
- **CD Compartment:** Top-loading CD player.

5. Setup

5.1 Connecting Power

1. Plug the AC power adapter into the DC IN jack on the back of the unit.
2. Plug the other end of the adapter into a standard wall outlet.
3. The unit will power on and the display will light up.

5.2 Installing Backup Batteries (Not Included)

The UR 1308 features a battery backup function to maintain time and alarm settings during a power outage.

1. Open the battery compartment cover on the bottom of the unit.
2. Insert 2 x AAA batteries (not included) according to the polarity markings (+ and -).
3. Close the battery compartment cover securely.

5.3 Setting the Clock

1. In standby mode, press and hold the **CLOCK** / **PROG** button until the hour digits flash.
2. Use the **TUNING -** / **TUNING +** buttons to adjust the hour.
3. Press the **CLOCK** / **PROG** button again to confirm the hour, and the minute digits will flash.

4. Use the **TUNING -** / **TUNING +** buttons to adjust the minutes.
5. Press the **CLOCK** / **PROG** button one more time to save the time.

6. Operating Instructions

6.1 Radio Operation (FM)

1. Press the **SOURCE** button repeatedly until "FM" appears on the display.
2. **Automatic Tuning:** Press and hold **TUNING -** / **TUNING +** for 2 seconds to automatically scan for the next available station.
3. **Manual Tuning:** Press **TUNING -** / **TUNING +** briefly to fine-tune the frequency step by step.
4. **Saving Presets:**
    a. Tune to your desired station.
    b. Press and hold the **MEMO** / **INFO** button until "PXX" (preset number) flashes.
    c. Use **TUNING -** / **TUNING +** to select the desired preset number (1-20).
    d. Press **MEMO** / **INFO** again to confirm and save.
5. **Recalling Presets:** Briefly press the **MEMO** / **INFO** button to cycle through saved stations.

6.2 CD Player Operation

1. Press the **SOURCE** button repeatedly until "CD" appears on the display.
2. Open the CD compartment cover and insert a CD (CD, CD-R, CD-RW) with the label side facing up.
3. Close the CD compartment cover. The CD will start playing automatically.
4. **Play/Pause:** Press the **PLAY MODE** button to pause playback, press again to resume.
5. **Skip Tracks:** Press **TUNING -** / **TUNING +** briefly to skip to the previous/next track.
6. **Fast Forward/Rewind:** Press and hold **TUNING -** / **TUNING +** to fast forward/rewind within a track.
7. **Programmable Playback:**
    a. In stop mode, press the **CLOCK** / **PROG** button. "PROG" will flash.
    b. Use **TUNING -** / **TUNING +** to select the desired track.
    c. Press **CLOCK** / **PROG** to confirm. Repeat for up to 20 tracks.
    d. Press **PLAY MODE** to start programmed playback.

6.3 Alarm Functions (Dual Alarm)

The unit has two independent alarms (Alarm 1 and Alarm 2).

1. **Setting Alarm Time:**
    a. Press and hold **ALARM 1** or **ALARM 2** button until the alarm hour flashes.
    b. Use **TUNING -** / **TUNING +** to adjust the hour. Press the alarm button again to confirm.
    c. The alarm minutes will flash. Use **TUNING -** / **TUNING +** to adjust minutes. Press the alarm button again to confirm.
2. **Setting Alarm Source:**
    a. After setting the alarm time, the display will show the alarm source (CD, FM, BUZ).
    b. Use **TUNING -** / **TUNING +** to select your desired alarm source.
    c. Press the alarm button again to confirm.
3. **Setting Alarm Mode (Frequency):**
    a. After setting the alarm source, the display will show the alarm mode (e.g., MO-FR, MO-SO, SA-SO, DAY).
    b. Use **TUNING -** / **TUNING +** to select the desired alarm mode.
    c. Press the alarm button again to confirm and activate the alarm. The alarm icon will appear on the display.

4. **Deactivating Alarm:** Briefly press the corresponding **ALARM 1** or **ALARM 2** button to turn off the alarm. The alarm icon will disappear.
5. **Snooze Function:** When the alarm sounds, press the **DIMMER** / **SNOOZE** button to temporarily silence the alarm for approximately 9 minutes. The alarm will sound again after this period.
6. **Stopping Alarm:** To stop the alarm completely, press the **POWER** button. The alarm will reset for the next day.

6.4 Sleep Timer

1. While the unit is playing (CD or Radio), press the **SLEEP** / **TIME** button repeatedly to cycle through sleep timer options (e.g., 90, 60, 30, 15 minutes, OFF).
2. The unit will automatically turn off after the selected time.

6.5 USB Charging

The integrated USB port allows you to charge compatible mobile devices.

- Connect your mobile device's USB charging cable to the USB Charging Port on the unit.
- Connect the other end of the cable to your mobile device.
- Charging will begin automatically. Note that charging speed may vary depending on the device.

6.6 Headphone Use

You can listen to audio privately using headphones.

- Plug your 3.5mm headphones into the **PHONES** jack on the unit.
- The internal speakers will automatically mute.

6.7 Display Dimmer

Adjust the brightness of the LED display.

- Briefly press the **DIMMER** / **SNOOZE** button to toggle between two brightness levels or turn the display off.

7. Maintenance

7.1 Cleaning the Unit

- Always unplug the unit from the power outlet before cleaning.
- Use a soft, dry cloth to wipe the exterior surfaces.
- Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- For the CD lens, use a specialized CD lens cleaner if necessary.

7.2 Battery Replacement

Replace the backup batteries when they are depleted or if the unit experiences frequent power outages.

- Open the battery compartment on the bottom of the unit.
- Remove the old batteries and dispose of them properly.
- Insert new 2 x AAA batteries, ensuring correct polarity.
- Close the battery compartment cover.

8. Troubleshooting

If you experience problems with your Karcher UR 1308, please check the following common issues before seeking professional service.

Problem	Possible Cause	Solution
Unit does not power on.	Power adapter not connected or faulty.	Ensure the power adapter is securely plugged into the unit and a working wall outlet. Try a different outlet.
No sound from speakers.	Volume is too low or muted. Headphones are connected.	Increase the volume using VOL + button. Disconnect headphones from the PHONES jack.
CD skipping or not playing.	CD is dirty, scratched, or inserted incorrectly.	Clean the CD with a soft, lint-free cloth. Check for scratches. Ensure the CD is inserted correctly with the label side up.
Poor FM radio reception.	Weak signal.	Adjust the position of the unit or the FM antenna (if applicable). Try tuning manually.
Alarm does not sound.	Alarm is not activated or set incorrectly.	Ensure the alarm icon is displayed. Verify the alarm time, source, and mode are set correctly. Check volume for radio/CD alarm.
USB charging not working.	Cable is faulty or device is not compatible.	Try a different USB cable. Ensure your device is compatible with USB charging.

9. Specifications

Feature	Specification
Model Number	UR 1308
Brand	Karcher
Power Source	AC Adapter
Radio Bands Supported	FM
CD Compatibility	CD, CD-R, CD-RW
USB Ports	1 (for charging)
Compatible Devices (USB)	MP3 Player, Personal Computer, Tablet, Smartphone
Audio Output	Stereo Speakers (2 x 1W RMS), Headphone Jack
Display	LED (2-level dimmable)
Dimensions (W x D x H)	23.8 x 16 x 7.5 cm
Battery Backup	Yes (Batteries not included)

10. Warranty and Support

Karcher products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official Karcher website.

If you require technical support or have questions not covered in this manual, please contact Karcher customer service through their official channels. Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07RCHVCJK

More documents and user manuals: **https://manuals.plus/**