**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## eufy AK-T2190121

# eufy L70 Hybrid Robot Vacuum User Manual

Model: AK-T2190121 / RoboVac L70

## Introduction

The eufy L70 Hybrid is an advanced 2-in-1 robotic vacuum and mop designed to provide efficient and thorough cleaning for your home. Featuring iPath Laser Navigation and AI Map Technology, it offers precise real-time mapping and customized cleaning capabilities. With 2200Pa of strong suction power, it effectively cleans various floor types, from hardwood to medium-pile carpets, while operating quietly. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your RoboVac L70 Hybrid.

## What's in the Box

Verify that all components are present before beginning setup.

- RoboVac L70 Hybrid Unit
- Charging Base
- AC Power Adapter
- Waterproof Pad
- Mopping Module (with washable mopping cloth)
- Quick Installation Guide
- User Manual (this document)
- Welcome Guide
- Manufacturer's Warranty Information
- Filter




**Figure 1:** The eufy L70 Hybrid unit, its charging base, and a smartphone displaying the companion app with a mapped cleaning area.

## Setup

1. **Prepare the Charging Base:** Place the charging base against a wall in an open, uncluttered area. Ensure there is at least 1 meter (3 feet) of clear space to the front and 0.5 meters (1.5 feet) to each side of the charging base. Connect the AC power adapter to the charging base and plug it into a wall outlet.
2. **Install the Waterproof Pad:** For mopping functionality, attach the waterproof pad to the charging base to protect your floor from moisture.
3. **Initial Charge:** Place the RoboVac L70 Hybrid onto the charging base. Ensure the charging pins on the RoboVac align with those on the base. The indicator lights on the RoboVac will illuminate to confirm charging. Allow the RoboVac to fully charge before its first use (approximately 4-5 hours).
4. **Download the eufyHome App:** Search for "eufyHome" in the App Store (iOS) or Google Play Store (Android) and download the application.
5. **Connect to Wi-Fi:** Follow the in-app instructions to connect your RoboVac L70 Hybrid to your home Wi-Fi network. This enables smart features like real-time mapping, customized cleaning, and remote control.

# Operating Instructions

## Cleaning Modes

The eufy L70 Hybrid offers versatile cleaning modes to suit different needs:

- **Auto Cleaning:** The RoboVac intelligently navigates and cleans your home using its iPath Laser Navigation system. It creates a real-time map of your environment to ensure comprehensive coverage.
- **Spot Cleaning:** Ideal for concentrated areas of dirt. Place the RoboVac in the center of the area to be cleaned, and it will clean in a spiral pattern.
- **Zone Cleaning:** Use the eufyHome app to define specific areas on the map for the RoboVac to clean.
- **Manual Cleaning:** Control the RoboVac's movement directly using the directional controls in the eufyHome app.

## Vacuuming and Mopping

The RoboVac L70 Hybrid combines vacuuming and mopping functionalities for a complete clean.

- **Vacuum Mode:** The RoboVac uses 2200Pa of strong suction power to pick up dust, debris, and pet hair from various surfaces, including hardwood, tile, laminate floors, and medium-pile carpets.
- **Mop Mode:** Attach the mopping module and fill the water tank. The RoboVac will simultaneously vacuum and mop hard floors. Ensure the waterproof pad is correctly positioned under the charging base when mopping to prevent water damage.




**Figure 2:** The eufy L70 Hybrid actively cleaning a hardwood floor, demonstrating its autonomous operation.




**Figure 3:** The eufy L70 Hybrid utilizing its real-time AI map technology to navigate a living space, with the companion app illustrating the 'No-Go Zones' feature.




**Figure 4:** A visual representation of the eufy L70 Hybrid's dual functionality, highlighting its integrated vacuum and mop components.

## Using the eufyHome App

The eufyHome app provides comprehensive control and customization options:

- **Real-time Mapping:** View the RoboVac's cleaning path and mapped areas in real-time.
- **No-Go Zones:** Set virtual boundaries to prevent the RoboVac from entering specific areas.
- **Zone Cleaning:** Select specific rooms or areas on the map for targeted cleaning.

- **Scheduling:** Set cleaning schedules for automated operation.
- **Suction Power Adjustment:** Adjust suction power levels (e.g., Standard, BoostIQ, Max) based on floor type and cleaning needs. BoostIQ automatically increases suction on carpets.
- **Water Flow Control:** For mopping, adjust the water flow level (Light, Medium, Heavy) via the app.
- **Find My Robot:** Locate your RoboVac if it gets stuck or is out of sight.

## Maintenance

Regular maintenance ensures the longevity and optimal performance of your RoboVac L70 Hybrid. Always power off the RoboVac and disconnect it from the charging base before performing any maintenance.

### Dust Collector and Filter

- **Emptying:** Empty the dust collector after each use.
- **Cleaning:** Rinse the dust collector with water. Allow it to air dry completely before re-installing.
- **Filter Maintenance:** Tap the filter to remove loose dirt. Brush off any remaining debris. Replace the filter every 3-6 months, or more frequently depending on usage.

### Main Brush and Side Brushes

- **Main Brush:** Remove hair and debris tangled around the main brush using the cleaning tool provided. Clean the main brush every week.
- **Side Brushes:** Check side brushes for damage or tangles. Clean them regularly and replace if worn or bent.

### Sensors and Charging Pins

- Wipe all sensors (drop sensors, cliff sensors) and charging pins on both the RoboVac and the charging base with a dry cloth monthly to ensure proper function.

### Mopping Cloth and Water Tank

- **Mopping Cloth:** Remove and wash the mopping cloth after each use. Allow it to air dry completely.
- **Water Tank:** Empty any remaining water from the tank after each mopping session. Rinse the tank and allow it to air dry to prevent mold or odor.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| RoboVac does not turn on. | Battery is low or depleted. | Place RoboVac on the charging base and ensure it is charging. |
| RoboVac gets stuck frequently. | Obstacles (cables, small objects) on the floor. | Clear the cleaning area of obstacles. Use "No-Go Zones" in the app for persistent problem areas. |
| Poor cleaning performance. | Dust collector is full, filter is clogged, or brushes are tangled. | Empty the dust collector. Clean or replace the filter. Clean the main brush and side brushes. |
| RoboVac cannot return to charging base. | Charging base is obstructed or too far. | Ensure the charging base is in an open area with no obstacles. Manually place RoboVac on the base if needed. |
| Mopping function not working. | Water tank is empty or mopping cloth is not properly attached. | Fill the water tank. Ensure the mopping cloth is securely attached and wet. Check water flow settings in the app. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Wi-Fi connection issues. | Incorrect Wi-Fi password, router issues, or RoboVac too far from router. | Verify Wi-Fi password. Restart router and RoboVac. Move RoboVac closer to the router during setup. |

## Specifications

- **Brand:** eufy
- **Model Name:** RoboVac L70
- **Model Number:** AK-T2190121
- **Color:** White
- **Product Dimensions:** 14.02"L x 14.02"W x 4.02"H
- **Filter Type:** Cloth
- **Battery Life:** 2.5 Hours
- **Dustbin Capacity:** 0.6 Liters
- **Power Source:** Corded Electric (for charging base)
- **Control Method:** App (eufyHome)
- **Lithium Battery Voltage:** 18 Volts
- **Compatible Devices:** Amazon Alexa
- **Item Weight:** 8.49 pounds
- **Manufacture Year:** 2019
- **UPC:** 848061058383

## Warranty and Support

eufy provides a worry-free 12-month warranty for the RoboVac L70 Hybrid. For any product inquiries, technical assistance, or warranty claims, please contact eufy customer support. Our friendly, easy-to-reach assistance team is available to help you. Please refer to the official eufy website or the eufyHome app for the most up-to-date contact information and support resources.

© 2023 eufy. All rights reserved.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B07RDFFSJC**

More documents and user manuals: **https://manuals.plus/**