Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CHOUBENBEN 20190506738

CHOUBENBEN Replacement Remote Control User Manual

For Lennox MS8-CI-09L1A, MS8-CI-12L1A, MS8-HI-09P1A, MS8-HI-12P1A, MS8-HI-18P1A AC Air Conditioners

Introduction

This manual provides instructions for the CHOUBENBEN replacement remote control, designed for use with specific Lennox AC Air Conditioner models. This remote offers direct functionality without the need for complex programming. Please read this manual thoroughly to ensure proper operation and longevity of your remote control.

Setup

1. Battery Installation

The remote control requires batteries for operation. Batteries are **not included** with this product and must be purchased separately. This remote typically uses Lithium batteries.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide or unclip the cover to open the compartment.
3. Insert the required batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover securely.



Image: Front view of the CHOUBENBEN replacement remote control. It features a rectangular shape with a display screen at the top and an array of buttons below, including power, mode, fan speed, and temperature controls.

2. Initial Use

This replacement remote control is designed for immediate use with compatible Lennox AC Air Conditioners. No programming or pairing is typically required. Once batteries are installed, point the remote towards your AC unit and press the power button to begin operation.

Operating Instructions

The remote control provides full functionality for your Lennox AC unit. Familiarize yourself with the buttons and their functions:

- **Power Button:** Turns the AC unit on or off.
- **Mode Button:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Temperature Adjustment Buttons (Up/Down Arrows):** Increases or decreases the desired temperature setting.
- **Fan Speed Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).

- **Swing/Louvre Button:** Controls the direction of the air flow.
- **Timer Button:** Sets the timer for automatic on/off operations.

Fahrenheit and Celsius Display

The remote control supports display in both Fahrenheit and Celsius. Refer to the remote's specific instructions or a dedicated button (if present) to switch between these temperature units. If no dedicated button is visible, consult the original AC unit's manual for remote temperature unit conversion methods, as some remotes may use a combination of buttons or a hidden switch.

Maintenance

Battery Replacement

Replace batteries when the remote's display becomes dim or the remote becomes unresponsive. Always replace all batteries at the same time with new ones of the same type. Do not mix old and new batteries or different types of batteries.

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are correctly installed with the proper polarity.
  - Replace old batteries with new ones.
  - Ensure there is a clear line of sight between the remote control and the AC unit's receiver. Obstructions can block the infrared signal.
  - Confirm the remote is compatible with your specific AC unit model.
- **Temperature display issues (e.g., stuck in Celsius/Fahrenheit):**
  - Some remotes have a dedicated button or a combination of buttons to switch between Fahrenheit and Celsius. Consult the original AC unit's manual or try common button combinations (e.g., pressing 'Mode' and 'Temp Down' simultaneously).
  - If the issue persists after battery replacement and checking for a conversion method, contact support.

Specifications

Brand	CHOUBENBEN
Model Number	20190506738
Compatible Devices	Air Conditioner (Lennox MS8-CI-09L1A, MS8-CI-12L1A, MS8-HI-09P1A, MS8-HI-12P1A, MS8-HI-18P1A)
Connectivity Technology	Infrared

Controller Type	Button Control
Battery Type	Lithium (not included)
Special Feature	Ergonomic, Display in Both Fahrenheit and Celsius

Warranty Information

Specific warranty details for this CHOUBENBEN replacement remote control are not provided in the product information. Please refer to your purchase documentation or contact the seller directly for any warranty-related inquiries.

Support

If you have any questions regarding the operation, compatibility, or troubleshooting of your CHOUBENBEN replacement remote control, please do not hesitate to contact the seller or manufacturer for assistance. Providing your product model number (20190506738) and your AC unit's model number will help expedite support.

© 2023 CHOUBENBEN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07RDL4VCB

More documents and user manuals: **https://manuals.plus/**