Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CHOUBENBEN 20190503111

CHOUBENBEN Remote Control User Manual

For Panasonic AC Models: CS-E18JKEW, CS-E21JKEW, CS-E7MKEW, CS-E9MKEW, CS-E12MKEW, CS-E15MKEW, CS-E18MKEW, CS-E21MKEW

Model: 20190503111

Introduction

This manual provides instructions for the proper setup, operation, and maintenance of your CHOUBENBEN replacement remote control for Panasonic Air Conditioners. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.



Figure 1: CHOUBENBEN replacement remote control. This image displays the front view of the remote control, highlighting its ergonomic design and button layout.

1. Setup

1.1 Battery Installation

The remote control requires two AAA batteries (not included). Ensure correct polarity when inserting the batteries.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open.
3. Insert two new AAA batteries, matching the (+) and (-) terminals as indicated inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.

Note: Remove batteries if the remote control will not be used for an extended period to prevent leakage.

1.2 Initial Use

This remote control is designed as a direct replacement for the specified Panasonic AC models. No programming or pairing is typically required. Simply install the batteries and point the remote towards your air conditioner's receiver.

2. Operating Instructions

Familiarize yourself with the buttons and their functions for effective control of your air conditioner.

2.1 Basic Functions

- **POWER Button:** Turns the air conditioner ON or OFF.
- **MODE Button:** Cycles through operating modes: Auto, Cool, Dry, Fan, Heat (if applicable to your AC model).
- **TEMP ▲ / ▼ Buttons:** Adjusts the temperature setting up or down.
- **FAN Button:** Adjusts fan speed (Auto, Low, Medium, High).
- **SWING Button:** Controls the louver swing function (if available on your AC unit).
- **TIMER Button:** Sets the ON/OFF timer for the air conditioner. Refer to your AC unit's manual for specific timer settings.

Note: Button labels and exact functions may vary slightly based on the specific Panasonic AC model you are operating.

3. Maintenance

3.1 Cleaning the Remote Control

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the surface or internal components.

3.2 Battery Replacement

Replace batteries when the remote control's range decreases or if the air conditioner does not respond to commands. Follow the battery installation steps in Section 1.1. Always replace both batteries at the same time with new ones of the same type.

3.3 Storage

When storing the remote control for extended periods, remove the batteries to prevent potential leakage and damage. Store in a cool, dry place away from direct sunlight and extreme temperatures.

4. Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	Dead or incorrectly installed batteries.	Replace batteries with new ones, ensuring correct polarity.
Air conditioner not responding.	Obstruction between remote and AC unit; remote too far away; AC unit's IR receiver blocked.	Ensure a clear line of sight to the AC unit. Move closer to the AC unit. Check if anything is blocking the AC unit's infrared receiver.
Limited functionality.	Remote control is a replacement and may not support all advanced features of the original remote or AC unit.	Confirm the remote's compatibility with your specific AC model's features. Some advanced functions might require the original remote.

5. Specifications

- **Brand:** CHOUBENBEN
- **Model Number:** 20190503111
- **Connectivity Technology:** Infrared (IR)
- **Power Source:** 2 x AAA Batteries (not included)
- **Compatible AC Models:** Panasonic CS-E18JKEW, CS-E21JKEW, CS-E7MKEW, CS-E9MKEW, CS-E12MKEW, CS-E15MKEW, CS-E18MKEW, CS-E21MKEW
- **Special Feature:** Ergonomic design

6. Warranty and Support

This CHOUBENBEN remote control is typically covered by a standard manufacturer's warranty against defects in materials and workmanship. For specific warranty details, please refer to the product packaging or contact your retailer. For technical support or inquiries, please contact the seller or manufacturer through the platform where the product was purchased. Please have your model number (20190503111) and purchase details ready.

© 2023 CHOUBENBEN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07RF81KXV

More documents and user manuals: **https://manuals.plus/**