Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CHOUBENBEN 20190506263

CHOUBENBEN Remote Control Instruction Manual

For Daikin Air Conditioners ARC480A32, ARC480A33, ARC480A34

Introduction

This manual provides instructions for the CHOUBENBEN replacement remote control, designed for use with various Daikin air conditioner models, including ARC480A32, ARC480A33, and ARC480A34. This remote control operates your air conditioner's primary functions, offering convenient temperature and mode adjustments. Please read this manual carefully before use.

Setup

1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

Note: *Always replace both batteries at the same time. Do not mix old and new batteries or different types of batteries. Remove batteries if the remote will not be used for an extended period.*

Operating Instructions

This remote control provides essential functions for your Daikin air conditioner. The display shows temperature in Celsius only.

Key Functions:

- **POWER Button:** Press to turn the air conditioner ON or OFF.
- **MODE Button:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **TEMP ▲ / ▼ Buttons:** Adjusts the desired temperature setting. The display is in Celsius.

- **FAN Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **SWING Button:** Controls the louver swing function for air direction.
- **TIMER Button:** Sets the ON/OFF timer for the unit. Refer to your air conditioner's main manual for detailed timer programming.



Figure 1: CHOUBENBEN Remote Control Layout. This image displays the front of the remote control, highlighting the power, mode, temperature adjustment, fan speed, and swing buttons, along with the digital display for temperature and mode indicators.

Maintenance

1. Cleaning the Remote Control

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water and a mild detergent, then wipe dry immediately.
- Do not use abrasive cleaners, alcohol, or chemical solvents, as these can damage the surface.

2. Battery Replacement

Replace batteries when the remote control's range decreases or the display becomes dim. Refer to the "Battery Installation" section under Setup for detailed instructions.

Troubleshooting

Problem	Possible Cause	Solution
Remote control not responding.	Dead or incorrectly installed batteries. Obstruction between remote and AC unit. Remote out of range.	Replace batteries, ensuring correct polarity. Remove any obstructions. Move closer to the AC unit (within 10 meters).
Display is dim or blank.	Low battery power.	Replace batteries.
Air conditioner does not respond to commands.	Remote control not compatible with the specific AC model. AC unit is off or unplugged.	Verify compatibility with your Daikin AC model (ARC480A32, ARC480A33, ARC480A34). Ensure the AC unit has power.
Temperature displays in Fahrenheit instead of Celsius.	This remote control only displays in Celsius.	No action required. The remote is designed for Celsius display only.
Remote range is reduced.	Low battery power. Interference.	Replace batteries. Ensure no strong electromagnetic interference sources are nearby.
Remote feels sluggish or buttons stick.	Dirt or debris under buttons.	Clean the remote control as described in the Maintenance section.
Remote control is physically damaged.	Accidental drop or impact.	Physical damage is typically not repairable. Consider purchasing a replacement.

Specifications

- **Model Number:** 20190506263
- **Compatible AC Models:** Daikin ARC480A32, ARC480A33, ARC480A34
- **Power Source:** 2 x AAA Batteries (not included)
- **Display Unit:** Celsius only
- **Maximum Range:** 10 Meters
- **Brand:** CHOUBENBEN
- **Manufacturer:** KITCHENWARE STORE

Support

If you have any questions or are unsure about the compatibility or operation of this remote control, please do not hesitate to contact the seller or manufacturer for assistance. Refer to your purchase documentation for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07RLLYGRR

More documents and user manuals: **https://manuals.plus/**