**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## LENSGO L322

# LENSGO L322 Mini Tripod User Manual

Portable Cell Phone Tripod Tabletop Stand for Android iPhone Smartphone/Camera/GoPro with Wireless Remote Shutter

## INTRODUCTION

The LENSGO L322 Mini Tripod is a versatile and portable accessory designed to enhance your mobile photography and videography experience. It is compatible with a wide range of devices, including smartphones, GoPro cameras, and small DSLR cameras. This manual provides detailed instructions for setting up, operating, and maintaining your LENSGO L322 Mini Tripod to ensure optimal performance and longevity.




Image: The LENSGO L322 Mini Tripod shown with a smartphone and a GoPro camera mounted, alongside its wireless remote shutter.

## Setup

### 1. Unpacking and Components

Carefully remove all components from the packaging. The LENSGO L322 Mini Tripod package typically includes:

- LENSGO L322 Mini Tripod
- Wireless Remote Shutter
- Universal Cell Phone Clip
- GoPro Mount (GoPro screw)




Image: All components of the LENSGO L322 Mini Tripod laid out, including the tripod, Bluetooth remote, GoPro screw, and phone clip, next to its retail packaging.

## 2. Attaching Your Device

The tripod features a standard 1/4" screw for direct attachment of cameras. For smartphones and GoPro devices, use the included adapters.

- **For Smartphones:** Attach the universal cell phone clip to the 1/4" screw on the tripod's ball head. Secure your smartphone within the clip. The clip supports phones with a width range of 2.17-3.35 inches (5.5-8.5 cm).
- **For GoPro:** Attach the GoPro mount to the 1/4" screw. Then, secure your GoPro camera to the mount using the provided GoPro screw.
- **For Cameras (Small DSLR/Mirrorless):** Directly screw your camera onto the 1/4" screw on the tripod's ball head. Ensure the camera is securely fastened. The tripod supports devices up to 2.5 kg.

## 3. Adjusting Tripod Legs and Height

The tripod legs can be adjusted for stability and height. The minimum height is 11 inches and the maximum height is 12 inches.

- To deploy the legs, gently pull them outwards until they click into place.
- To adjust the angle of the legs, use the rotating ring at the base of the ball head. This allows for angle adjustments, typically 30 to 45 degrees, providing stability on various surfaces.
- The tripod's non-slip feet ensure stability on ground or desktop surfaces.




Image: Detailed view of the tripod's 360° ball head with 1/4" screw, the rotating ring for fixing tripod legs, and the angle adjustment mechanism.

## 4. Pairing the Wireless Remote Shutter

The wireless remote shutter allows you to capture photos and videos from a distance of up to 30 feet.

1. Ensure the remote shutter has a working battery.
2. Turn on the Bluetooth function on your smartphone.
3. Press and hold the button on the remote shutter until its indicator light begins to flash, indicating it is in pairing mode.
4. On your smartphone, search for Bluetooth devices and select "LENSGO Remote" or a similar name to pair.

5. Once paired, the indicator light on the remote will stop flashing. You can now use the remote to trigger your phone's camera.




Image: The tripod's legs opened to reveal the hidden storage compartments for the universal cell phone clip and the Bluetooth remote shutter.

## Operating Instructions

### 1. Using the 360° Rotation Ball Head

The integrated ball head provides flexible positioning for your device.

- Loosen the knob on the side of the ball head to allow for free movement.
- Adjust your device to the desired angle (up to 90° tilt) and rotation (360°).
- Tighten the knob to secure the device in position.

### 2. Capturing Photos and Videos

Once your device is mounted and positioned, you can begin capturing content.

- **Using the Wireless Remote:** Open your camera application on your smartphone. Press the button on the remote shutter to take a photo or start/stop video recording. The remote supports both portrait and landscape shots.
- **Manual Operation:** You can also manually trigger your device's camera directly.




Image: A LENSGO L322 tripod with a camera and a smartphone mounted, demonstrating the use of the wireless remote shutter to capture moments.




Image: The LENSGO L322 tripod shown in various useful life situations, including holding a DSLR camera, a smartphone, and being used as a handheld grip.

## Maintenance

Proper maintenance will extend the life of your LENSGO L322 Mini Tripod.

- **Cleaning:** Wipe the tripod with a soft, dry cloth after each use to remove dust and dirt. For stubborn marks, use a slightly damp cloth and then dry thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, collapse the tripod legs and store it in a cool, dry place away from direct sunlight and extreme temperatures. The wireless remote shutter and phone clip can be stored within the tripod legs for convenience.
- **Inspection:** Periodically check all screws and joints to ensure they are tight. Do not overtighten.

## Troubleshooting

If you encounter issues with your LENSGO L322 Mini Tripod, refer to the following common solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Wireless Remote Not Connecting | ◦ Remote battery is low or dead.<br>◦ Bluetooth is off on the smartphone.<br>◦ Remote is not in pairing mode.<br>◦ Interference from other devices. | ◦ Replace the remote battery.<br>◦ Ensure Bluetooth is enabled on your smartphone.<br>◦ Press and hold the remote button to enter pairing mode.<br>◦ Move closer to the remote or away from other Bluetooth devices.<br>◦ Forget the device in your phone's Bluetooth settings and re-pair. |
| Tripod Instability | ◦ Legs not fully extended or locked.<br>◦ Device weight exceeds the limit.<br>◦ Uneven surface. | ◦ Ensure legs are fully extended and the rotating ring is tightened.<br>◦ Verify your device's weight is within the 2.5 kg limit.<br>◦ Adjust leg angles using the rotating ring to compensate for uneven surfaces. Ensure anti-skid pads are clean. |
| Device Not Fitting in Clip | ◦ Smartphone width is outside the supported range. | ◦ Check that your smartphone's width is between 2.17-3.35 inches (5.5-8.5 cm). |

## SPECIFICATIONS

| | |
|---|---|
| **Brand** | LENSGO |
| **Model Number** | L322 |
| **Product Dimensions** | 10 x 10 x 4 cm |
| **Item Weight** | 156 Grams |
| **Material** | ABS Metal |
| **Colour** | Black |
| **Compatible Devices** | iPhone, Android smartphones (width 2.17-3.35"), GoPro, Small DSLR Camera, Portable Projector, Camcorder |
| **Weight Limit** | 2500 Grams (2.5 kg) |
| **Maximum Height** | 12 Inches |
| **Minimum Height** | 11 Inches |
| **Tripod Head Type** | Ball Heads (360° Rotation) |

| | |
|---|---|
| **Remote Shutter Range** | Up to 30 feet |

## Warranty and Support

LENSGO stands behind the quality of its products.

- **Return Policy:** We accept returns within 30 days without any reason.
- **Warranty:** The LENSGO L322 Mini Tripod comes with a 6-month warranty.
- **Customer Service:** Lifetime customer service is provided. If you have any problems or questions, please feel free to contact the seller or LENSGO customer support for assistance.

© 2024 LENSGO. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question



**Open the live page**

**https://manuals.plus/asin/B07RLPNRHF**

More documents and user manuals: **https://manuals.plus/**