Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MuzicLight MZR-101

MuzicLight Violin Wall Mount Viola Hanger Multicolor LED User Manual

Model: MZR-101 | Brand: MuzicLight

1. Product Overview

The MuzicLight Violin Wall Mount Viola Hanger is designed to securely display your violin or viola while providing ambient LED lighting. It features a robust construction with a steel headstock cradle and soft foam padding to protect your instrument. The integrated multicolor LED lights enhance the visual presentation of your instrument.



Image 1.1: The MuzicLight Violin Wall Mount Hanger illuminated with blue LED light, showcasing its design and functionality.

This hanger is suitable for most common violin and viola necks and is engineered to safely hold instruments weighing up to 35 pounds. It offers versatile power options, allowing operation via 2 AA batteries or a USB connection for continuous lighting.

2. Safety Information

- Ensure the wall surface is suitable for mounting and can support the weight of the hanger and your instrument. Recommended surfaces include concrete, brick, and wood studs.
- Always use appropriate mounting hardware and follow installation instructions carefully to prevent damage or injury.
- Do not exceed the maximum weight capacity of 35 pounds.
- Keep batteries out of reach of children. Dispose of used batteries responsibly.
- Avoid exposing the unit to excessive moisture or extreme temperatures.

3. Package Contents

Verify that all items are present in the package:

- MuzicLight Violin Wall Mount Hanger (1 unit)
- Mounting Hardware (screws, drywall anchors)
- AA Batteries (2 units, pre-installed or separate)
- Instruction Manual (this document)



Image 3.1: Visual representation of the items typically included in the MuzicLight package, such as the hanger unit, mounting hardware, and batteries.

4. Setup and Installation

Follow these steps to securely install your MuzicLight Violin Wall Mount Hanger:

1. **Choose Location:** Select a suitable wall location, preferably a wall stud for maximum security. Ensure there is enough space for your instrument.
2. **Mark Drilling Points:** Hold the hanger against the wall at the desired height. Use a pencil to mark the positions for the mounting screws.
3. **Drill Pilot Holes:** Using an appropriate drill bit for your wall type (e.g., 3/16 inch for drywall anchors), drill pilot holes at the marked locations. If mounting into a wood stud, a smaller pilot hole may be sufficient.
4. **Insert Anchors (if needed):** If drilling into drywall without a stud, gently tap the provided drywall anchors into the pilot holes until flush with the wall surface.
5. **Attach Hanger:** Align the hanger's mounting holes with the drilled holes/anchors. Insert the screws and tighten them securely with a screwdriver until the hanger is firmly attached to the wall. Do not overtighten.
6. **Install Batteries:** If using battery power, ensure 2 AA alkaline batteries are correctly inserted into the battery compartment. The batteries are typically included.
7. **Test Stability:** Gently pull on the installed hanger to confirm it is stable and securely fastened before hanging your instrument.

MUZICLIGHT

PLAY IT & DISPLAY IT



MultiColor



Multi Power Option



In The box

With versatile power options, you can choose to power the LED lights using 2 AA batteries (included) for up to 200 hours of illumination, or via USB for continuous lighting. The durable plastic construction ensures long-lasting performance, while the easy installation process allows you to mount the hanger securely to any wall. Whether you're a musician looking to display your violin or a collector seeking a unique lighting solution,

Image 4.1: Detailed view of the MuzicLight unit, highlighting the USB power input, the control button for color changes and power, and the location of the LED lights.

The hanger features a back plate design, ensuring no exposed hardware is visible after installation, contributing to a clean aesthetic.

5. Operating Instructions

5.1 Hanging Your Instrument

The headstock cradle is made of solid steel with a foam coating to protect your instrument's finish. The angled cradle design ensures your violin or viola is held securely. To remove the instrument, lift it approximately 2 inches upwards from the cradle.



Image 5.1: This diagram shows the swivel mechanism of the hanger's posts, allowing adjustment for various instrument headstock shapes, both symmetrical and asymmetrical.

5.2 LED Lighting Control

The integrated LED lights offer multiple color options to illuminate your instrument. The lights are controlled by an on/off button located on the unit.

- **Power On/Off:** Press the control button once to turn the LED lights on or off.
- **Change Color:** While the lights are on, press the control button repeatedly to cycle through the available multicolor options (e.g., red, green, white, purple, blue).



Image 5.2: A series of MuzicLight hangers demonstrating the range of available LED colors, including red, green, blue, purple, and white, illuminating the wall behind the instrument.

5.3 Power Options

The MuzicLight hanger can be powered in two ways:

- **AA Batteries:** Two AA alkaline batteries (included) provide power for over 200 hours of illumination under normal usage. This offers wireless operation.
- **USB Power:** For continuous lighting, the unit can be powered via a USB connection. Connect a standard USB cable

(not included) to the USB power input port on the hanger and to a compatible USB power source (e.g., wall adapter, power bank).



Image 5.3: Example of multiple instruments, including violins and a cello, elegantly displayed on a wall using MuzicLight hangers, showcasing the ambient lighting effect in a living space.

6. Maintenance

- **Cleaning:** Wipe the hanger with a soft, dry cloth to remove dust. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** When the LED lights dim or stop working, replace both AA batteries with new alkaline batteries. Ensure correct polarity.
- **Foam Protection:** Periodically inspect the foam padding on the headstock cradle for wear and tear. Replace the unit if the foam is significantly damaged to prevent scratching your instrument.

7. Troubleshooting

Problem	Possible Cause	Solution
LED lights do not turn on.	◦ Batteries are dead or incorrectly inserted. ◦ USB cable is not connected or power source is off. ◦ Unit is damaged.	◦ Replace batteries with new AA alkaline batteries, ensuring correct polarity. ◦ Check USB cable connection and power source. ◦ Contact customer support if the unit is damaged.
Lights are dim.	◦ Batteries are low.	◦ Replace batteries. ◦ Consider using USB power for consistent brightness.
Hanger feels loose on the wall.	◦ Screws are not tightened sufficiently. ◦ Improper installation for wall type.	◦ Retighten screws. ◦ Re-install using appropriate anchors or by locating a wall stud.

8. Specifications

Model Number	MZR-101
Brand	MuzicLight
Color	Violin Multicolor
Material	Plastic (Body), Steel (Cradle)
Mounting Type	Wall Mount
Maximum Weight Capacity	35 Pounds
Dimensions (L x W x H)	6.48 x 4.5 x 2.97 inches
Item Weight	10.5 ounces
Power Source	2 AA Alkaline Batteries (included) or USB
Included Components	Mounting Hardware, 2 AA Batteries
Recommended Surfaces	Concrete, Brick, Wood
UPC	680201831254

9. Warranty Information

The MuzicLight Violin Wall Mount Viola Hanger comes with a**Lifetime Limited Warranty**. This warranty covers defects in materials and workmanship under normal use. For specific terms, conditions, and to make a warranty claim, please

refer to the warranty documentation included with your product or contact MuzicLight customer support.

10. Customer Support

For further assistance, technical support, or inquiries regarding your MuzicLight product, please visit the official MuzicLight store or contact their customer service department.

- **MuzicLight Store:** Visit the MuzicLight Store on Amazon
- **Manufacturer:** Muziclight

© 2025 MuzicLight. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07RMKZLDK

More documents and user manuals: **https://manuals.plus/**