ZdalaMit AKB75135401

User Manual: AKB75135401 Replacement Remote Control

For LG Ultra HD Blu-ray Disc Players

1. Introduction and Overview

This manual provides essential information for the operation and maintenance of your ZdalaMit AKB75135401 Replacement Remote Control. This remote is designed as a direct replacement for original LG Ultra HD Blu-ray Disc Player remotes, offering seamless functionality without the need for complex programming or pairing.
The AKB75135401 remote control is compatible with various LG Blu-ray Disc Player models, ensuring you can quickly regain control of your entertainment system.

2. Product Features

- Direct replacement for LG Ultra HD Blu-ray Disc Player remote controls.
- No programming or pairing required; ready for use after battery installation.
- Ergonomic design for comfortable handling.
- Durable buttons with tactile feedback.

3. Setup

3.1 Battery Installation

The AKB75135401 remote control requires two (2) AAA alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Battery compartment on the back of the remote control.

Once batteries are installed, the remote control is ready for immediate use with compatible LG Blu-ray Disc Players.

4. Operating Instructions

The AKB75135401 remote control provides full functionality for your LG Blu-ray Disc Player. Point the remote control directly at the Blu-ray Disc Player for optimal performance.



Figure 2: Front view of the AKB75135401 remote control.

4.1 Basic Functions

- **POWER:** Turns the Blu-ray Disc Player on or off.
- **OPEN/CLOSE:** Opens or closes the disc tray.
- **Number Buttons (0-9):** Used for direct track selection or inputting numbers.

- **Play/Pause (▶/‖):** Starts or pauses playback.
- **Stop (■):** Stops playback.
- **Fast Forward (▶▶):** Skips forward through content.
- **Rewind (◀◀):** Skips backward through content.
- **Skip Forward (▶▶▶):** Skips to the next track/chapter.
- **Skip Backward (◀◀◀):** Skips to the previous track/chapter.

4.2 Navigation and Menu Functions

- **HOME:** Accesses the main home menu of the Blu-ray Disc Player.
- **INFO/MENU:** Displays information or accesses the disc menu.
- **Directional Arrows (Up, Down, Left, Right):** Navigates through menus and options.
- **ENTER:** Confirms a selection.
- **BACK:** Returns to the previous screen or menu.
- **DISC MENU:** Accesses the menu of the currently playing disc.
- **CAPTION:** Toggles closed captions or subtitles.
- **REPEAT:** Repeats playback of a track or chapter.

4.3 TV Control Functions (Limited)

This remote includes basic TV control functions. Note that these functions may vary in compatibility depending on your TV model.

- **TV POWER:** Turns the connected TV on or off.
- **INPUT:** Cycles through TV input sources.
- **VOL-** / **VOL+:** Adjusts the TV volume down or up.
- **Colored Buttons (R, G, Y, B):** These buttons typically correspond to specific functions within menus or applications, as indicated on-screen by your Blu-ray player.

5. Compatible Models

The AKB75135401 Replacement Remote Control is compatible with the following LG Ultra HD Blu-ray Disc Player models:

- LG UBK80
- LG UP870
- LG UP875
- LG BPM35
- LG BP175

If your model is not listed, please verify compatibility with the product specifications or contact customer support.

6. Specifications

Feature	Detail
Model Number	AKB75135401
Brand	ZdalaMit

Power Supply	2 x 1.5V AAA Alkaline Battery (not included)
Product Dimensions	6 x 1.8 x 0.5 inches
Item Weight	0.001 ounces
Color	Black
Compatible Devices	LG DVD/Blu-ray Players (UBK80, UP870, UP875, BPM35, BP175)

7. Troubleshooting

7.1 Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old or depleted batteries with new AAA alkaline batteries.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the Blu-ray Disc Player. The remote requires a clear line of sight to the player's infrared sensor.
- **Distance:** Ensure you are within the effective operating range of the remote control (typically up to 20 feet).
- **Player Power:** Verify that the Blu-ray Disc Player is powered on and functioning correctly.

7.2 Specific Buttons Not Working

- **Clean Contacts:** If certain buttons are unresponsive, try removing the batteries and gently cleaning the battery contacts inside the compartment and on the batteries themselves with a clean, dry cloth.
- **Test with Camera:** You can test if the remote is sending an infrared signal by pointing the remote's IR emitter at a digital camera (like a smartphone camera) and pressing a button. If you see a light flashing on the camera screen, the remote is likely sending a signal.

If troubleshooting steps do not resolve the issue, please refer to the Support section.

8. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries when the remote's performance degrades. If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry.

9. Warranty and Support

For any queries or assistance regarding your ZdalaMit AKB75135401 Replacement Remote Control, please contact the manufacturer or seller directly. Information regarding specific warranty terms may be provided at the point of purchase or on the product packaging.
Please retain your purchase receipt for warranty purposes.

© 2025 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question