ANGELLOONG MF-03X456

ANGELLOONG Flickering Flameless Candles User Manual

Model: MF-03X456

1. Introduction and Overview

Thank you for choosing ANGELLOONG Flickering Flameless Candles. This set of realistic LED candles provides a warm, inviting ambiance without the hazards of traditional flames. Designed for both indoor and outdoor use, these battery-operated candles offer convenience and safety with remote control functionality and a built-in timer. This manual provides essential information for the safe and effective use of your new LED candles.



Image: The ANGELLOONG Flickering Flameless Candles set, including three candles of varying heights and the accompanying remote control.

2. What's in the Box

Your package includes the following components:

- 3 x Flameless LED Candles (sizes: 3x4, 3x5, 3x6 inches)
- 1 x Remote Control

3. Setup

Battery Installation

Each candle requires 2 x AA batteries (not included). For optimal performance, use high-quality alkaline batteries.

1. Locate the battery compartment on the bottom of each candle.
2. Open the battery cover by sliding or gently prying it off.
3. Insert 2 AA batteries into the compartment, ensuring correct polarity (+ and - ends match the diagram inside).
4. Close the battery cover securely.



Image: The base of an ANGELLOONG candle, illustrating the battery compartment and its cover.

4. Operating Instructions

Remote Control Functions

Your ANGELLOONG Flameless Candles come with an 8-key remote control for convenient operation. Ensure the remote is pointed towards the candles for best response.



Image: The remote control for the candles, showing buttons for ON/OFF, Timer, Mode (Candle/Light), and Dimming.

ON/OFF Button: Press the **ON** button to turn all candles on. Press the**OFF** button to turn all candles off.

TIMER Buttons (2H/4H/6H/8H): Select the desired duration for the candles to remain on. Once set, the candles will automatically turn off after the selected time and turn back on at the same time the next day, cycling every 24 hours.

MODE Buttons (Candle/Light):

- **Candle:** Activates the realistic flickering flame effect.
- **Light:** Provides a steady, non-flickering light.

DIM Buttons (+/-): Press the **+** button to increase brightness. Press the**-** button to decrease brightness.

Manual Operation

Each candle also features a physical ON/OFF switch located on its base. This allows for individual control of each

candle, independent of the remote control.

5. Features & Benefits

- **Realistic 3D LED Flame:** Designed with a simulated black wick and 3D flickering effect to mimic the natural movement of a real candle flame.
- **Remote Control Convenience:** Easily manage power, timer settings, lighting mode (flicker or steady), and brightness levels from a distance.
- **Timer Functionality:** The integrated timer allows for automatic shut-off after 2, 4, 6, or 8 hours, conserving battery life and providing automated ambiance.
- **Indoor & Outdoor Use:** Constructed from durable plastic, these candles are weather-resistant and suitable for both indoor and outdoor environments, such as patios, decks, and living rooms.
- **Enhanced Safety:** Enjoy the aesthetic appeal of candles without the risks associated with open flames, smoke, dripping wax, or fire hazards, making them safe for homes with children and pets.
- **Versatile Decor:** The classic ivory color and varying sizes (3x4, 3x5, 3x6 inches) allow for flexible arrangement and complement a wide range of decor styles for various occasions, including weddings, holidays, and everyday home ambiance.

6. Maintenance

- **Cleaning:** Clean the candles with a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the plastic surface.
- **Battery Care:** Remove batteries from the candles if they will not be used for an extended period (e.g., several weeks or months) to prevent potential battery leakage and damage to the product.
- **Storage:** Store the candles in a cool, dry place away from direct sunlight or extreme temperatures when not in use.

7. Troubleshooting

- **Candles not turning on:**
  - Check that the physical ON/OFF switch on the bottom of each candle is in the 'ON' position.
  - Verify that the batteries are inserted with correct polarity (+ and -).
  - Replace old batteries with new, fresh AA batteries.
  - Ensure the remote control has a working battery and is pointed directly at the candles.
- **Flicker effect not working / Light is steady:**
  - Press the 'Candle' mode button on the remote control to activate the flickering effect.

- **Remote not responding:**
  - Check the remote's battery and replace if necessary.
  - Ensure there are no obstructions between the remote and the candles.
  - Try moving closer to the candles.

8. Specifications

Feature	Detail
Brand	ANGELLOONG
Model Number	MF-03X456
Material	Plastic
Light Source Type	LED
Power Source	Battery Powered (2 AA batteries per candle)
Control Type	Remote Control
Color	Classic Ivory
Product Dimensions	3"D x 3"W x 6"H (various sizes included)
Item Weight	Approx. 0.17 Kilograms (5.9 ounces)
Special Features	Dimmable, Weather-Resistant, Cordless
Water Resistance Level	Waterproof

9. Warranty & Support

For warranty information or technical support regarding your ANGELLOONG Flickering Flameless Candles, please contact ANGELLOONG customer service through the retailer where the product was purchased.
You can also visit the official ANGELLOONG Store for more information:ANGELLOONG Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question