Beurer MP42

Beurer MP42 Nail Drill Instruction Manual

Model: MP42 | Brand: Beurer

Product Overview

Achieve salon quality nail care from the comfort of your home with the Beurer MP42 electronic nail drill. This powerful fingernail drill can be used on natural or acrylic nails, and for both fingernails and toenails.

Key Features:

- **7-in-1 NAIL KIT:** The MP42 Nail Drill includes 7 sapphire, stainless steel, and felt nail drill bits, it also comes with a dust shield to collect nail dust, a portable storage case and 10ft cord - please note this is NOT cordless, item must be plugged in during use.
- **LED PRECISION LIGHT:** This electric nail file has an LED light to brightly illuminate the spot you're treating and make it easier see – use our efile nail drill to buff your nails like a professional.
- **DUAL ROTATION:** Simply flip a switch, and MP42 nail dremel can spin clockwise or counterclockwise for treatment of your left or right hand or foot, a great addition to your pedicure kit or manicure set.
- **5 SPEED LEVELS:** Our electric nail drill has a continuously adjustable speed up to 5 levels – tough enough to grind thick toenails or remove calluses yet gentle enough for those with sensitive skin.
- **ERGONOMIC GRIP:** Keep the nail drill machine securely in your hand during use with our ergonomic design that prevents slipping – this nail buffer and drill bit set is an essential in your nail supplies.

Important Safety Information

Please read all safety instructions carefully before using the Beurer MP42 Nail Drill.

- Handle with care due to sharp drill bits.
- Ensure the product is unplugged when not in use.
- Keep away from water.
- Users with sensitive skin should be cautious using at higher speed levels.

Product Components

The Beurer MP42 Nail Drill comes with the main unit and 7 high-quality attachments, along with a dust shield and storage case.

Included Attachments:

- **Sapphire Cone:** Used for removing dry skin or calluses from the soles and heels of the feet and for manicuring nails.
- **Sapphire Disk with a fine grain texture:** Used for filing and treatment of the nails.
- **Sapphire Disk with a coarse grain texture:** Used for filing and treatment of the nails.
- **Sapphire Callus Rasp:** Used for the fast removal of thick or large calluses on the soles and heels of the feet.
- **Flame Milling Cutter:** Used for removing ingrown nails on both hands and feet.
- **Cylindrical Milling Cutter:** Used for the grinding and smoothing of any lignified foot nail surfaces.
- **Felt Cone:** Used for smoothing and polishing the edge of nails after filing, as well as for cleaning the nail surface.



Image: The Beurer MP42 Nail Drill unit, its 7 interchangeable sapphire and felt attachments, power adapter, and compact storage case.

Setup Guide

1. **Unpack:** Carefully remove all components from the storage case.
2. **Connect Power:** Plug the power adapter into a suitable electrical outlet. Connect the other end of the cord to the Beurer MP42 Nail Drill unit. Note: This device is corded and requires continuous power during use.
3. **Select Attachment:** Choose the appropriate sapphire or felt attachment for your desired treatment (refer to "Product Components" section for details).
4. **Attach Bit:** Firmly insert the selected attachment into the opening at the tip of the drill unit until it clicks securely into place.
5. **Optional Dust Shield:** For certain treatments, especially those generating dust, attach the clear dust shield over the working end of the drill.

Your browser does not support the video tag.

Video: Official product video demonstrating the setup and various features of the Beurer MP42 Nail Drill Kit.

Operating Instructions

1. **Power On:** Once plugged in, slide the power switch to the 'on' position. The integrated LED light will illuminate, providing precision lighting for your treatment area.
2. **Adjust Speed:** Use the '+' and '-' buttons on the unit to select one of the 5 continuously adjustable speed levels. Start with a lower speed and gradually increase as needed for comfort and effectiveness.
3. **Select Rotation Direction:** Utilize the dual rotation switch to change the direction of the drill's rotation (clockwise or counterclockwise). This feature allows for comfortable use on both left and right hands/feet, and for different nail shaping techniques.
4. **Perform Treatment:** Gently apply the rotating attachment to the nail or skin area you wish to treat. Avoid excessive pressure to prevent discomfort or injury. Move the drill smoothly across the surface.
5. **Monitor Progress:** The bright LED light helps you clearly see the area being treated, ensuring precise and effective results.



Image: The Beurer MP42 Nail Drill displaying its 5 adjustable speed levels via LED indicators.



Image: The Beurer MP42 Nail Drill highlighting its dual rotation capability for versatile use.

Maintenance and Care

- **Cleaning Attachments:** After each use, remove the attachment from the drill unit. Clean the sapphire and felt attachments with a brush or damp cloth to remove any nail dust or debris. For thorough cleaning, attachments can be disinfected with alcohol.
- **Cleaning Unit:** Wipe the main drill unit with a soft, dry cloth. Do not immerse the unit in water or use abrasive cleaners.
- **Storage:** Store the Beurer MP42 Nail Drill and all its attachments in the provided portable storage case to protect them from dust and damage. Ensure the unit is unplugged before storing.

Troubleshooting

If you encounter any issues with your Beurer MP42 Nail Drill, please refer to the following common solutions:

- **Device Not Turning On:** Ensure the power adapter is securely plugged into both the wall outlet and the drill unit. Verify that the power switch is in the 'on' position.
- **Attachment Not Rotating:** Check that the attachment is fully and securely inserted into the drill tip. If it's loose, it may not engage properly.
- **Reduced Performance/Overheating:** If the device feels hot or performance decreases, allow it to cool down for at least 15-20 minutes before resuming use. Avoid prolonged continuous operation. Ensure attachments are clean and free of debris that might impede rotation.
- **Attachments Not Staying in Tool:** Ensure the attachment is pushed firmly into the spindle until it clicks. If issues persist, inspect the spindle for any damage or wear.

Technical Specifications

Feature	Detail
Model Name	MP42 Nail Drill
Brand	Beurer
Power Source	Corded Electric (10ft cord)
Speed Levels	5 (continuously adjustable)
Rotation Direction	Dual (Clockwise/Counterclockwise)
Attachments Included	7 (Sapphire and Felt)
Special Features	Integrated LED Light, Dust Shield, Ergonomic Grip, Portable Storage Case
Product Dimensions	1.5"L x 1.5"W x 5.98"H
Item Weight	4 ounces
Material	Stainless Steel (attachments)
UPC	853879007430
Country of Origin	China

Warranty and Support

For warranty information and customer support, please refer to the official Beurer website or the user manual included with your product.

A digital version of the user manual can be foundhere.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question