Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Garmin PRO 550 Plus

Garmin PRO 550 Plus Handheld

DOG TRAINING AND TRACKING DEVICE INSTRUCTION MANUAL

1. Product Overview

The Garmin PRO 550 Plus is a rugged, one-handed device designed for dog training and tracking. It provides at-a-glance directional tracking and customizable training options for up to three dogs, with a range of up to 9 miles.





Image: The Garmin PRO 550 Plus handheld device, showing its compact design and display screen.

- **Fast Location Tracking:** Features a 2.5-second update rate for quick dog location tracking.
- **Customizable Training:** Offers 18 levels of continuous and momentary stimulation, along with tone and vibration settings.
- **At-a-Glance Tracking:** Built-in display with GPS and GLONASS satellite reception indicates direction and distance to your dogs.

2. Package Contents

Verify that all items are present in your PRO 550 Plus package:

- PRO 550 Plus Handheld device

- AC Adapter
- Instruction Manual (this document)

3. Initial Setup

3.1 Charging the Device

Before first use, fully charge the PRO 550 Plus handheld device using the provided AC adapter. Connect the adapter to the device's charging port and plug it into a standard wall outlet. The charging indicator will show the status.

3.2 Pairing with Dog Collars

The PRO 550 Plus is designed to pair with compatible Garmin dog collars (e.g., TT25). Follow these steps to pair your handheld with a collar:

1. Ensure both the handheld and the dog collar are powered on and within close proximity.
2. Access the pairing menu on the PRO 550 Plus (refer to the on-screen prompts).
3. Initiate pairing on both devices. The handheld will search for available collars.
4. Once detected, confirm the pairing. The device will indicate successful connection.

For detailed pairing instructions specific to your collar model, consult the collar's instruction manual.

4. Operation Guide

4.1 Powering On/Off

To power on the device, press and hold the power button located on the side of the unit until the screen illuminates. To power off, press and hold the power button again until a power-off prompt appears, then confirm.

4.2 Tracking Dogs

The PRO 550 Plus provides directional tracking to your paired dogs. The built-in display shows an arrow indicating the direction and a numerical value for the distance to each dog. The device updates location every 2.5 seconds, providing near real-time tracking.

4.3 Training Functions

The device offers various training modes:

- **Stimulation:** Choose between 18 levels of continuous or momentary stimulation. Adjust the level based on your dog's temperament and training needs.
- **Tone:** Emits an audible tone from the collar.
- **Vibration:** Provides a tactile vibration from the collar.

Use the dedicated buttons on the handheld to select the desired training function and intensity. The one-handed design allows for intuitive, no-look operation.

4.4 Garmin Explore App Integration

The PRO 550 Plus can be linked with the Garmin Explore app on your smartphone for enhanced mapping capabilities. Refer to the Garmin Explore app documentation for setup and usage details.

5. Care and Maintenance

5.1 Cleaning

Regularly clean the device with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the unit.

5.2 Battery Care

The PRO 550 Plus is equipped with a rechargeable Lithium Ion battery, offering up to 24 hours of life. To prolong battery lifespan, avoid extreme temperatures and fully charge the device before extended storage.

5.3 Software Updates

Garmin periodically releases software updates to improve performance and add features. Connect your device to a computer and use Garmin Express software to check for and install available updates.

6. Troubleshooting Common Issues

- **Device not connecting to collars:**
  Ensure both the handheld and collars are charged and powered on. Try turning the handheld off and on again to re-establish connection. Verify that the collars are compatible and properly paired.
- **Inaccurate direction or distance readings:**
  Ensure you have a clear view of the sky for optimal GPS/GLONASS reception. Environmental factors like dense foliage or tall buildings can interfere with satellite signals. Recalibrate the compass if available in the device settings.
- **Short battery life:**
  Ensure the device is fully charged. Extreme temperatures can affect battery performance. If battery life significantly degrades, contact Garmin support.
- **Device unresponsive:**
  Attempt a soft reset by holding the power button for an extended period (e.g., 15 seconds) until the device restarts. If the issue persists, ensure the device is charged.

For further assistance, refer to the official Garmin support resources online.

7. Technical Specifications

Feature	Specification
Product Dimensions	8 x 5 x 3 inches
Item Weight	1.06 pounds
Model Number	010-02035-50
Batteries	1 Lithium Ion battery (included)
Connectivity Technologies	GPS, GLONASS
Special Features	One-Handed Operation, No-Look Tracking, Customizable Training

Human Interface Input	Buttons
Color	Black
Battery Life	Up to 24 Hours

8. Warranty Information and Support

The Garmin PRO 550 Plus is covered by a limited warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Garmin website. For technical support, product registration, and additional resources, please visit the Garmin support page or contact Garmin customer service.

You can find more information and support at the officialGarmin Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07SG785XG

More documents and user manuals: **https://manuals.plus/**