Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY RC4870

ALLIMITY RC4870 Replacement Remote Control User Manual

Model: RC4870

1. Introduction

Thank you for choosing the ALLIMITY RC4870 Replacement Remote Control. This remote is designed to be a direct replacement for various TV models from brands such as Polaroid, Techwood, Telefunken, Selecline, Panasonic, and JVC. This manual provides detailed instructions on how to set up, operate, and maintain your new remote control to ensure optimal performance.

2. Product Overview

The ALLIMITY RC4870 remote control features a standard layout with all essential buttons for controlling your television. Familiarize yourself with the remote's design and button placement.



Figure 2.1: Angled view of the ALLIMITY RC4870 remote control, showing the full button layout and ergonomic design.





Figure 2.2: Front view of the ALLIMITY RC4870 remote control, highlighting the numerical keypad, navigation buttons, and media controls.





Figure 2.3: Back view of the ALLIMITY RC4870 remote control, showing the battery compartment and the model number RC4870.

3. Setup

3.1 Battery Installation

The remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Note: *Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.*

4. Operating Instructions

This remote control is pre-programmed and ready to use with compatible TV models. No additional programming is typically required.

4.1 Basic Functions

- **Power Button ( ):** Turns the TV on or off.
- **Number Buttons (0-9):** Selects channels directly.
- **Volume Up/Down (+/-):** Adjusts the volume level.
- **Channel Up/Down (P+/-):** Changes channels sequentially.
- **Mute Button ( ):** Mutes or unmutes the TV sound.
- **MENU Button:** Accesses the TV's main menu.
- **OK Button:** Confirms selections within menus.
- **Navigation Buttons (▲▼◀▶):** Navigates through menu options.
- **BACK Button:** Returns to the previous screen or menu.
- **EXIT Button:** Exits the current menu or function.

4.2 Advanced Functions

- **LANG. Button:** Changes the audio language or subtitle language if available.
- **Colored Buttons (Red, Green, Yellow, Blue):** Used for specific functions within certain TV menus or applications, as indicated on the screen.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward):** Controls playback of media content (e.g., from a USB drive or smart TV apps).
- **Info Button (i):** Displays information about the current program or input.

5. Maintenance

5.1 Cleaning

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, abrasive cleaners, or immerse the remote in water.

5.2 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.

6. Troubleshooting

If you encounter issues with your remote control, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Remote not responding.	◦ Check if batteries are inserted correctly with correct polarity. ◦ Replace old or depleted batteries with new ones. ◦ Ensure there are no obstructions between the remote and the TV's infrared sensor. ◦ Point the remote directly at the TV.
Some buttons are not working.	◦ This remote is a replacement and may not support all functions of your original remote if your TV model has unique features. ◦ Ensure the remote is clean and free of debris that might obstruct button presses.
Short operating range.	◦ Batteries may be low; replace them. ◦ Ensure no strong light sources (like direct sunlight) are interfering with the TV's IR sensor.

7. Specifications

Feature	Description
Brand	ALLIMITY
Model Number	RC4870
Connectivity Technology	Infrared (IR)
Compatible Devices	POLAROID P40D100, P32LED12, P40LED13, PT240LED14; Selecline 40284, 32182, etc.; Panasonic Viera TX-39AW304, TX-32A300E, etc.; Techwood XF32A300, TC49278DLED, etc. (Refer to product listing for full compatibility list)
Special Feature	Lightweight design
Battery Type	2 x AAA batteries (not included)
Maximum Range	10 Meters

Feature	Description
Number of Buttons	2 (This seems to be an error in the source data, as the image clearly shows many more buttons. The remote has a full set of control buttons.)

8. Warranty and Support

8.1 Warranty Information

This product is typically covered by a standard manufacturer's warranty. Please refer to the specific warranty terms provided by the seller or manufacturer at the time of purchase. Keep your proof of purchase for any warranty claims.

8.2 Customer Support

For further assistance, technical support, or inquiries regarding your ALLIMITY RC4870 remote control, please contact the seller or manufacturer directly through the platform where the product was purchased. Provide your model number (RC4870) and a detailed description of your issue for efficient support.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07SG9MYJD

More documents and user manuals: **https://manuals.plus/**