Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY RC4875

ALLIMITY RC4875 Replacement Remote Control User Manual

Model: RC4875

1. Introduction

This manual provides instructions for the ALLIMITY RC4875 Replacement Remote Control, designed for various Telefunken television models. This remote control offers direct compatibility without requiring complex setup procedures.

2. Product Overview



Figure 1: ALLIMITY RC4875 Remote Control (Angled Front View)

This image displays the ALLIMITY RC4875 remote control from an angled front perspective. All buttons, including number keys, volume and channel controls, navigation pad, and special function buttons, are visible. The remote has a black finish with clearly labeled white and colored buttons.



Figure 2: ALLIMITY RC4875 Remote Control (Straight Front View)

This image shows a direct front view of the ALLIMITY RC4875 remote control. It emphasizes the ergonomic layout of the buttons, including the power button, numeric keypad, volume and channel up/down, mute, menu, navigation arrows with OK button, back, exit, and colored function keys.



Figure 3: ALLIMITY RC4875 Remote Control (Back View with Battery Compartment)
This image presents the back of the ALLIMITY RC4875 remote control with the battery compartment cover removed. It clearly shows the slots for two AAA batteries, indicating the correct polarity for insertion. The model number "RC4875" is also visible on the back casing.

3. Setup

The ALLIMITY RC4875 remote control is designed for immediate use with compatible Telefunken TV models without requiring any programming or pairing. Simply insert the batteries, and it should function directly.

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards and remove it.
3. Insert two (2) AAA batteries, ensuring the correct polarity (+ and -) matches the diagrams inside the compartment. Refer to Figure 3 for visual guidance.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

Note: Batteries are not included with the remote control.

4. Operating Instructions

The ALLIMITY RC4875 remote control provides standard functions for controlling your compatible Telefunken television. Point the remote directly at the TV's infrared receiver for optimal performance.

4.1 Button Functions

- **Power Button (●):** Turns the TV on or off.
- **Numeric Keypad (0-9):** Directly select channels.
- **Volume Up/Down (+V / -V):** Adjusts the sound volume.
- **Channel Up/Down (+P / -P):** Changes the TV channel.
- **Mute Button (☒):** Mutes or unmutes the TV sound.
- **Menu Button:** Accesses the TV's main menu.
- **Navigation Arrows (▲ ◄ OK ► ▼):** Navigate through menus and options.
- **OK Button:** Confirms selections in menus.
- **Back Button:** Returns to the previous screen or menu.
- **Exit Button:** Exits the current menu or function.
- **Colored Function Buttons (Red, Green, Yellow, Blue):** These buttons typically correspond to specific functions displayed on your TV screen, often used in smart TV interfaces or teletext.
- **LANG. Button:** Changes audio language or subtitle options.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** Used for media playback functions, if supported by your TV.

5. Maintenance

5.1 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's surface or buttons.

5.2 Battery Replacement

Replace batteries when the remote control's response becomes inconsistent or stops working. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

5.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can damage the device.

6. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the maximum operating range (up to 10 meters).
- **Intermittent response:**
  - This often indicates low battery power. Replace the batteries.
  - Clean the remote's infrared emitter and the TV's sensor if they appear dirty.

- **Remote works for some functions but not others:**
  - Verify that your TV model is listed as compatible. Some advanced functions might be TV-specific.
  - Ensure no buttons are stuck or jammed.

7. Specifications

Attribute	Detail
Brand	ALLIMITY
Model Number	RC4875
Connectivity Technology	Infrared
Controller Type	Button Control
Special Feature	Lightweight
Color	Aubergine
Maximum Supported Devices	1
Maximum Range	10 Meters
Batteries Required	2 x AAA (not included)

7.1 Compatible Telefunken TV Models

This remote control is compatible with a wide range of Telefunken TV models, including but not limited to:

D32H277N3C, D39F182C3C, D39F185N2, D39F185N3, D39F185N3C, D40F125A3C, D40F125R3C, D40F127I3, D40F182C3C, D40F280R3CW, TFL20DVSAT12V16B, TFL2405HDB, L48F249A3CW, XF40A300, TFL40282305DLED16WH, H32V3WHITE, LF39NZ20D, D43F278N3CW, TE65249G35C2N, D32F289R3C, TFL32DHD04B, WF39-EA10, D40F289N3CW, A49F535A, A43F435A, TFS40D02SDFHDB, TFL20SAT12V17B, TFL20DVSAT12V17B, TE32EUB35TXD, TFL40DFHD04B, TE24EUB37TXB, TE32EUS27TXD, 22DV6115, 29TLK512E, 32FLY168S, 32TLKDLEDSMART, 32TX182D, CF32H130KCTS2B, D32F197I3C, D32F197R3C, D32F275I3, D32H125A3, D32H125A3C, D32H125N2, D32H125N2V1, D32H125N3, D32H125N3C, D32H127N2, D32H182C3C, D32H182N3C, D32H182Q3, D32H189B2

8. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your original purchase or contact the seller directly. As a replacement remote, specific warranty terms may vary.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07SMNKC6T

More documents and user manuals: **https://manuals.plus/**