Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Rosieres RIES844SC

Rosieres RIES844SC Induction Hob User Manual

Model: RIES844SC

1. Introduction

Thank you for choosing the Rosieres RIES844SC Left Flexi Zone+ 2 Induction Hob. This appliance is designed for efficient and safe cooking, featuring a versatile Flexi Zone that can adapt to various cookware sizes. This manual provides essential information for the correct installation, operation, maintenance, and troubleshooting of your new induction hob. Please read it thoroughly before using the appliance and keep it for future reference.

The Rosieres RIES844SC induction hob offers rapid heating and precise temperature control, making it ideal for a wide range of cooking tasks from boiling water to simmering delicate sauces. Its induction technology ensures quick response times and energy efficiency.

2. Safety Instructions

Your safety and the safety of others are paramount. Please observe the following safety precautions:

- **Electrical Safety:** Ensure the hob is installed by a qualified electrician in accordance with local wiring regulations. Do not attempt to repair or modify the appliance yourself.
- **Hot Surfaces:** Although induction hobs heat the cookware directly, the hob surface can become hot from residual heat. Avoid touching the hob surface immediately after cooking.
- **Pacemakers and Medical Implants:** Individuals with pacemakers or other medical implants should consult their doctor before using an induction hob, as electromagnetic fields may interfere with their operation.
- **Metal Objects:** Do not place metal objects such as knives, forks, spoons, or lids on the hob surface, as they can become hot.
- **Children and Vulnerable Persons:** This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- **Ventilation:** Ensure adequate ventilation around the appliance as specified in the installation instructions to prevent overheating.
- **Flammable Materials:** Keep flammable materials away from the hob during operation.
- **Proper Cookware:** Only use induction-compatible cookware. Non-compatible cookware will not heat up.

3. Installation and Setup

Installation of the Rosieres RIES844SC induction hob should only be performed by a qualified technician or electrician. Incorrect installation can lead to hazards and void the warranty.

3.1 Unpacking

Carefully remove the hob from its packaging. Inspect the appliance for any signs of damage. If damage is found, do not install or use the hob and contact your retailer immediately.

3.2 Placement and Ventilation

Ensure the installation area provides sufficient clearance and ventilation as per the installation template provided with the appliance. The hob requires adequate airflow to function correctly and prevent overheating. The package dimensions are approximately 89 x 64 x 15 cm, which can serve as a guide for the required cutout and surrounding space.

3.3 Electrical Connection

The hob must be connected to a suitable electrical supply by a qualified electrician. Refer to the wiring diagram in the separate installation guide for specific connection details. The appliance operates at 7400 watts.



Figure 1: Top view of the Rosieres RIES844SC Induction Hob. It features two distinct circular cooking zones on the right side and a larger, rectangular flexible cooking zone on the left side, designed to accommodate various pot sizes or be used as two separate zones. The control panels are located at the bottom front.

4. Operating Instructions

4.1 Compatible Cookware

Induction hobs require cookware with a magnetic base. To check if your cookware is compatible, hold a magnet to the bottom of the pot or pan. If the magnet sticks, the cookware is suitable for induction cooking.

4.2 Turning On/Off

- **To Turn On:** Touch the main power button (⏻) on the control panel. The display will illuminate.
- **To Turn Off:** Touch the main power button again. The hob will switch off, and residual heat indicators (if any) will appear.

4.3 Selecting a Cooking Zone and Adjusting Power

- Place an induction-compatible pan on the desired cooking zone.
- Touch the corresponding zone selection button on the control panel.
- Use the slider or '+' and '-' buttons to adjust the power level from 1 (low) to 9 (high).

4.4 Using the Flexi Zone

The left side of the hob features a Flexi Zone, which can be used as a single large cooking area or divided into two separate zones. This is ideal for larger pots, griddle pans, or multiple smaller pans.

- **To use as two separate zones:** Place pans on the individual markings within the Flexi Zone. Select each zone separately and adjust power as described above.
- **To combine into a single large zone:** Place a large pan (e.g., a griddle) across both markings of the Flexi Zone. Touch the Flexi Zone activation button (often indicated by a bridge or linked zones icon). The hob will recognize the

large pan and operate both sections as one. Adjust the power level for the combined zone.

4.5 Timer Function

The hob may include a timer function for individual zones or a general minute minder. Refer to the specific icons on your control panel for activation and adjustment. Typically, you select the zone, then press the timer button and use '+' and '-' to set the desired cooking time.

5. Cleaning and Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Rosieres RIES844SC induction hob.

- **Before Cleaning:** Always ensure the hob is switched off and has cooled down completely.
- **Daily Cleaning:** Wipe the ceramic glass surface with a soft cloth or sponge and warm soapy water. Rinse thoroughly and dry with a clean cloth to prevent water marks.
- **Stubborn Stains:** For burnt-on food or stubborn stains, use a specialized ceramic hob cleaner and a hob scraper (if necessary). Follow the product instructions carefully.
- **Avoid:** Abrasive cleaners, scouring pads, harsh chemicals, or steam cleaners, as these can damage the hob surface.
- **Control Panel:** Wipe the control panel gently with a damp cloth. Ensure no moisture enters the electronic components.

6. Troubleshooting

If you encounter issues with your hob, refer to the following common troubleshooting steps before contacting service.

Problem	Possible Cause	Solution
Hob does not turn on.	No power supply; main power button not pressed; child lock activated.	Check circuit breaker; press main power button firmly; deactivate child lock (refer to control panel icons).
Cooking zone not heating.	Non-compatible cookware; pan not centered; pan too small; safety cut-out activated.	Use induction-compatible cookware; center pan on zone; use appropriate size pan; turn hob off and on again.
Display shows "E" or error code.	Internal fault; overheating; voltage fluctuation.	Turn off the hob at the mains for a few minutes, then restart. If the error persists, contact customer support.
Hob makes humming/buzzing noise.	Normal operation of induction technology; cookware quality.	This is often normal. Some cookware may produce more noise than others. Ensure cookware has a flat, thick base.

7. Specifications

Brand	Rosieres
Model Number	RIES844SC (Internal: 33802037)
Type	Induction Hob

Colour	Black
Power / Wattage	7400 watts
Item Weight	15.4 kg
Package Dimensions (approx.)	89 x 64 x 15 cm

8. Warranty and Support

For warranty information, please refer to the warranty card included with your appliance or contact your retailer. Keep your proof of purchase for any warranty claims.

If you require technical assistance or have questions not covered in this manual, please contact Rosieres customer support or your authorized service center. Contact details can typically be found on the manufacturer's website or in your purchase documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07SMYBTVQ

More documents and user manuals: **https://manuals.plus/**