ALLIMITY RC5118

ALLIMITY RC5118 Remote Control User Manual

For Telefunken Televisions

1. Introduction

This manual provides instructions for the ALLIMITY RC5118 replacement remote control. This remote is designed to be compatible with a wide range of Telefunken television models, offering a direct replacement for your original remote without the need for complex programming. Please refer to the 'Specifications' section for a detailed list of compatible models.





Image 1: Front view of the ALLIMITY RC5118 Remote Control, showing all buttons and the model number.

2. Setup

The ALLIMITY RC5118 remote control is designed for immediate use with compatible Telefunken TV models. No programming or pairing is required. Simply install the batteries, and the remote will be ready to operate your television.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AAA alkaline batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

Note: Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.



Image 2: Angled view of the ALLIMITY RC5118 Remote Control, highlighting its ergonomic design.

3. Operating Instructions

The ALLIMITY RC5118 remote control features standard buttons for common television functions, as well as dedicated buttons for smart TV features.

3.1 Button Functions Overview

- **Power ( ):** Turns the television on or off.
- **Source:** Selects the input source (e.g., HDMI 1, AV, TV).
- **YouTube** / **Netflix:** Direct access buttons for these streaming services.

- **Number Pad (0-9):** For direct channel selection.
- **LANG.:** Changes audio language or subtitle options.
- **Volume Up/Down (V+/V-):** Adjusts the sound volume.
- **Channel Up/Down (P+/P-):** Changes television channels.
- **Mute ( ):** Mutes or unmutes the television sound.
- **Navigation Buttons (▲ ◄ ▼ ►):** Used to navigate menus and select options.
- **OK:** Confirms selections in menus.
- **MENU:** Opens the main television menu.
- **Q.MENU:** Opens the quick menu for common settings.
- **BACK:** Returns to the previous screen or menu.
- **EXIT:** Exits the current menu or application.
- **Color Buttons (Red, Green, Yellow, Blue):** Functionality varies depending on the TV model and current menu/application.

4. Maintenance

Proper care and maintenance will extend the life of your remote control.

4.1 Cleaning

- Wipe the remote control with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not spray liquids directly onto the remote.
- Avoid using harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's surface or internal components.

4.2 Battery Care

- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Dispose of used batteries according to local regulations.

4.3 Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

If you experience issues with your ALLIMITY RC5118 remote control, please refer to the following common solutions:

- **Remote Not Responding:**
  - **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace with fresh AAA alkaline batteries.
  - **Line of Sight:** Make sure there is a clear line of sight between the remote control and the TV's infrared sensor. Obstructions can block the signal.
  - **Distance:** Ensure you are within the effective operating range (up to 10 meters).
- **Intermittent Functionality:**
  - **Weak Batteries:** Replace batteries if they are low.
  - **Interference:** Other electronic devices or strong light sources can sometimes interfere with the infrared signal.

Try using the remote in a different environment.

- **Specific Buttons Not Working:**
  - **Clean Buttons:** Ensure buttons are not stuck or dirty. Gently clean around the buttons.
  - **TV Compatibility:** While this remote is broadly compatible, some advanced or unique functions of your specific TV model might not be supported by a universal replacement remote. Refer to your TV's original manual for specific features.

If these steps do not resolve the issue, please contact the seller or manufacturer for further assistance.

6. Specifications

Feature	Detail
Brand	ALLIMITY
Model	RC5118
Compatible Devices	Telefunken TVs including XF43D401, 32HB5150, 32HB5151, 43FB5151, 43UC7250, 49UC7250, 55UC7250, 65UC8250, 43UHD7008-1, 48WF400A, A40F446A, A55F446A, C55U320A4CW-3D, C55U320N4CW-3D, D32F286B4CW, D32F287N4CW, D32H286B3CW, D39F265B3CW, D39F275M3CW, D40F282Y4CW, D40F286B4CW, D40F287M4CW, D40U292X4C, D43F279Q3CW, D43F282Y4CW, D43F286B3CW, D43F287M3CW, D48F287M4CW, TFLU4317UHD31B, D49F279N3CW, D49F286B4CW, L43U300N4CW, D49F287N4CW, D49U297N4CW, D49U400U4CW, D55F287B3CW, D55F287B4CW, D55F287M4CW, D55F287N3CW, D55F287Y4CW, D55F289N4CW, D55U297N4CW, D55U400Y4CW, DOMUS40DVISMW, L32F249U4CW, L40F283A4CW, L40U300A4CW, L48U300A4CW-3D, L48U300N4CW, L48U300Q4CW, L48U500M4CWI, L55F249N3CW, L55U300N4CW, L55U300N4CWI, L55U300Q4CW, L65F249A3CW, D32H286B4CW, L65F249N3CW, L65U249A4CW-3D, L65U249N4CW, L65U249Q4CW, L65U253B4CW, LF43FZ20, LF43WZ20, LU49FZ30, TFK32BC16, TFL24DVSAT12V16B, TFL494303UHD17, TFL554303UHD17, TFL65FHD250BC/2, TFLE55FHDC6300B/2, TFLES65302FHDWF400B, TFLUC5516UHD300B, TFS49UHD17B, WF43-EA40, WF43-EA41, WF48-EA40, WF48-EA41, XF43B400, XF48B400, XF50A401, XF55A400, XF55B400, XH32A100D, XH32A201D, XH32A201D-W, XH32A301, XH32A301-W, XU40A401, XU49A401, XU49B401, XU55A441C, XU65A441.
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Maximum Range	10 Meters
Item Weight	0.11 Kilograms (110 g)
Product Dimensions	4 x 0.9 x 19 cm
Batteries	2 x AAA Alkaline (not included)
Manufacturer	changchunshi jutongwangluokeji youxiangongsi

7. Warranty and Support

For information regarding warranty coverage, please refer to the purchase documentation or contact the retailer from whom you purchased the ALLIMITY RC5118 remote control. For technical support or further inquiries, please reach out to the ALLIMITY customer service or the seller directly.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question