AEG AXP34U338CW

AEG AXP34U338CW Portable Air Conditioner User Manual

Model: AXP34U338CW | Brand: AEG

1. Introduction

Thank you for choosing the AEG AXP34U338CW Portable Air Conditioner. This manual provides essential information for the safe operation, installation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before using the product and keep it for future reference.

This portable air conditioner is designed to provide efficient cooling for your indoor spaces, featuring a powerful 3400W cooling capacity and convenient remote control operation.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Ensure the power supply matches the voltage specified on the appliance's rating label (230 Volts).
- Do not operate the air conditioner with a damaged cord or plug.
- Keep the air intake and exhaust vents clear of obstructions.
- Do not insert fingers or foreign objects into the air vents.
- This appliance is for indoor use only. Do not use it in bathrooms or other excessively humid environments.
- Always unplug the unit before cleaning or performing any maintenance.
- Do not attempt to repair or modify the unit yourself. Contact qualified service personnel for repairs.
- The appliance contains R290 refrigerant. Handle with care and ensure proper ventilation during installation and maintenance.

3. Package Contents

Verify that all items are present and in good condition upon unpacking.

- AEG AXP34U338CW Portable Air Conditioner Unit
- Exhaust Hose
- Window Sealing Kit

- Remote Control
- User Manual

4. Product Overview



Figure 4.1: Front view of the AEG AXP34U338CW Portable Air Conditioner, showcasing its sleek white design and top control panel.



Figure 4.2: Rear view of the unit, highlighting the exhaust hose connection port and air vents.



Figure 4.3: The portable air conditioner positioned in a living room, demonstrating its compact footprint.



Figure 4.4: The unit in an indoor setting, showing the R290 gas label, indicating the type of refrigerant used.

5. Setup and Installation

Follow these steps to set up your portable air conditioner for optimal performance.

1. **Unpack the Unit:** Carefully remove the air conditioner and all accessories from the packaging. Retain the packaging for future storage or transport.
2. **Position the Unit:** Place the air conditioner on a flat, stable surface near a window and a grounded electrical outlet. Ensure there is at least 20 inches (50 cm) of space around the unit for proper airflow.
3. **Install the Exhaust Hose:**
    - Screw one end of the exhaust hose onto the exhaust port on the back of the air conditioner.
    - Extend the hose and connect the other end to the window sealing kit.
4. **Install the Window Sealing Kit:**
    - Open the window and place the window sealing kit into the window opening. Adjust it to fit snugly.
    - Ensure the window is closed as much as possible around the kit to prevent warm air from entering the room.

5. **Connect Power:** Plug the power cord into a grounded 230 Volt electrical outlet.

6. Operating Instructions

6.1 Control Panel and Remote Control

The unit can be operated using the control panel on top of the unit or the provided remote control. The remote control offers full functionality for convenience.

6.2 Operating Modes

- **Cool Mode:** Select this mode for cooling. Adjust the desired temperature using the temperature up/down buttons. The unit will cool the room to the set temperature.
- **Fan Mode:** Circulates air without cooling. Useful for ventilation. Fan speed can be adjusted.
- **Dry (Dehumidify) Mode:** Reduces humidity in the room. The fan speed is typically fixed in this mode.
- **Sleep Mode:** Operates at a quieter fan speed and gradually increases the set temperature over time for comfortable sleep.

6.3 Fan Speed Adjustment

Press the Fan Speed button to cycle through available fan speeds (Low, Medium, High). Higher fan speeds provide faster cooling but may result in increased noise (up to 64 dB).

6.4 Timer Function

Use the Timer button to set a delay for the unit to turn on or off. This feature helps save energy and allows for pre-cooling or scheduled shutdown.

7. Maintenance

Regular maintenance ensures the longevity and efficient operation of your air conditioner.

- **Air Filter Cleaning:** The air filter should be cleaned every two weeks or more frequently depending on usage.
    a. Unplug the unit.
    b. Remove the air filter from the back of the unit.
    c. Wash the filter with warm, soapy water. Rinse thoroughly and allow it to air dry completely before reinserting.
- **Draining Water:** The unit has a self-evaporative system, but in high humidity conditions, water may accumulate.
    - Place a shallow pan under the drain port at the bottom rear of the unit.
    - Remove the drain plug to allow water to flow out.
    - Replace the drain plug once all water has been drained.
- **Exterior Cleaning:** Wipe the exterior of the unit with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** If storing the unit for an extended period, drain all water, clean the filter, and cover the unit to protect it from dust. Store in a dry, cool place.

8. Troubleshooting

Refer to the table below for common issues and their solutions. If the problem persists, contact customer support.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Unit does not turn on	No power; Power cord unplugged; Circuit breaker tripped; Full water tank.	Ensure unit is plugged in; Check circuit breaker; Empty water tank if full indicator is on.
Unit does not cool effectively	Air filter clogged; Exhaust hose not properly installed; Room too large; Doors/windows open.	Clean air filter; Ensure exhaust hose is properly connected and sealed; Close all doors and windows; Check if unit capacity matches room size.
Loud noise during operation	Unit not on a level surface; Obstruction in fan; Normal operating noise.	Place unit on a flat surface; Check for obstructions; Note that noise level can be up to 64 dB.
Water leakage	Drain plug loose or missing; Unit tilted; Drain pan full.	Ensure drain plug is secure; Place unit on a level surface; Drain water from the unit.

9. Specifications

Feature	Specification
Brand	AEG
Model Number	AXP34U338CW (7332543587728)
Cooling Power	3400 Watts
Noise Level	64 dB
Voltage	230 Volts
Item Weight	2.2 pounds
Product Dimensions (D x W x H)	15.35 x 18.9 x 27.95 inches
Capacity	1 Liters (internal water tank)
Installation Type	Portable
Special Features	Remote control
Color	White
Power Source	AC adapter

10. Warranty and Support

For warranty information, please refer to the warranty card included with your product or contact AEG customer service. Keep your purchase receipt as proof of purchase.

If you encounter any issues not covered in the troubleshooting section or require technical assistance, please contact AEG customer support through their official website or the contact information provided in your product documentation.

For more information, visit the official AEG website:www.aeg.com

© 2024 AEG. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question