Whirlpool MWP254W

Whirlpool MWP 254 W 25-Liter Microwave Oven User Manual

Model: MWP254W

1. Introduction

Thank you for choosing the Whirlpool MWP 254 W Microwave Oven. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your appliance. Please read these instructions carefully before using the microwave oven and retain them for future reference.

2. Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, injury to persons, or exposure to excessive microwave energy.

- Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy.
- Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.
- The oven should not be adjusted or repaired by anyone except properly qualified service personnel.
- Ensure the appliance is properly grounded.
- Do not heat liquids or other foods in sealed containers since they are liable to explode.
- Only use utensils that are suitable for use in microwave ovens.

3. Product Overview

The Whirlpool MWP 254 W is a 25-liter countertop microwave oven featuring electronic controls, a grill function, and a rotating turntable. It is designed for domestic use, offering various cooking modes including microwave, grill, and combined cooking.



Figure 3.1: Front view of the Whirlpool MWP 254 W Microwave Oven.



Figure 3.2: The microwave oven with its door closed, showcasing the control panel and display.



Figure 3.3: An angled perspective of the microwave oven, highlighting its compact design.



Figure 3.4: Interior view of the microwave oven, showing the glass turntable and a dish inside.

4. Setup and Installation

4.1 Unpacking

- Remove all packaging materials from the oven cavity and accessories.
- Check the oven for any damage, such as dents or a misaligned door. Do not install if damaged.

4.2 Placement

- Place the microwave oven on a flat, stable surface strong enough to hold its weight and the heaviest food likely to be cooked in it.
- Ensure adequate ventilation: leave a minimum of 20 cm (8 inches) of space above the oven, 10 cm (4 inches) at the rear, and 5 cm (2 inches) on each side.
- Do not block air vents.
- Keep the oven away from heat sources and strong magnetic fields.

4.3 Electrical Connection

- Plug the power cord into a properly installed and grounded wall outlet. The voltage must match the rating label on the oven.
- Do not use extension cords or adapters.

5. Operating Instructions

5.1 Control Panel Overview

The microwave oven features an electronic control panel with a digital display and various function buttons. Refer to the labels on the control panel for specific functions.

5.2 Setting the Clock

- When the oven is first plugged in, the display will show '0:00'.
- Press the 'Clock' button (if available, or refer to specific model instructions for clock setting).
- Use the '+' and '-' buttons to set the hour and minute.
- Press 'Clock' again to confirm.

5.3 Microwave Cooking

1. Place food in a microwave-safe container on the turntable.
2. Close the door.
3. Press the 'Microwave' button.
4. Use the '+' and '-' buttons to select the desired cooking time.
5. Press 'Jet Start' or 'Start' to begin cooking.

5.4 Grill Cooking

The grill function is ideal for browning and crisping food.

1. Place food on the grill rack (if provided) or a heat-resistant dish.
2. Close the door.
3. Press the 'Grill' button.
4. Use the '+' and '-' buttons to set the grilling time.
5. Press 'Jet Start' or 'Start' to begin.

5.5 Combi Grill (Microwave + Grill)

This mode combines microwave power with the grill for faster cooking and browning.

1. Place food in a suitable container.
2. Close the door.
3. Press the 'Combi Grill' button (or equivalent).
4. Select the desired cooking time and power level combination using the '+' and '-' buttons.
5. Press 'Jet Start' or 'Start' to begin.

5.6 Defrost Function

The defrost function allows for quick and efficient thawing of frozen foods.

1. Place frozen food on the turntable.
2. Close the door.
3. Press the 'Defrost' button.
4. Select the food type or weight using the '+' and '-' buttons.
5. Press 'Jet Start' or 'Start' to begin. The oven may prompt you to turn the food over during the cycle.

5.7 Special Functions (Soft/Melt, Keep Warm, Dough Rising, Steam/Boil, Auto Cook, Auto Clean)

Your microwave oven includes several pre-programmed functions for convenience. Refer to the specific icons on the control panel for these features:

- **Soft/Melt:** For gently softening or melting ingredients like butter or chocolate.
- **Keep Warm:** Maintains food at a warm temperature after cooking.

- **Dough Rising:** Provides an optimal environment for dough to rise.
- **Steam/Boil:** For steaming vegetables or boiling water (requires appropriate accessories).
- **Auto Cook:** Pre-set programs for various food types. Select the program and weight, then start.
- **Auto Clean:** A function to assist in cleaning the oven interior (refer to Maintenance section).

To use these functions, press the corresponding button and follow the on-screen prompts or instructions in the full manual for specific settings.

6. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your microwave oven.

6.1 General Cleaning

- Always unplug the oven before cleaning.
- Clean the oven cavity after every use with a damp cloth and mild detergent. Avoid abrasive cleaners.
- The outer surfaces should be cleaned with a damp cloth. Do not allow water to enter the ventilation openings.
- The door and door seals should be kept clean. Use a soft cloth and mild detergent.
- The glass turntable can be washed in warm soapy water or in a dishwasher.

6.2 Auto Clean Function

If your model features an 'Auto Clean' function, follow these steps:

1. Place a microwave-safe bowl with water and a few drops of lemon juice inside the oven.
2. Press the 'Auto Clean' button (or refer to specific instructions for activating this mode).
3. The steam generated will help loosen food particles. After the cycle, carefully remove the bowl and wipe the interior with a soft cloth.

7. Troubleshooting

If you encounter issues with your microwave oven, consult the following table before contacting service.

Problem	Possible Cause	Solution
Oven does not start	Power cord not plugged in; Door not closed properly; Fuse blown or circuit breaker tripped.	Plug in power cord; Close door securely; Check fuse or reset circuit breaker.
Food not heating	Door not closed properly; Cooking time/power level not set correctly; Food not suitable for microwave.	Ensure door is closed; Adjust time/power; Use microwave-safe dishes.
Turntable not rotating	Turntable not placed correctly; Obstruction under turntable.	Ensure turntable is seated properly on its support; Remove any obstructions.
Unusual noise during operation	Food container touching oven walls; Turntable not correctly positioned.	Adjust food container; Reposition turntable.

8. Specifications

Feature	Specification
Model Number	MWP254W
Capacity	25 Liters
Microwave Power Output	900 W
Grill Power Output	1000 W (Quartz Grill)
Controls	Electronic / Touch
Turntable Diameter	270 mm
Installation Type	Countertop
Color	White
Material	Glass, Metal
Appliance Width	483 mm
Appliance Depth	419 mm
Appliance Height	281 mm
Net Weight	14.5 kg
Power Connection	1400 W
Cable Length	100 cm
Voltage	230 Volts
Special Features	Interior Light, Timer, Automatic Defrost

9. Warranty and Support

For information regarding your product's warranty, please refer to the warranty card included with your purchase or visit the official Whirlpool website. For technical support, spare parts, or service inquiries, please contact Whirlpool customer service in your region. Ensure you have your model number (MWP254W) and serial number ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question