Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iJoy 842700107661

iJoy Activity Tracker User Manual

Model: 842700107661

Introduction

Thank you for purchasing the iJoy Activity Tracker. This device is designed to help you monitor your daily physical activity, including steps taken, distance covered, and calories burned. Please read this manual carefully before using the device to ensure proper operation and to maximize its benefits.

Safety Information

- Do not attempt to disassemble or modify the device. This may cause damage and void the warranty.
- Keep the device away from extreme temperatures, direct sunlight, and moisture.
- Avoid dropping the device or subjecting it to strong impacts.
- Dispose of batteries according to local regulations. Do not dispose of batteries in fire.
- If you experience any discomfort or skin irritation while wearing the tracker, discontinue use and consult a medical professional.

Product Overview

The iJoy Activity Tracker is a compact, wearable device designed for ease of use. It features a clear digital display and two control buttons.



Figure 1: Front view of the iJoy Activity Tracker. The display shows time and activity data. The two buttons are for mode selection and setting adjustments.

Components:

- **Digital Display:** Shows the current time, steps, distance, and calories.
- **MODE Button:** Used to cycle through different display modes (Time, Steps, Distance, Calories).
- **SET Button:** Used to enter setting mode and confirm selections.

- **Wrist Strap:** Adjustable strap for comfortable wear.

Setup

1. Battery Installation:

The iJoy Activity Tracker uses an Alkaline battery. To install or replace the battery:

1. Carefully open the battery compartment cover on the back of the device.
2. Insert the Alkaline battery, ensuring correct polarity (+/-).
3. Close the battery compartment cover securely.

Note: Changing the battery may reset some settings. It is recommended to perform unit changes (metric/imperial) after a battery change.

2. Initial Setup (Time, Date, Units):

After battery installation, the device will typically be in setup mode or you can enter it by pressing and holding the **SET** button.

1. **Set Time:** When the time display flashes, use the **MODE** button to adjust the hour, then press **SET** to confirm and move to minutes. Repeat for minutes.
2. **Set Date:** Follow similar steps to set the year, month, and day.
3. **Set Units (Metric/Imperial):** After setting the date, the unit setting will appear. Press **MODE** to toggle between Metric (km, kg) and Imperial (miles, lbs). Press **SET** to confirm your selection.
4. **Set Personal Information:** The device may prompt for personal information such as stride length, weight, and height for more accurate calorie and distance calculations. Use **MODE** to adjust values and **SET** to confirm.
5. Once all settings are confirmed, the device will return to normal operation mode.

Operating Instructions

Viewing Data:

Press the **MODE** button repeatedly to cycle through the following display screens:

- **Time Display:** Shows the current time.
- **Step Count:** Displays the total number of steps taken for the day.
- **Distance:** Shows the total distance covered (in km or miles, depending on your unit setting).
- **Calories Burned:** Estimates the calories burned based on your activity and personal settings.

*Note: Pressing the **MODE** or **SET** button will briefly activate a green backlight for improved visibility in low light conditions.*

Resetting Daily Data:

To reset your daily step, distance, and calorie data to zero, typically this happens automatically at midnight. If you need to manually reset for a new activity session:

- Navigate to the Step Count, Distance, or Calories display.
- Press and hold the **SET** button for a few seconds until the display resets to zero.

Maintenance

Cleaning:

Wipe the device regularly with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or internal components.

Battery Replacement:

When the display becomes dim or the device stops responding, it's time to replace the Alkaline battery. Follow the "Battery Installation" steps in the Setup section. It is advised not to touch the batteries yourself if you are uncomfortable, and to seek professional assistance if needed.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on / Display is blank.	Battery is dead or incorrectly installed.	Replace the battery, ensuring correct polarity.
Display is dim or hard to read.	Low battery. Not backlit (only has a temporary light).	Replace the battery. Use the temporary backlight by pressing MODE or SET in low light.
Inaccurate step count.	Improper wearing position; device movement not corresponding to steps.	Ensure the tracker is worn securely on the wrist. Avoid excessive wrist movements that are not actual steps.
Cannot change units (Metric/Imperial).	Unit change option only available during initial setup or after battery replacement.	Perform a battery replacement to access the unit setting option during the initial setup process.
Buttons are unresponsive.	Device frozen; low battery.	Try replacing the battery. If issue persists, contact customer support.

Specifications

Brand	iJoy
Model Number	842700107661
Screen Size	0.96 Inches (Visible screen diagonal: 1" / 3 cm)
Sensor Type	Wearable
Battery Type	Alkaline
Item Weight	2.39 ounces
Package Dimensions	4.9 x 4.3 x 1.2 inches
Compatible Devices	Smartphones (Note: This device operates independently and does not require smartphone connection for basic functions.)

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official iJoy website. Keep your purchase receipt as proof of purchase.
You can also visit the iJoy Store on Amazon for more information: iJoy Store

© 2023 iJoy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07SZKBB1M

More documents and user manuals: **https://manuals.plus/**