Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beyution AH59-02533A

Beyution AH59-02533A Remote Control User Manual

For Samsung Blu-Ray & Home Theater Systems

1. Introduction

This manual provides essential instructions for the Beyution AH59-02533A replacement remote control. It is designed to operate various Samsung Blu-Ray players and Home Theater Systems. This remote functions as an infrared replacement and does not require programming; simply insert batteries to begin use.

2. Product Overview

The AH59-02533A remote control is a direct replacement for original Samsung remotes, offering full functionality for compatible devices. Its ergonomic design ensures comfortable handling.

Compatible Models:

This remote is compatible with the following Samsung Blu-Ray and Home Theater System models:

- HT-F4500, HT-F4500/ZA
- HT-FM45, HT-FM45/ZA
- HT-H4500, HT-H4500/ZA
- HT-H4530, HT-H5200
- HT-H5500W, HT-H5500W/ZA, HT-H5500WZA
- HT-H5530, HT-HM55, HT-HM55/ZA
- HT-J41/ZA, HT-J4100, HT-J4100/ZA
- HT-J4500, HT-J4500/ZA
- HT-J5500, HT-J5500/2A
- HT-J5500W, HT-J5500W/ZA
- HT-J5550W, HT-JM41

VOLUME
MUTE
1
2
3
4
5
6
7
8
9
DISC MENU
TITLE MENU
0
POPUP
SUBTITLE
HOME
REPEAT
TOOLS
INFO
RETURN
EXIT
TUNER MEMORY
MO/ST
A
B
C
D
TV SOUND
DSP/EQ
TUNING
DOWN
UP
AH59-02533A

Image 1: Front view of the Beyution AH59-02533A remote control, showing all buttons and their labels.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two (2) AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.

Important: Use new alkaline batteries for optimal performance. Rechargeable batteries may not provide sufficient power for consistent operation.

Image 2: Rear view of the remote control with the battery compartment open, showing where to insert two AAA batteries.

4. Operating Instructions

Once batteries are installed, the remote is ready for use. Point the remote directly at your Samsung Blu-Ray or Home Theater System.

4.1 Basic Functions

- **Power (Red Button):** Turns the device on or off.
- **Volume (+/-):** Adjusts the audio volume.
- **Mute:** Silences the audio.
- **Number Pad (0-9):** For direct track selection or input.
- **Disc Menu** / **Title Menu** / **Popup:** Accesses various disc or title menus.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Previous, Next):** Standard media playback functions.
- **Home:** Returns to the main home screen or menu.
- **Subtitle:** Toggles subtitle options.
- **Repeat:** Repeats current track or section.

4.2 Navigation and System Controls

- **Directional Pad (Up, Down, Left, Right) & Enter:** Navigates through menus and confirms selections.
- **Tools:** Accesses additional settings or options.
- **Info:** Displays information about the current content or system status.
- **Return:** Goes back to the previous screen or menu.
- **Exit:** Closes the current menu or application.
- **Colored Buttons (A, B, C, D):** Functionality varies depending on the specific application or menu.
- **TV Sound DSP/EQ:** Adjusts sound processing or equalizer settings.
- **Tuner Memory MO/ST:** For radio tuner functions.

- **Tuning (Down, Up):** Adjusts radio frequency.

5. Maintenance

5.1 Battery Replacement

Replace batteries when the remote's response becomes inconsistent or stops working. Always replace both AAA batteries simultaneously with new alkaline batteries.

5.2 Cleaning

To clean the remote, gently wipe its surface with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as these can damage the remote's finish or internal components.

6. Troubleshooting

6.1 Remote Not Responding

- **Check Batteries:** Ensure new alkaline batteries are correctly installed with proper polarity. Replace old or weak batteries.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the infrared sensor on your Samsung device.
- **Remote Sensor:** Confirm the remote's infrared emitter (at the front tip) is clean and unobstructed.
- **Device Sensor:** Ensure the infrared receiver on your Samsung Blu-Ray or Home Theater System is clean and not blocked.

6.2 Incompatible Device

If your device model number is not listed in the 'Compatible Models' section (Section 2), this remote may not be fully compatible. Please verify your device's model number against the provided list.

7. Specifications

Model Number	AH59-02533A (BE-AH59-02533A-CAD)
Brand	Beyution
Connectivity Technology	Infrared
Compatible Devices	Samsung Blu-Ray & Home Theater Systems
Power Source	2 x AAA Batteries (Alkaline recommended)
Product Dimensions	7 x 2 x 0.65 inches (approx.)
Item Weight	2.08 ounces (approx.)

8. Support

If you encounter issues not covered in this manual or require further assistance, please refer to the support information provided by your retailer or the manufacturer of the Beyution remote control. For specific device compatibility questions, it is recommended to consult the original documentation for your Samsung Blu-Ray or Home Theater System.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07T13VJT4

More documents and user manuals: **https://manuals.plus/**