Ricoh 408310

Ricoh 408310 Black Print Cartridge User Manual

Model: 408310 | Brand: Ricoh

Introduction

This manual provides comprehensive instructions for the proper use and maintenance of your Ricoh 408310 Black Print Cartridge. Designed for the Ricoh P C600 printer, this genuine Ricoh cartridge ensures high-quality output and reliable performance. Please read this manual carefully before installation and use to ensure optimal results and to protect your investment.

Product Overview

The Ricoh 408310 is a genuine black laser print toner cartridge engineered to work seamlessly with Ricoh P C600 printers. It is designed to deliver consistent, sharp black prints and has an approximate yield of 18,000 pages, making it suitable for high-volume printing environments.



An image showing the Ricoh 408310 Black Print Cartridge alongside a separate waste toner bottle. The cartridge is black and rectangular with a green lever, and the waste toner bottle is also black with a white cap and warning labels.

Setup and Installation

Follow these steps to install the Ricoh 408310 Black Print Cartridge into your Ricoh P C600 printer:

1. **Preparation:** Ensure your printer is powered off before beginning the installation process.
2. **Open the Front Cover:** Locate and open the front cover of your Ricoh P C600 printer to access the toner cartridge compartment.
3. **Remove the Old Cartridge:** If replacing an existing cartridge, carefully grasp the old toner cartridge and pull it straight out of the printer. Place it in a sealed bag for proper disposal according to local regulations.
4. **Unpack the New Cartridge:** Remove the new Ricoh 408310 Black Print Cartridge from its packaging. Avoid touching the green drum or electrical contacts.
5. **Shake the Cartridge:** Gently shake the new cartridge horizontally 5-6 times to distribute the toner evenly inside.
6. **Insert the New Cartridge:** Align the new cartridge with the guides inside the printer and push it firmly until it clicks into place. Ensure it is securely seated.
7. **Close the Front Cover:** Close the front cover of the printer.
8. **Power On:** Turn on your printer. The printer will typically perform a self-check and recognize the new cartridge.

Note: *Always use genuine Ricoh toner cartridges to ensure optimal print quality and to prevent damage to your printer.*

Operating Considerations

Once installed, the Ricoh 408310 Black Print Cartridge operates automatically as part of your Ricoh P C600 printer's printing process. The cartridge is designed for a yield of approximately 18,000 pages, which may vary based on print coverage and environmental conditions. The printer's display will typically indicate when the toner level is low or when the cartridge needs replacement.

Maintenance and Storage

- **Storage:** Store new toner cartridges in their original, unopened packaging in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle cartridges carefully to avoid dropping them or exposing them to excessive vibration,

which could damage internal components or cause toner leakage.

- **Disposal:** Dispose of used toner cartridges responsibly. Many manufacturers and retailers offer recycling programs. Do not incinerate toner cartridges.
- **Printer Cleaning:** Periodically clean the interior of your printer according to your printer's user manual to prevent toner buildup and maintain print quality.

Troubleshooting

If you encounter issues related to your toner cartridge, consider the following:

- **Low Toner Warning:** If the printer displays a low toner warning, prepare a new cartridge for replacement. You may be able to continue printing for a short period, but print quality may degrade.
- **Print Quality Issues (Fading, Streaks):**
  - Ensure the cartridge is properly seated. Remove and reinsert it.
  - Gently shake the cartridge to redistribute any remaining toner.
  - If the issue persists and the cartridge is nearing its estimated yield, replace it with a new one.
  - Check your printer's settings for print density or toner saving modes.
- **Cartridge Not Recognized:**
  - Ensure the cartridge is fully inserted and clicked into place.
  - Power cycle the printer (turn off, wait 30 seconds, turn on).
  - Verify that you are using a genuine Ricoh cartridge compatible with your printer model (Ricoh P C600).

For more complex issues, refer to your Ricoh P C600 printer's comprehensive user manual or contact Ricoh customer support.

Specifications

Feature	Detail
Model Number	408310
Brand	Ricoh
Color	Black
Page Yield	Approx. 18,000 pages
Compatible Devices	Ricoh P C600 Printer
Item Weight	1.7 pounds

Product Dimensions	12.8 x 5 x 5.9 inches
UPC	026649083105

Warranty and Support

Genuine Ricoh products are designed for reliability and performance. While specific warranty details for consumables like toner cartridges are typically covered under the printer's warranty or Ricoh's general terms, using genuine Ricoh parts helps maintain your printer's warranty and ensures optimal operation.
For technical support, warranty claims, or further assistance, please visit the official Ricoh support website or contact their customer service. Always refer to your Ricoh P C600 printer's manual for printer-specific troubleshooting and maintenance.
No official product videos from the seller were available for embedding based on the provided data.

© 2024 Ricoh. All rights reserved.