Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iPega PG-9157

IPEGA PG-9157 GamePad WiFi Controller User Manual

Comprehensive guide for setup, operation, and maintenance.

1. Introduction

Thank you for choosing the iPega PG-9157 GamePad WiFi Controller. This device is designed to enhance your gaming experience across various platforms, including Android, iOS, Smart TV, and PC. It features Bluetooth 4.0 connectivity for direct play without complex setup procedures. Please read this manual carefully to ensure proper use and maximize the performance of your controller.

2. Product Overview

2.1 Key Features

- **Bluetooth 4.0 Connectivity:** Supports direct connection and play on iOS and Android devices.
- **Wide Compatibility:** Compatible with Android 6.0 and above, iOS 11.0 and above (not compatible with iOS 13.4 and some MediaTek chipsets), Smart TVs, set-top boxes, and PCs.
- **Customizable Buttons:** Download the exclusive APP for personalized button settings.
- **Integrated Phone Holder:** Features an exclusive telescopic mobile phone bracket, extending up to 95mm, suitable for 4.5-5 inch phones.
- **Long Battery Life:** Built-in high-performance lithium battery provides over 15 hours of continuous use and up to 30 days standby time on a full charge.
- **Ergonomic Design:** Comfortable to handle for extended gaming sessions.

2.2 Package Contents

The iPega PG-9157 GamePad package includes:

- 1 x iPega PG-9157 Bluetooth Gamepad
- 1 x USB Cable (for charging)
- 1 x User Manual

2.3 Product Diagram



Figure 1: Front view of the iPega PG-9157 GamePad, showing the D-pad, action buttons (A, B, X, Y), dual analog sticks, Select, Start, and iPega logo button.



Figure 2: Angled view of the iPega PG-9157 GamePad, highlighting the ergonomic grip and trigger buttons.



Figure 3: Side view of the iPega PG-9157 GamePad, showing the shoulder buttons and the overall profile.



Figure 4: Packaging of the iPega PG-9157 GamePad, illustrating the product and its features on the box.

3. Setup and Connection

3.1 Charging the Controller

Before first use, fully charge the controller. Connect the supplied USB cable to the charging port on the controller and the other end to a USB power source (e.g., computer, USB wall adapter). The charging indicator light will show the charging status and turn off when fully charged.

3.2 Bluetooth Pairing

The PG-9157 supports direct play mode for iOS and Android devices. The pairing method may vary slightly depending on your device's operating system.

1. **Power On:** Press and hold the power button (iPega logo button) for a few seconds until the indicator light starts flashing, indicating it's in pairing mode.
2. **Activate Bluetooth:** On your mobile device (Android/iOS), go to your Bluetooth settings and turn on Bluetooth.
3. **Search for Devices:** Your device will scan for available Bluetooth devices. Look for "PG-9157" or a similar name in the list.
4. **Connect:** Select "PG-9157" to pair. Once successfully paired, the indicator light on the controller will become solid.

Note: For subsequent uses, the controller should automatically reconnect to the last paired device when powered on and Bluetooth is active on the device.

3.3 Device Compatibility

- **Android:** Supports Android 6.0 and higher.
- **iOS:** Supports iOS 11.0 and higher. *Not compatible with iOS 13.4 and above.*
- **PC:** Compatible with Windows operating systems via wireless connection.
- **Smart TV/Set-top Box:** Supports wireless connection to compatible Smart TVs and set-top boxes.
- **Important Limitation:** Phones with MediaTek chipsets are generally *not supported*. Please verify your device's chipset before use.

4. Operating Instructions

4.1 Attaching Your Phone

The controller features a telescopic phone holder. Gently pull the top part of the holder upwards to extend it. Carefully place your smartphone into the holder, ensuring it is securely gripped. The holder can extend up to 95mm, accommodating most 4.5-5 inch smartphones.

4.2 Gaming Modes

The PG-9157 is designed for direct play, meaning it should work with many games that support external controllers without additional configuration. This is particularly optimized for popular mobile games like PUBG and Wang Rongyao.

4.3 Custom Button Mapping (APP)

For advanced users or specific game requirements, you can download the exclusive iPega APP to customize button mappings. Refer to the APP's instructions for detailed guidance on creating personalized control schemes. This feature allows you to tailor the controller's response to your preferred gaming style.

Note: Ensure the APP is compatible with your device's operating system. Some apps may not be compatible with all Smart TV or PC setups.

5. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the controller. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the controller regularly, even if not in use for extended periods.
- **Avoid Drops:** Protect the controller from drops and impacts, which can damage internal components.

6. Troubleshooting

6.1 Controller Not Pairing/Connecting

- **Check Battery:** Ensure the controller is sufficiently charged.
- **Bluetooth On:** Verify that Bluetooth is enabled on your device.
- **Restart Devices:** Try restarting both the controller and your mobile device/PC.
- **Forget Device:** If previously paired, try "forgetting" or "unpairing" the controller from your device's Bluetooth settings and then re-attempt the pairing process.
- **Compatibility:** Confirm your device's operating system version (Android 6.0+, iOS 11.0-13.3) and ensure it does not have a MediaTek chipset.
- **Interference:** Move away from other wireless devices that might cause interference.

6.2 Buttons Not Responding Correctly

- **Game Support:** Ensure the game you are playing supports external controllers.
- **Re-pair:** Disconnect and re-pair the controller.
- **Custom Mapping:** If using a custom button mapping app, ensure it is configured correctly and is compatible with the game.
- **Firmware:** Check the iPega website or app for any available firmware updates for the controller.

6.3 Controller Disconnects Frequently

- **Battery Level:** Low battery can cause unstable connections. Charge the controller fully.
- **Distance:** Ensure the controller is within the effective range of your Bluetooth device.
- **Interference:** Minimize interference from other wireless devices.

7. Specifications

Parameter	Detail
Brand	iPega
Model Number	PG-9157
Connectivity	Wireless Bluetooth V4.0
Compatible Systems	Android (6.0+), iOS (11.0-13.3), Windows, Smart TV
Material	ABS
Battery Type	Built-in Lithium-ion
Battery Capacity	380 mAh

Charging Mode	USB Charging
Charging Time	Approximately 2 hours
Continuous Use Time	Over 15 hours
Standby Time	Up to 30 days
Product Dimensions	17.7 x 16.1 x 6.7 cm
Product Weight	276 grams
Phone Holder Extension	Max 95 mm

8. Warranty and Support

For information regarding warranty and return policies, please refer to the retailer's specific terms and conditions at the point of purchase. Generally, if you wish to return a product within 30 days of receipt because you have changed your mind, consult the retailer's help page on returns. If you have received a defective or damaged product, consult the retailer's help page on defective items. For specific information on purchases made on marketplaces, consult the relevant marketplace's help page.

For technical support or further assistance, please contact iPega customer service or refer to their official website for updated information and resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07T69HF9T

More documents and user manuals: **https://manuals.plus/**