**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Bergner Q3066**

# Bergner Click & Cook Frying Pans User Manual

Model: Q3066 | Brand: Bergner

## Introduction

This user manual provides comprehensive instructions for the Bergner Click & Cook Set of 2 Pressed Aluminium Frying Pans (24 cm and 28 cm). These pans are designed for versatility and ease of use, featuring a removable ergonomic handle and compatibility with various cooktops, including induction. Please read this manual thoroughly before first use to ensure proper operation, care, and longevity of your product.

## Product Overview

### Components

- 1 x 24 cm Pressed Aluminium Frying Pan
- 1 x 28 cm Pressed Aluminium Frying Pan
- 1 x Removable Ergonomic Handle

### Key Features

- **Pressed Aluminium Construction:** Lightweight, durable, and ensures optimal heat distribution.
- **Non-Stick Coating:** Designed to prevent food from sticking, making cooking and cleaning easier.
- **Stackable Design:** Pans can be stacked for compact storage, saving kitchen space.
- **Removable Ergonomic Handle:** Provides a comfortable grip and allows for oven use by detaching the handle.
- **Multi-Cooktop Compatibility:** Suitable for induction, ceramic, gas, halogen, and electric cookers.
- **Oven Safe:** Pans can be used in the oven once the handle is removed.



Image: The Bergner Click & Cook set, showing both the 24 cm and 28 cm frying pans along with the detachable ergonomic handle. The pans feature a speckled non-stick interior and a black exterior.

## Setup

### Before First Use

1. Remove all packaging materials and labels from the pans and handle.
2. Wash the pans and handle thoroughly with warm, soapy water.
3. Rinse well and dry completely with a soft cloth.
4. For optimal non-stick performance, lightly season the interior of the pans by rubbing a small amount of cooking oil over the surface with a paper towel. Heat on low for 30 seconds, then let cool and wipe clean.

### Attaching the Handle

Align the handle's attachment mechanism with the designated slot on the pan's rim. Press the release button on the

handle and slide it firmly onto the pan until it clicks securely into place. Ensure the handle is fully engaged and stable before lifting or cooking.




Image: A hand demonstrating the attachment of the ergonomic handle to the frying pan. The handle features a click mechanism for secure locking onto the pan's edge.

### Detaching the Handle

To detach the handle, ensure the pan is cool. Press the release button on the handle and slide it away from the pan. The handle should disengage smoothly. This feature allows for easy storage and oven use.

## Operating Instructions

### Cooking on Stovetops

- These pans are compatible with induction, ceramic, gas, halogen, and electric cooktops.
- Always use a burner size that matches the base of the pan to ensure even heating and energy efficiency.

- Use low to medium heat settings for most cooking tasks. High heat can damage the non-stick coating over time and is generally not necessary due to the pan's excellent heat distribution.
- Avoid preheating empty pans on high heat for extended periods.
- Use wooden, silicone, or plastic utensils to protect the non-stick surface. Metal utensils can scratch and damage the coating.




Image: The underside of a Bergner Click & Cook frying pan, highlighting its induction-compatible base. This demonstrates its suitability for various heat sources.




Image: A perfectly fried egg resting in the non-stick frying pan, illustrating the pan's non-stick properties and ease of food release.

### Oven Use

- The pans are oven safe only when the removable handle is detached.
- Ensure the handle is completely removed before placing the pan in the oven.
- Always use oven mitts when handling hot pans from the oven.

## Care and Maintenance

### Cleaning

- Allow pans to cool completely before washing. Sudden temperature changes can cause warping.
- Hand washing with warm, soapy water and a soft sponge is recommended to prolong the life of the non-stick coating.
- While the pans are dishwasher safe, frequent dishwasher use may reduce the lifespan of the non-stick surface and

dull the exterior finish.

- For stubborn food residue, soak the pan in warm, soapy water for a few minutes before cleaning.
- Avoid using abrasive cleaners, steel wool, or scouring pads, as these can damage the non-stick coating.

### Storage

- Thanks to their stackable design, these pans can be stored efficiently.
- To protect the non-stick surface when stacking, place a soft cloth or pan protector between the pans.
- Store the removable handle separately or attached to one of the pans, ensuring it is clean and dry.




Image: The two frying pans stacked neatly, demonstrating their space-saving design. The image also indicates their diameters of 24 cm and 28 cm.

## TROUBLESHOOTING

| Issue | Possible Cause | Solution |
|---|---|---|

| Issue | Possible Cause | Solution |
|---|---|---|
| Food sticking to pan | Pan not properly seasoned; too high heat; damaged non-stick coating. | Re-season pan; use lower heat settings; avoid metal utensils. |
| Handle not attaching securely | Mechanism not aligned; debris in slot; handle not fully engaged. | Ensure proper alignment; clean slot; press firmly until it clicks. |
| Pan warping or deforming | Sudden temperature changes (e.g., hot pan under cold water); excessive high heat. | Always allow pan to cool before washing; use medium heat settings. |
| Discoloration on pan exterior | Residue from cooking; high heat. | Clean thoroughly after each use; ensure burner size matches pan base. |

## Specifications

| Attribute | Detail |
|---|---|
| Brand | Bergner |
| Model Number | Q3066 |
| Material | Pressed Aluminium |
| Color | Black Pressed Aluminum |
| Pan Sizes | 24 cm and 28 cm Diameter |
| Handle Material | Aluminum (for handle mechanism) |
| Compatibility | Induction, Ceramic, Gas, Halogen, Electric Cooktops |
| Dishwasher Safe | Yes |
| Oven Safe | Yes (without handle) |
| Product Dimensions | 12.2 x 13.19 x 14.17 inches (overall package) |
| Item Weight | 3.39 pounds |
| GTIN (UPC) | 06941349528333 |




Image: The base of a Bergner frying pan, illustrating the pressed aluminum material and its robust construction, designed for efficient heat distribution.

## Warranty and Support

Bergner products are manufactured to high quality standards. This product includes a**2-year EU Spare Part Availability Duration**, ensuring access to necessary components for repair or replacement within this period.
For any questions, concerns, or support regarding your Bergner Click & Cook Frying Pans, please contact Bergner customer support through their official website or the retailer from whom you purchased the product. Please have your model number (Q3066) and purchase information ready when contacting support.
Visit the official Bergner Store for more information:Bergner Store on Amazon

© 2024 Bergner. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B07T8GHRGK**

More documents and user manuals: **https://manuals.plus/**