## Vieta Pro Upper

# Vieta Pro Upper Portable Speaker User Manual

Model: Upper

## 1. Product Overview

The Vieta Pro Upper is a versatile portable speaker designed for high-quality audio on the go. It features Bluetooth connectivity for wireless streaming, an integrated FM radio, and a built-in microphone for hands-free calls. With True Wireless Dual Pair functionality, you can connect two Upper speakers for an enhanced stereo experience. It also supports USB playback and Micro SD card reading, offering multiple ways to enjoy your music. Its IPX6 water resistance makes it suitable for various environments.




**Figure 1.1:** Front view of the Vieta Pro Upper portable speaker, highlighting the top control panel and fabric finish.



**Figure 1.2:** Side view of the Vieta Pro Upper speaker, showing the vertical control buttons and integrated strap.



**Figure 1.3:** The Vieta Pro Upper speaker covered in water droplets, illustrating its IPX6 water-resistant design.



**Figure 1.4:** Contents of the Vieta Pro Upper package, including the speaker, charging cable, audio cable, and user manual.

## 2. Safety Information

- Do not expose the speaker to extreme temperatures or direct sunlight for prolonged periods.
- Avoid dropping or subjecting the speaker to strong impacts.
- Keep the speaker away from medical devices and strong magnetic fields.
- Do not attempt to disassemble or modify the speaker. This will void the warranty.
- Ensure all ports are properly sealed when exposed to water to maintain IPX6 water resistance.
- Use only the provided charging cable or a certified equivalent.

## 3. Package Contents

Please check the package contents upon unboxing to ensure all items are present:

- Vieta Pro Upper Portable Speaker
- USB Charging Cable
- Audio Cable
- User Manual
- Remote Control (if included with your specific model)

*Note: The inclusion of a remote control may vary by region or specific product bundle. Refer to Figure 1.4 for a visual representation of typical package contents.*

## 4. Setup

### 4.1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB charging cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will show the charging status and turn off when fully charged.

### 4.2. Powering On/Off

- To power on: Press and hold the Power button (⏻) for approximately 3 seconds until you hear an audible prompt.
- To power off: Press and hold the Power button (⏻) for approximately 3 seconds until you hear an audible prompt and the indicator lights turn off.

## 5. Operating Instructions

### 5.1. Bluetooth Pairing

1. Ensure the speaker is powered on.
2. The speaker will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
3. On your smartphone or tablet, enable Bluetooth and search for available devices.
4. Select "Vieta Pro Upper" from the list of devices.
5. Once paired, the LED light will become solid, and you will hear a confirmation sound.

6. The speaker will automatically reconnect to the last paired device when powered on, if within range.

### 5.2. True Wireless Dual Pair (TWS) Function

The TWS function allows you to connect two Vieta Pro Upper speakers together for a stereo sound experience.

1. Ensure both Vieta Pro Upper speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS button (often indicated by a chain link or infinity symbol) for a few seconds.
3. The primary speaker will search for the secondary speaker.
4. Once connected, you will hear a confirmation sound, and the LED indicators on both speakers will change to indicate a successful TWS connection.
5. Now, connect your Bluetooth device to the primary speaker as described in Section 5.1. Audio will play through both speakers in stereo.

### 5.3. FM Radio Mode

To switch to FM Radio mode, press the Mode button (often labeled with an 'M' or a symbol for mode switching) until you hear the FM radio prompt. Use the volume buttons to adjust the volume. To scan for stations, press and hold the Play/Pause button. The speaker will automatically scan and save available FM stations.

### 5.4. USB Playback and Micro SD Card

Insert a USB flash drive or a Micro SD card (up to 32GB, formatted to FAT32) into the respective port. The speaker will automatically detect the storage device and begin playing audio files (MP3, WAV, WMA formats supported). Use the track skip buttons to navigate through songs.

### 5.5. Auxiliary Input (AUX)

Connect an external audio device (e.g., MP3 player, computer) to the speaker's AUX-in port using the provided 3.5mm audio cable. The speaker will automatically switch to AUX mode. Control playback from your connected device.

### 5.6. Hands-Free Calling

When connected via Bluetooth to a smartphone, the integrated microphone allows for hands-free calling. Press the Play/Pause button to answer an incoming call, and press it again to end the call. Press and hold the Play/Pause button to reject an incoming call.

## 6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker. For stubborn dirt, a slightly damp cloth can be used, but ensure all ports are sealed and the speaker is completely dry before use or charging. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use, to maintain battery health.

## 7. Troubleshooting

| Problem | Possible Cause | Solution |
| --- | --- | --- |

| Problem | Possible Cause | Solution |
|---|---|---|
| Speaker does not turn on. | Battery is depleted. | Charge the speaker fully. |
| No sound. | Volume is too low; Device not paired; Incorrect mode selected. | Increase volume on speaker and connected device; Re-pair Bluetooth; Switch to correct input mode (Bluetooth, USB, SD, AUX, FM). |
| Bluetooth connection unstable. | Device is out of range; Interference; Low battery. | Move device closer to speaker (within 10m); Avoid obstacles; Charge speaker. |
| Cannot connect two speakers via TWS. | One or both speakers are already paired to a device; Incorrect TWS pairing procedure. | Disconnect speakers from any Bluetooth devices; Follow TWS pairing steps carefully (Section 5.2). |
| FM radio reception is poor. | Weak signal; Environmental interference. | Relocate the speaker; Extend the antenna (if applicable, or use the charging cable as an auxiliary antenna). |

## 8. Specifications

| Feature | Detail |
|---|---|
| Model Name | Upper |
| Brand | Vieta Pro |
| Connectivity Technology | Bluetooth, USB |
| Maximum Speaker Output Power | 10 Watts |
| Audio Output Mode | Stereo |
| Special Features | Bluetooth, Wireless, FM Radio, Integrated Microphone, True Wireless Dual Pair, USB Player, Micro SD Card Reader, IPX6 Water Resistance |
| Recommended Uses | For smartphones or tablets |
| Compatible Devices | Smartphone, Tablet |
| Mounting Type | Table Mount |
| Product Dimensions | 26.8 x 14 x 11.6 cm |
| Item Weight | 1.56 kg |

## 9. Warranty and Support

Vieta Pro products are manufactured with high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official Vieta Pro website. Keep your purchase receipt as proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or service inquiries, please contact Vieta Pro customer support through their official channels. Contact information can typically be found on the product packaging, the official website, or the included user manual.

You can also visit the Vieta Pro Store on Amazon for more product information and support resources.

© 2024 Vieta Pro. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.