Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Earthtec W11307244

Earthtec W11307244 Washer Lid Lock Replacement Manual

For Maytag, Kenmore, and other compatible washing machine models.

Introduction

This manual provides instructions for the installation and troubleshooting of the Earthtec W11307244 washer lid lock assembly. This replacement part is designed to restore proper lid locking functionality to your washing machine, addressing common issues such as error codes, inability to start cycles, or failure to drain or spin.

Product Overview



The W11307244 is a replacement lid lock assembly for various washing machine models. It includes the lock mechanism, wiring harness, and connectors necessary for installation. This component ensures the washer lid remains securely closed during operation, which is crucial for safety and proper cycle completion.



This image provides a detailed view of the W11307244 lid lock assembly, highlighting its main components: the black lock housing, the white latch mechanism, and the attached wiring harness with connectors. The yellow corrugated tubing protects a portion of the wiring.

Compatibility

The W11307244 washer lid lock assembly is compatible with a range of washing machine models from brands such as Maytag, Kenmore, and Whirlpool. It replaces part numbers W10682535, W10838613, W10838613VP, W11253733, and PS12704713.
Known compatible models include, but are not limited to:

- NTW4516FW0, NTW4516FW3
- WTW4655JW0, WTW4816FW2, WTW4955HW1
- WTW5000DW1, WTW5000DW2, WTW5000DW3, WTW5005KW0
- MVWC565FW1



This image displays a comprehensive table listing various compatible washing machine models from Whirlpool, Kenmore, Maytag, Crosley,

Roper, and Admiral, ensuring broad applicability for the W11307244 replacement part.

Troubleshooting Common Issues

The W11307244 lid lock assembly is designed to resolve several common washing machine malfunctions related to the lid locking mechanism. If your washing machine is experiencing any of the following symptoms, replacing the lid lock may be necessary:

- The washing machine displays error codes F2 and E1.
- The washing machine prompts "Locked," but the door is closed and the cycle cannot be started.
- The washing machine fails to rotate or agitate.
- The washing machine does not drain water.
- The lid can be opened while the washing machine is in operation.

Installation Instructions

Safety Precaution: Before beginning any installation, always disconnect the washing machine from its power supply. It is also recommended to wear work gloves to protect your hands.

1. **Access the Lid Lock:**
   To access the lid lock assembly, gently slide the washing machine lid forward. Then, slightly lift the front edge of the lid (approximately the thickness of a finger). Slide the lid a little further back to release any hooks, allowing the lid to open fully.
2. **Disconnect Old Assembly:**
   Locate the existing lid lock assembly. Carefully disconnect the wiring harness and any mounting screws or clips securing it in place. Note the orientation of the old part for correct installation of the new one.
3. **Install New Assembly:**
   Position the new W11307244 lid lock assembly in the same location and orientation as the old part. Secure it with the appropriate screws or clips. Connect the wiring harness firmly.



This image illustrates the process of installing the W11307244 lid lock assembly into the washing machine, showing the component in place with its wiring.

4. **Post-Installation Unlock Procedure:**
   If the washing machine remains locked after installation, you may need to perform an unlock procedure. Insert a flat-head screwdriver into the lock mechanism and gently push the latch to the left. Then, insert the screwdriver

into the washing machine's lid strike area. The lock should release after 5 to 10 seconds.

5. **Test Functionality:**
   Reconnect the washing machine to the power supply. Close the lid and attempt to start a cycle to verify that the lid locks correctly and the machine operates as expected.

For visual guidance, it is recommended to search for relevant installation videos on platforms like YouTube using the part number W11307244.

Your browser does not support the video tag.

This video demonstrates the W11307244 washer lid lock assembly, showing its physical characteristics and how it functions. It can serve as a visual aid for understanding the component before installation.

Specifications

Attribute	Detail
Part Number	W11307244
Item Weight	5 ounces
Package Dimensions	13.54 x 4.29 x 1.3 inches
Manufacturer	Earthtec
Batteries Required	No



This diagram provides key dimensions of the W11307244 lid lock assembly, including length, width, and height, which can be useful for verifying fitment.

Maintenance

As a replacement part, the W11307244 washer lid lock assembly typically requires no routine maintenance. Its design is intended for long-term operation once correctly installed. If issues recur, re-evaluate the installation steps or consult a qualified technician.

Warranty and Support

Information regarding specific warranty terms or direct support contacts for the Earthtec W11307244 replacement part is not provided within this manual. Please refer to the product packaging or the retailer's website for details on warranty

coverage and customer support options.

Earthtec W11307244 Washer Lid Lock Replacement Manual. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07TG72N2K

More documents and user manuals: **https://manuals.plus/**