Soundstream VR-720B

Soundstream VR-720B Multimedia Player User Manual

Model: VR-720B

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Soundstream VR-720B Multimedia Player. Please read this manual thoroughly before using the product to ensure proper functionality and safety. Keep this manual for future reference.

Safety Information

To prevent injury or damage to the unit, observe the following precautions:

- Do not operate the unit while driving. Distracted driving can lead to accidents.
- Ensure proper ventilation around the unit to prevent overheating.
- Avoid exposing the unit to extreme temperatures, direct sunlight, or moisture.
- Use only specified power sources and accessories.
- Do not attempt to disassemble or modify the unit. Refer all servicing to qualified personnel.
- Keep out of reach of children.

Product Overview

The Soundstream VR-720B is a versatile car stereo multimedia player featuring a motorized 7-inch foldable touch screen, DVD/CD playback, Bluetooth connectivity, and a built-in amplifier. It is designed to enhance your in-car entertainment experience.

Main Unit Components



Figure 1: Front view of the Soundstream VR-720B with the 7-inch motorized touch screen in the extended position, displaying the Soundstream logo.



Figure 2: Front view of the Soundstream VR-720B unit with the screen retracted, showing the control panel, display, and USB port.



Figure 3: Included remote control for the VR-720B, alongside an external camera. Note: Camera functionality and inclusion may vary by package.

Key Features:

- 7-inch Foldable DVD Receiver
- Motorized Angle Adjustment for screen positioning
- Detachable Anti-Theft Faceplate for security
- Bluetooth V4.0 for Hands-Free Calling
- A2DP Wireless MP3 Audio Playback
- DVD-R, DVD-RW, VCD, CD-R, CD-RW Media Playback
- USB Connectivity

Setup and Installation

Professional installation is highly recommended for this product. Incorrect wiring or installation can cause damage to the unit or vehicle's electrical system.

Pre-Installation Checklist:

- Ensure the vehicle's battery is disconnected before starting installation.
- Verify all included components are present (main unit, wiring harness, remote control, mounting hardware).
- Consult your vehicle's service manual for specific dashboard removal and wiring diagrams.

Wiring Diagram (General):

A detailed wiring diagram is typically provided with the product packaging. Below is a general guide for common connections:

Wire Color	Function
Yellow	Constant 12V (Battery)
Red	Switched 12V (Accessory/Ignition)
Black	Ground
Blue	Power Antenna / Amplifier Remote Turn-On
Orange/White	Illumination
Green	Left Rear Speaker (+)
Green/Black	Left Rear Speaker (-)
Purple	Right Rear Speaker (+)
Purple/Black	Right Rear Speaker (-)
White	Left Front Speaker (+)
White/Black	Left Front Speaker (-)
Gray	Right Front Speaker (+)
Gray/Black	Right Front Speaker (-)

Note: This is a general guide. Always refer to the specific wiring diagram provided with your VR-720B unit for accurate connections.

Operating Instructions

Power On/Off and Volume Control

- **Power On:** Press the **POWER** button (usually the volume knob) to turn the unit on.
- **Power Off:** Press and hold the **POWER** button for a few seconds to turn the unit off.
- **Volume Adjustment:** Rotate the **VOL** knob clockwise to increase volume, counter-clockwise to decrease.

Screen Operation

- **Screen Extension/Retraction:** Press the **OPEN** button to extend the screen. Press it again to retract.
- **Angle Adjustment:** Use the **ANGLE** buttons on the remote or touch screen controls to adjust the viewing angle of the motorized screen.
- **Touch Screen:** Navigate menus and control functions by touching the icons and options displayed on the 7-inch LCD screen.

Source Selection

Press the **SOURCE** or **MODE** button to cycle through available audio/video sources: Radio (FM/AM), DVD/CD, USB, Bluetooth Audio, AUX In.

Radio Operation (FM/AM)

- **Band Selection:** Press the **BND** button to switch between FM1, FM2, FM3, and AM bands.
- **Manual Tuning:** Press the **TUNE +/-** buttons to manually adjust the frequency.
- **Seek Tuning:** Press and hold the **TUNE +/-** buttons to automatically seek the next strong station.
- **Preset Stations:** Press and hold a numbered preset button (1-6) to save the current station. Briefly press to recall a saved station.

DVD/CD Playback

- **Disc Insertion:** Gently insert a DVD or CD into the disc slot. The unit will automatically load and begin playback.
- **Playback Controls:** Use the **PLAY/PAUSE**, **STOP**, **SKIP** (>>|, |<<), and **FAST FORWARD/REWIND** buttons on the unit or remote.
- **Menu Navigation:** Use the touch screen or directional buttons on the remote to navigate DVD menus.

Bluetooth Operation

- **Pairing:**
    1. Ensure Bluetooth is enabled on your mobile phone.
    2. Select "Bluetooth" as the source on the VR-720B.
    3. On your phone, search for available devices and select "VR-720B" (or similar name).
    4. If prompted, enter the pairing code (usually "0000" or "1234").
    5. Once paired, the unit will confirm the connection.
- **Hands-Free Calling:**
    - **Answer Call:** Press the **PHONE** button or touch the answer icon on the screen.
    - **End Call:** Press the **PHONE** button or touch the end call icon.
    - **Dialing:** Use the touch screen dial pad or initiate calls from your paired phone.
- **Bluetooth Audio (A2DP):** Once paired, audio from your phone (music, podcasts) will stream wirelessly to the VR-

720B. Use the unit's controls or your phone to manage playback.

USB Playback

- Insert a USB flash drive into the USB port. The unit will automatically switch to USB mode and begin playing compatible audio/video files.
- Use the **SKIP** buttons to navigate between tracks/files.

Maintenance

- **Cleaning the Screen:** Use a soft, lint-free cloth to gently wipe the touch screen. Do not use abrasive cleaners or solvents.
- **Cleaning the Unit:** Wipe the exterior of the unit with a soft, dry cloth.
- **Disc Care:** Handle discs by their edges. Keep them clean and free of scratches.
- **Detachable Faceplate:** When removing the faceplate, store it in the provided protective case to prevent damage.

Troubleshooting

Problem	Possible Cause	Solution
No Power	Incorrect wiring; Blown fuse; Vehicle battery low.	Check wiring connections (Yellow, Red, Black). Replace fuse if blown. Check vehicle battery.
No Sound	Volume too low; Mute function active; Speaker wires disconnected; Incorrect audio settings.	Increase volume. Deactivate mute. Check speaker connections. Adjust audio settings (e.g., fader/balance).
Disc Error / Disc Not Playing	Disc is dirty, scratched, or incompatible format; Disc inserted incorrectly.	Clean disc. Try a different disc. Ensure disc is inserted correctly with label facing up. Check media type compatibility.
Bluetooth Pairing Failure	Bluetooth not enabled on phone; Unit not in pairing mode; Interference.	Ensure Bluetooth is on and discoverable on your phone. Select Bluetooth source on unit. Move closer to unit. Restart both devices.
Screen Not Extending/Retracting	Obstruction; Motor issue; Power issue.	Check for obstructions. Ensure unit has stable power. If problem persists, contact support.
Poor Radio Reception	Antenna not connected or damaged; Weak signal area.	Check antenna connection. Try tuning to a stronger station.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Feature	Detail
Model Number	VR-720B
Brand	Soundstream

Feature	Detail
Product Dimensions	26.67 x 22.86 x 11.43 cm
Item Weight	1.81 kg (4 pounds)
Screen Size	7 inches
Display Type	LCD
Display Resolution	800 x 480 pixels
Visible Screen Diameter	7 inches / 18 cm
Media Type	DVD-R, DVD-RW, VCD, CD-R, CD-RW
Connectivity Technology	Bluetooth, USB
Bluetooth Version	V4.0
Compatible Devices	Mobile Phone
Color	Black
Manufacturer	Sound Stream
First Available Date	September 18, 2022
UPC	709483058224

Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Soundstream website. Keep your proof of purchase for warranty claims.
Online Resources: For the latest updates, FAQs, and additional support, please visit theSoundstream Official Website.

© 2024 Soundstream. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question