AMI PARTS 218428101

AMI PARTS 218428101 Refrigerator Door Handle Instruction Manual

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your AMI PARTS 218428101 Refrigerator Door Handle. Please read these instructions carefully before beginning installation to ensure proper function and safety. This handle is designed as a replacement for various refrigerator models.

Safety Information

WARNING:

- Always unplug the refrigerator unit from its power source before attempting any service or installation. Failure to do so may result in electrical shock or injury.
- Wear appropriate personal protective equipment, such as gloves, during installation to prevent injury.
- If you are unsure about the correct part or installation procedure, consult a qualified technician or contact AMI PARTS customer support.

Product Specifications

Feature	Detail
Model Number	218428101
Material	High-strength plastic
Color	White
Product Dimensions (L x W)	Approximately 16.7 inches x 0.98 inches
Item Weight	3.84 ounces
Handle Attachment Mechanism	Screw



Figure 1: Product Dimensions. The handle measures approximately 16.7 inches in length.

Compatibility

The AMI PARTS 218428101 refrigerator door handle is compatible with various models from the following brands:

- Frigidaire
- Kenmore
- Crosley
- Gibson
- Tappan
- White-Westinghouse

This handle replaces part numbers AP2114539, 241711801, AH427922, EA427922, and PS427922.
Known compatible refrigerator models include, but are not limited to:

- WRT13CRJW0

- WRT13GRHW1
- WRT15CSHW1
- WRT15CSHW2
- WRT15CSHW4
- WRT15MB3AQ0
- WRT15MB3AQ1
- WRT15MB3AW0
- WRT15MB3AW1
- WRT15MB3AW2
- WRT15MB3AW3
- WRT15MB3AW4
- WRT15MG4BW0
- WRT15MG4BW1
- WRT15MG4BW3
- WRT15MG4BW4
- WRT15MG4BW5
- WRT15MG4BW7
- WRT15MG4BW8
- WRT15MG4BWA
- WRT16JRCW0
- WRT16JRCW1
- WRT16JRCW2



Figure 2: Compatible Refrigerator Models.

Installation Instructions

Follow these steps to replace your refrigerator door handle. Remember to unplug the appliance before starting.

1. **Step 1: Remove the Old Handle**
   Carefully locate and remove the screws securing the old handle to the refrigerator door. These are typically found at the top and bottom ends of the handle. Keep the screws as they may be needed for the new handle.
2. **Step 2: Position the New Handle**
   Align the new AMI PARTS 218428101 handle with the screw holes on the refrigerator door. Ensure the handle is oriented correctly.
3. **Step 3: Secure the Handle**
   Insert the screws (from the old handle or new ones if provided and compatible) into the handle's attachment points and tighten them securely. Do not overtighten, as this may damage the handle or door.
4. **Step 4: Test the Installation**

Gently pull on the newly installed handle to ensure it is firmly attached and does not wobble.



Figure 3: Step-by-Step Installation Guide.

Video Instructions (Not Available)

No specific installation videos were provided for this product in the available data. Please refer to the step-by-step written instructions and diagrams.

Operating Instructions

The AMI PARTS 218428101 Refrigerator Door Handle functions as a standard refrigerator handle. Simply grasp the handle firmly and pull to open the refrigerator or freezer door. Ensure the door closes completely after use to maintain appliance efficiency.

Maintenance

To maintain the appearance and functionality of your refrigerator door handle:

- Clean the handle regularly with a soft cloth and mild soap and water.
- Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the plastic finish.
- Periodically check the screws for tightness and re-tighten if necessary to prevent loosening.



Figure 4: Handle Details for Maintenance.

Troubleshooting

If you encounter issues with your AMI PARTS 218428101 Refrigerator Door Handle, consider the following:

- **Handle Feels Loose:** Check the attachment screws at both ends of the handle. Tighten them gently with a screwdriver until the handle is secure. Avoid overtightening.
- **Handle Does Not Fit Properly:** Verify that the model number of your refrigerator is listed in the compatibility section. Some refrigerators may have slight variations. Ensure you are using the correct screws and that the handle is aligned correctly with the mounting points. In some cases, minor adjustments or drilling new pilot holes might be

necessary if the replacement handle is slightly different from the original.

- **Difficulty Opening Door:** Ensure the handle is securely fastened and not obstructing the door's movement. If the issue persists, it may be related to the refrigerator door seal or hinges, not the handle itself.

Warranty and Support

The AMI PARTS 218428101 Refrigerator Door Handle replacement supports a 180-day return and exchange policy. If you have any questions or encounter problems with this refrigerator handle, please contact AMI PARTS customer service. Our professional after-sales service team is available to assist you and aims to resolve your concerns within 24 hours. You can reach us through the Amazon email system or by utilizing the question and answers section on the product page.

© 2026 AMI PARTS. All rights reserved.
For more information and products, visit the AMI PARTS Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question