**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Skip Hop 303600**

# Skip Hop Cry-Activated Baby Sleep Soother (Unicorn, Model 303600) User Manual

Model: 303600

## Introduction

The Skip Hop Cry-Activated Baby Sleep Soother is designed to comfort and soothe infants with a combination of lullabies, nature sounds, and a parent's recorded voice. This plush unicorn features a smart sensor that detects and responds to a baby's cries, helping both baby and parents achieve better sleep. It easily attaches to a crib and can transition into a huggable friend as the child grows.

### Key Features:

- Cry-activated smart sensor automatically responds to baby's cries.
- Voice recorder mode allows parents to record custom messages.
- Includes 3 lullabies and 3 soothing white noise sounds.
- Provides up to 20 minutes of continuous play.
- Easily attaches to most cribs with hook-and-loop fasteners.
- Designed to grow with the child, becoming a huggable plush toy.



Image: The Skip Hop Unicorn Soother attached to a crib, providing comfort to a sleeping baby.

## Safety Information

Please read and follow all safety instructions to ensure safe operation and prevent injury.

- Always ensure the soother is securely attached to the crib and out of reach of the baby's hands and mouth.
- Do not place the soother inside the crib with the baby.
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the product is not used for an extended period.
- Inspect the product regularly for any damage. Discontinue use if damaged.
- This product is not a toy for chewing or rough play.

## Package Contents

- 1 x Skip Hop Cry-Activated Baby Sleep Soother (Plush Unicorn)
- 1 x Removable Sound Module (pre-installed)
- Instruction Manual (this document)

## Setup

### 1. Battery Installation

1. Locate the sound module compartment on the back of the plush unicorn.
2. Open the fabric flap and remove the sound module.
3. Using a small screwdriver, open the battery compartment on the sound module.
4. Insert 3 AAA batteries (not included), ensuring correct polarity (+/-).
5. Close the battery compartment and secure it with the screw.
6. Place the sound module back into the plush unicorn and secure the fabric flap.

### 2. Attaching to Crib

1. Identify a suitable location on the crib rail, ensuring it is out of the baby's reach.
2. Use the hook-and-loop fasteners located on the unicorn's arms/legs to securely attach it to the crib rail.
3. Ensure the soother is firmly attached and cannot be pulled down by the baby.



Image: Securely attaching the soother to the crib rail.

## Operating Instructions

The sound module, located within the plush unicorn, features controls for power, sound selection, volume, and recording.




Image: Control buttons on the sound module.

## 1. Power On/Off

- Press and hold the power button (usually the central button) for 2 seconds to turn the unit on or off.

## 2. Sound Selection

- Press the 'Sound' button (often indicated by a music note or wave icon) to cycle through the available lullabies, nature sounds, and white noise options.
- The soother offers 3 lullabies and 3 soothing sounds.

## 3. Volume Adjustment

- Use the '+' and '-' buttons to increase or decrease the volume level.

## 4. Cry-Activated Sensor

- When the soother is on, the cry-activated sensor is active. It distinguishes between cries and other sounds.

- If the baby cries, the soother will automatically play the last selected sound for up to 20 minutes to help soothe the baby back to sleep.

## 5. Voice Recording

1. Locate the 'Record' button on the sound module (often indicated by a microphone icon).
2. Press and hold the 'Record' button. Speak clearly into the microphone on the sound module.
3. Release the 'Record' button when finished. The recorded message will be saved.
4. To play your recorded message, select it using the 'Sound' button.



Image: Recording a personalized message for your baby.

## 6. Transition to Toddler Friend

As your child grows, the soother can be removed from the crib and used as a soft, huggable plush toy. The sound module can remain inside for continued use of sounds and recordings, or be removed if desired.



Image: The soother transitions into a comforting friend for toddlers.

## Maintenance

### 1. Cleaning

- Remove the sound module before cleaning the plush toy.
- The plush toy can be surface-cleaned with a damp cloth and mild soap. Air dry thoroughly.
- Do not immerse the plush toy or sound module in water.
- Wipe the sound module with a dry, soft cloth.

### 2. Storage

- Store the soother in a cool, dry place away from direct sunlight.
- If storing for an extended period, remove the batteries from the sound module to prevent leakage.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| No sound or unit does not turn on. | Dead or incorrectly installed batteries. | Check battery polarity. Replace with fresh AAA batteries. |
| Cry sensor not activating. | Low battery, sensor obstructed, or too much ambient noise. | Replace batteries. Ensure sensor area is clear. Reduce other noise sources. |
| Poor recording quality. | Microphone too far, speaking too softly, or background noise. | Speak closer to the microphone. Record in a quiet environment. |
| Sound cuts out prematurely. | Low battery power. | Replace batteries. |

## Specifications

- **Model Number:** 303600
- **Brand:** Skip Hop
- **Color:** Unicorn
- **Item Weight:** 0.34 kg (0.75 lbs)
- **Item Dimensions (L x W x H):** 6.02 x 4.02 x 10.98 inches
- **Power Source:** 3 x AAA Batteries (not included)
- **GTIN/UPC:** 816523028908
- **Features:** Cry-activated sensor, Voice recorder, 3 Lullabies, 3 Soothing Sounds, 20-minute continuous play.

## Warranty & Support

For detailed warranty information, please refer to the official warranty document provided by Skip Hop. A digital copy may be available at the following link:
Skip Hop Warranty Information (PDF)
For further assistance or support, please visit the official Skip Hop website or contact their customer service department.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B07TPY1RMD**

More documents and user manuals: **https://manuals.plus/**