Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beper BP.690

BEPER BP.690 Milkshake and Cocktail Mixer Instruction Manual

Model: BP.690 | Brand: Beper

1. Introduction

Thank you for purchasing the BEPER BP.690 Milkshake and Cocktail Mixer. This appliance is designed for preparing creamy milkshakes, iced coffee, cocktails, and baby food. Please read this instruction manual carefully before first use to ensure safe and efficient operation. Keep this manual for future reference.



This image displays the BEPER BP.690 mixer in red, highlighting its 100W power, 500ml capacity, two speed settings, and stainless steel components. Two prepared drinks, an iced coffee and a milkshake, are shown next to the mixer.

2. Important Safety Instructions

- Read all instructions before using the appliance.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not immerse the motor unit, cord, or plug in water or other liquids.
- Always unplug the appliance from the power outlet when not in use, before cleaning, and before assembling or disassembling parts.
- Keep hands and utensils out of the container while blending to reduce the risk of severe injury to persons or damage to the mixer.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use the mixer for blending whole fruit or ice, as this can damage the appliance.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- Do not use outdoors.

3. Product Components

The BEPER BP.690 Milkshake and Cocktail Mixer consists of the following main components:

- Motor Unit (Base)
- Mixing Spindle with Whisk
- 500 ml Stainless Steel Mixing Cup
- On/Off and Speed Selection Switch





A detailed view of the stainless steel mixing cup, showing clear measurement lines for up to 500ml, essential for precise ingredient quantities.

4. Setup

1. Unpack all components and remove any packaging materials.
2. Place the motor unit on a stable, flat, and dry surface.
3. Ensure the appliance is unplugged before assembly.
4. Wash the stainless steel mixing cup and whisk thoroughly before first use. Refer to the 'Cleaning and Maintenance'

section for details.

5. Ensure the mixing spindle with whisk is securely attached to the motor unit.

5. Operating Instructions

Follow these steps to operate your BEPER BP.690 mixer:

1. Ensure the on/off switch is set to the '0' (off) position.
2. Pour your desired ingredients into the 500 ml stainless steel mixing cup. Remember, the mixer is ideal for milkshakes, iced coffee, cocktails, and baby food. Do not use whole fruit or ice.
3. Place the mixing cup onto the base, aligning it so the whisk is submerged in the ingredients.
4. Plug the appliance into a suitable power outlet.
5. Select your desired speed by moving the switch to 'I' (low speed) or 'II' (high speed). Choose the speed based on the consistency you wish to achieve.
6. Allow the mixer to operate until the desired consistency is reached.
7. Once mixing is complete, set the on/off switch back to '0' and unplug the appliance.
8. Carefully remove the mixing cup and pour out the contents.



This collage illustrates the operational steps: 1. Placing the stainless steel cup onto the mixer. 2. Pouring ingredients into the cup. 3. Serving a finished cocktail from a shaker. 4. The mixer alongside a prepared cocktail and a glass of milk.

6. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your appliance.

- Always unplug the mixer before cleaning.
- The stainless steel mixing cup is removable and dishwasher safe for easy cleaning.
- The steel and plastic whisk should be cleaned with a damp sponge and mild detergent. Do not place the whisk in a dishwasher if it contains plastic parts that are not specified as dishwasher safe.
- Wipe the motor unit (base) with a damp cloth. Do not immerse the motor unit in water or any other liquid.
- Ensure all parts are completely dry before storing or re-using the appliance.
- Do not use abrasive cleaners or scouring pads, as they may scratch the surfaces.

7. Troubleshooting

If you encounter issues with your mixer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mixer does not turn on.	Not plugged in; power switch is off; power outlet malfunction.	Ensure the power cord is securely plugged into a working outlet. Check the on/off switch is set to 'I' or 'II'. Test the outlet with another appliance.
Ingredients are not mixing properly.	Too many ingredients; ingredients are too thick; incorrect speed selected.	Reduce the amount of ingredients. Add more liquid if the mixture is too thick. Select a higher speed setting. Ensure ingredients are suitable for the mixer (no whole fruit or ice).
Unusual noise or vibration.	Cup not properly seated; foreign object in cup; damaged whisk.	Ensure the mixing cup is correctly placed. Unplug and check for any foreign objects. Inspect the whisk for damage. If the problem persists, discontinue use and contact customer support.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Feature	Detail
Model Number	BP.690
Brand	BEPER
Power	100 W
Voltage	220 V
Capacity	500 ml
Number of Speeds	2
Dimensions (D x W x H)	13D x 18W x 39.5H cm
Materials	ABS, Stainless Steel
Color	Red

Feature	Detail
Dishwasher Safe (Cup)	Yes
BPA-Free	Yes

9. Warranty and Customer Support

For warranty information, technical support, or service inquiries, please refer to the documentation included with your product or visit the official Beper website. You may also find additional support by contacting the retailer where the product was purchased.

An official instruction manual (PDF) is available for download: Download PDF Manual

© 2023 Beper. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07TQVD94L

More documents and user manuals: **https://manuals.plus/**