Skip Hop 304326

Skip Hop Cry-Activated Baby Soother (Model 304326) Instruction Manual

Brand: Skip Hop | Model: 304326

1. Product Overview

The Skip Hop Cry-Activated Baby Soother is designed to comfort infants with soothing sounds and lullabies, featuring a cry-activated smart sensor. This soft plush toy, available as a Sloth, automatically responds to a baby's cries to help them return to sleep. It includes a voice recording option for personalized comfort and can be easily attached to a crib. As the child grows, it transitions into a huggable friend.

Key Features:

- **Cry-Activated Smart Sensor:** Distinguishes between cries and other sounds to automatically activate soothing responses.
- **Removable Sound Module:** Easy to set and customize.
- **Voice Recorder Mode:** Allows parents to record their voice to comfort the baby.
- **Multiple Sound Options:** Includes 3 lullabies and 3 soothing white sounds.
- **Continuous Play:** Offers up to 20 minutes of continuous play.
- **Crib Attachment:** Easily attaches to most cribs using hook-and-loop fasteners.
- **Grows with Baby:** Designed to become a huggable friend for toddlers.





Image: The Skip Hop Cry-Activated Baby Soother in Sloth design, attached to the side of a white crib where a baby is sleeping peacefully. This illustrates the product in its intended use environment.



Image: A toddler is shown happily hugging the Skip Hop Sloth Baby Soother, illustrating how the product can transition into a comforting companion as the child grows.

2. Setup and Installation

1. **Unpack the Soother:** Carefully remove the soother from its packaging. Ensure all components are present.
2. **Install Batteries:**

- Locate the battery compartment on the back of the sound module, typically found within the plush toy.
- Open the compartment using a small screwdriver if necessary.
- Insert 3 AA batteries, ensuring correct polarity (+/-). The product typically includes batteries.
- Close the battery compartment securely.

3. **Attach to Crib:**
    - The soother features hook-and-loop fasteners on its arms.
    - Wrap the arms around a crib rail or other secure fixture.
    - Ensure the soother is securely fastened and out of reach of the baby's hands and mouth to prevent entanglement or choking hazards.



Image: A woman demonstrates how to securely attach the Sloth Baby Soother to the crib rail, highlighting the hook-and-loop fasteners for safe placement.

3. Operating Instructions

Sound Module Controls:

The sound module, located within the plush toy, has several buttons for controlling its functions.



Image: A hand pressing a button on the sound module located on the back of the Sloth Soother, which is attached to a crib. This shows the user interface for operating the device.

- **Power Button:** Press to turn the soother ON or OFF.
- **Volume Control:** Adjust the sound level to a comfortable volume for your baby.
- **Sound Selection:** Cycle through the 3 lullabies and 3 white sounds.
- **Voice Recorder Button:**
    - Press and hold to record a message or song.

    - Release the button to stop recording.
    - Press briefly to play back your recorded message.
- **Cry-Activated Sensor Mode:** Activate this mode for the soother to automatically respond to baby's cries. The soother will play selected sounds for up to 20 minutes.

Your browser does not support the video tag.

Video: An official product video demonstrating the cry-activated feature, sound options, and voice recording function of the Skip Hop Cry-Activated Soother. It shows the soother responding to a baby's cries and a parent recording their voice.

4. Maintenance and Care

- **Cleaning the Plush Toy:**
    - Before cleaning, always remove the sound module from the plush toy.
    - The plush exterior can be surface-cleaned with a damp cloth and mild soap.
    - Allow to air dry completely before reinserting the sound module.
    - Do not immerse the plush toy or sound module in water.
- **Battery Care:**
    - Replace all batteries at the same time. Do not mix old and new batteries.
    - Use only AA Alkaline batteries as specified.
    - Remove batteries if the soother will not be used for an extended period to prevent leakage and damage.
    - Dispose of used batteries responsibly according to local regulations.
- **Storage:** Store the soother in a clean, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

Problem	Possible Cause	Solution
Soother does not turn on or function.	• Dead or incorrectly installed batteries. • Battery corrosion.	• Ensure batteries are new and inserted with correct polarity. • Check battery compartment for corrosion. If present, clean carefully or replace the sound module if severely damaged.
Cry-activated sensor is not responding.	• Sensor not activated. • Ambient noise interfering.	• Ensure the cry-activated sensor mode is enabled on the sound module. • Reduce other loud noises in the room.
Sound is too loud or too quiet.	Volume setting.	Adjust the volume using the dedicated buttons on the sound module.
Voice recording is unclear or not playing.	• Recording error. • Microphone obstruction.	• Re-record the message, ensuring you speak clearly and close to the microphone. • Check for any debris or fabric covering the microphone on the sound module.

6. Specifications

Feature	Detail
Model Number	304326
Product Dimensions	6.02 x 4.02 x 10.98 inches
Item Weight	12 ounces (0.34 Kilograms)
Material Type	Polyester
Color Name	Sloth Baby Soother
Batteries Required	3 AA batteries (included)
Battery Type	Alkaline
Voltage	28 (Note: This value is provided in the product specifications. For typical 3xAA battery devices, the voltage is 4.5V.)
Date First Available	June 26, 2019

7. Warranty and Support

For warranty information and customer support, please refer to the official Skip Hop website or contact their customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.
You can visit the Skip Hop Store for more information:Skip Hop Store on Amazon