Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Accessory USA AC/DC Adapter

Accessory USA AC/DC Adapter for Kinter MA-200 Amplifier User Manual

Introduction

This manual provides essential instructions for the safe and effective use of your Accessory USA AC/DC Adapter. This adapter is specifically designed for compatibility with the Kinter MA-200 USB SD Amp 480W 4CH Home Car HiFi Digital Stereo Power Amplifier, ensuring reliable power delivery for your audio system.

Safety Information

- Our products are **CE** / **FCC** / **RoHS certified**, ensuring compliance with international safety and environmental standards.
- The adapter features **OVP (Over Voltage output Protection)**, **OCP (Over Current output Protection)**, and **SCP (Short Circuit output Protection)** to safeguard your connected devices from electrical hazards.
- Always ensure the adapter's voltage and wattage specifications match the requirements of your Kinter MA-200 amplifier before connecting.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to severe impact.

Setup

Follow these steps to correctly set up your AC/DC adapter:

1. **Identify Ports:** Locate the power input port on your Kinter MA-200 amplifier.
2. **Connect DC Output:** Carefully connect the DC output plug of the Accessory USA AC/DC Adapter to the amplifier's power input port. Ensure a snug and secure fit.
3. **Connect AC Input:** Plug the AC input cord of the adapter into a standard wall outlet (compatible with 100-240V AC).
4. **Verify Connections:** Double-check that all connections are firm and correctly seated before proceeding.



An image showing the black rectangular AC/DC power adapter unit with its attached input and output power cables coiled neatly beside it.

Operating Instructions

Once properly connected, the Accessory USA AC/DC Adapter will supply the necessary power to your Kinter MA-200 amplifier. Operate your amplifier according to its own instruction manual. To disconnect, always unplug the adapter from the wall outlet first, then from the amplifier.

Maintenance

- Keep the adapter clean by wiping it with a dry, soft cloth. Avoid using liquid cleaners.
- Store the adapter in a cool, dry place when not in use.
- Regularly inspect the power cords for any signs of fraying, cuts, or damage. If damage is observed, discontinue use immediately and replace the adapter.
- Do not attempt to open, modify, or repair the adapter yourself. This can void any potential warranty and poses a safety risk.

Troubleshooting

- **No Power to Amplifier:**
  - Ensure the adapter is securely plugged into both the wall outlet and the amplifier.
  - Verify that the wall outlet is functional by testing it with another device.
  - Check for any visible damage to the adapter's cables or housing.
- **Intermittent Power:**
  - Check for loose connections at both the wall outlet and the amplifier.
  - Confirm that the adapter's specifications (voltage, wattage) are appropriate for the amplifier's power

requirements.

Specifications

- **Brand:** Accessory USA
- **Input Voltage:** 100-240 Volts AC
- **Wattage:** 480 watts
- **Connector Type:** USB *(Note: This refers to a feature of the compatible amplifier, Kinter MA-200, not the adapter's output plug.)*
- **Special Feature:** Short Circuit Protection
- **Power Source:** Corded Electric
- **Main Power Connector Type:** 2 Pin (AC Input)
- **Certifications:** CE, FCC, RoHS
- **UPC:** 607182561765
- **Compatible Model:** Kinter MA-200

Warranty and Support

For product support, warranty information, or any inquiries regarding your Accessory USA AC/DC Adapter, please contact Accessory USA customer service directly. Refer to your purchase documentation for specific contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07TRJZKWJ

More documents and user manuals: **https://manuals.plus/**