Expert Grill 841765101317

Expert Grill Portable Charcoal Grill User Manual

Model: 841765101317

Introduction

Thank you for choosing the Expert Grill Portable Charcoal Grill. This compact and convenient charcoal grill is designed for grilling on the go, making it ideal for camping trips, picnics, tailgating, or small outdoor spaces. Its easy assembly ensures you can start grilling quickly.



Image: The Expert Grill Portable Charcoal Grill, showcasing its compact design with the lid closed.

Safety Information

WARNING: Failure to follow these safety instructions could result in fire, explosion, or burn hazard, which could

cause property damage, personal injury, or death.

- For outdoor use only. Do not use indoors or in enclosed areas.
- Keep children and pets away from the grill at all times.
- Use on a flat, stable, non-combustible surface.
- Do not use gasoline, alcohol, or other highly volatile fluids to light charcoal.
- Allow the grill to cool completely before moving or cleaning.
- Always use heat-resistant gloves when handling hot components.
- Ensure proper ventilation to prevent carbon monoxide buildup.
- Keep a fire extinguisher or a bucket of sand nearby in case of fire.

Package Contents

Please ensure all parts are present before beginning assembly. If any parts are missing or damaged, do not attempt to assemble or operate the grill. Contact customer support for assistance.

- Grill Body (Bowl)
- Lid with Handle
- Cooking Grate (1)
- Charcoal Grate
- Legs (3)
- Leg Caps (3)
- Assembly Hardware (screws, nuts, washers)



Image: Components of the Expert Grill Portable Charcoal Grill, including the bowl, lid, grates, and legs, prior to assembly.

Setup

The Expert Grill Portable Charcoal Grill is designed for easy assembly. Follow these steps:

1. **Attach Legs:** Securely attach the three legs to the grill body using the provided hardware. Ensure they are firmly tightened for stability.
2. **Insert Charcoal Grate:** Place the smaller charcoal grate at the bottom of the grill bowl. This grate holds the charcoal.
3. **Place Cooking Grate:** Position the larger cooking grate above the charcoal grate. This is where food will be placed.
4. **Attach Lid Handle:** If not pre-attached, secure the handle to the lid using the provided hardware.
5. **Add Leg Caps:** Place the protective caps on the bottom of each leg.



Image: A side view of the assembled grill, highlighting the sturdy leg structure.

Operating Instructions

1. Preparing the Grill

- Place the grill on a stable, heat-resistant surface away from flammable materials.
- Open the air vent on the side of the grill body to allow for airflow.
- Arrange charcoal briquettes or lump charcoal on the charcoal grate. Do not overfill.

2. Lighting the Charcoal

- Use a charcoal chimney starter or approved charcoal lighter fluid (follow lighter fluid instructions carefully).
- Allow charcoal to burn until covered with a light gray ash (approximately 15-20 minutes).

3. Grilling

- Once charcoal is ready, carefully place the cooking grate onto the grill.
- Place food on the cooking grate.
- Use the lid to control heat and smoke. Closing the lid helps retain heat and cook food more evenly.
- Adjust the side air vent to control temperature: open for more heat, close for less heat.



Image: The portable grill in use, with various foods such as corn, peppers, and burgers cooking on the grate.

4. After Grilling

- Close all air vents to extinguish the charcoal.
- Allow the grill to cool completely before handling or cleaning.

Maintenance

Cleaning

- **Cooking Grate:** After each use, once cooled, scrape off any food residue with a grill brush. Wash with warm, soapy water and rinse thoroughly.
- **Grill Body and Lid:** Wipe down with a damp cloth and mild detergent. Avoid abrasive cleaners that can damage the finish.
- **Ash Removal:** Once the grill is completely cool, remove the charcoal grate and dispose of cooled ashes safely.

Storage

- Store the grill in a dry, covered area to protect it from the elements.
- Ensure the grill is clean and dry before storing to prevent rust.



Image: An overhead view of the grill's interior, showing the cooking grate and the charcoal grate below it, ready for use or cleaning.

Troubleshooting

Problem	Possible Cause	Solution
Charcoal not staying lit / Smothers out	Insufficient airflow; too much ash buildup; charcoal too dense.	Ensure air vent is fully open. Clear any ash from below the charcoal grate. Use less charcoal or arrange it to allow for better airflow.
Grill unstable	Legs not properly tightened or placed on uneven surface.	Check that all leg screws are tightened. Move grill to a flat, stable surface.
Food sticking to grate	Grate not properly seasoned or cleaned; not hot enough.	Clean grate thoroughly. Lightly oil the cooking grate before placing food. Ensure grill is preheated to desired temperature.



Image: A detailed view of the side air vent on the grill body, which controls airflow to the charcoal.

Specifications

Feature	Detail
Brand	Expert Grill
Model Number	841765101317
Product Dimensions (D x W x H)	14.5"D x 14.5"W x 18.1"H
Item Weight	5.54 pounds
Fuel Type	Charcoal
Material	Porcelain, Stainless Steel, Steel
Assembly Required	Yes
Number of Racks	1
Special Feature	Portable



Image: The portable grill with its key dimensions (height, width, depth) indicated.

Warranty and Support

Specific warranty details for the Expert Grill Portable Charcoal Grill are not provided within this manual. For information regarding warranty coverage, product support, or to purchase replacement parts, please contact Expert Grill customer service directly or visit their official website.
Please retain your proof of purchase for any warranty claims.

Product Video

No official product videos from the seller are available for embedding in this manual. Please refer to the product images and instructions for visual guidance.

© 2023 Expert Grill. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question