**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Victrola Highland

# Victrola Highland 4-in-1 Bluetooth Record Player

Model: VTA-330B-FNT

User Instruction Manual

## 1. Important Safety Instructions

Please read and understand all safety instructions before using this product. Keep these instructions for future reference.

- **Power Source:** Use only the specified power adapter. Ensure the voltage matches the requirements of the unit.
- **Water and Moisture:** Do not expose the unit to rain, moisture, or dripping/splashing liquids. Do not place objects filled with liquids, such as vases, on the unit.
- **Ventilation:** Ensure proper ventilation. Do not block any ventilation openings.
- **Heat:** Do not place near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Clean only with a dry cloth.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **Placement:** Place the unit on a stable, flat surface to prevent damage from falling.

## 2. Package Contents

Verify that all items listed below are included in your package:

- Victrola Highland 4-in-1 Bluetooth Record Player
- Power Adaptor
- Instruction Manual
- RCA Line Output Cable

## 3. Product Overview

The Victrola Highland 4-in-1 Bluetooth Record Player combines vintage aesthetics with modern audio capabilities. It features a 3-speed belt-driven turntable, Bluetooth connectivity, an FM radio, and a 3.5mm auxiliary input.




Image: Front view of the Victrola Highland record player with the lid open, showing the turntable platter and tonearm. The front panel features a fabric grille and a circular FM radio tuner with gold accents.

## Key Components:

- **Turntable Platter:** Supports the vinyl record.
- **Tonearm:** Holds the stylus (needle) for playing records.
- **Speed Selector:** Allows selection of 33 1/3, 45, or 78 RPM.
- **Function Knob:** Selects between PHONO (Vinyl), AUX, FM, and Bluetooth modes.
- **Volume Knob:** Adjusts the audio output level.
- **FM Tuner Dial:** For selecting FM radio stations.
- **3.5mm AUX Input:** For connecting external audio devices.
- **Headphone Jack:** For private listening.
- **RCA Line Outputs:** For connecting to external speakers or amplifiers.

## 4. Setup

Follow these steps for initial setup of your record player:

1. **Unpack:** Carefully remove the unit from its packaging. Retain packaging for future transport or storage.
2. **Placement:** Place the record player on a flat, stable surface away from direct sunlight, heat sources, and excessive dust or vibration. Ensure adequate space for the lid to open fully.
3. **Power Connection:** Connect the power adapter to the DC IN jack on the back of the unit, then plug the adapter into a wall outlet.
4. **Remove Stylus Protector:** Gently remove the white plastic stylus protector from the needle before playing records.




Image: The Victrola Highland record player positioned on a wooden side table, demonstrating typical placement in a living space.

## 5. Operating Instructions

### 5.1 Playing Records

1. **Select Mode:** Turn the Function Knob to the PHONO position.
2. **Select Speed:** Set the Speed Selector to the appropriate speed (33 1/3, 45, or 78 RPM) for your record. For 45 RPM records, place the included 45 RPM adapter on the center spindle.
3. **Place Record:** Place a record on the turntable platter.
4. **Lift Tonearm:** Gently lift the tonearm using the cue lever.
5. **Position Tonearm:** Move the tonearm over the desired starting track of the record.
6. **Lower Tonearm:** Slowly lower the tonearm onto the record using the cue lever. The record will begin to play.

7. **Adjust Volume:** Rotate the Volume Knob to adjust the sound level.
8. **End of Play:** When the record finishes, the tonearm will automatically return to its rest position. Lift the tonearm, return it to the tonearm rest, and secure it with the clip.




Image: A detailed view of the turntable section, showing the record platter, tonearm with stylus, speed selector switch, and volume/function knobs.

### 5.2 Bluetooth Streaming

1. **Select Mode:** Turn the Function Knob to the BLUETOOTH position. The Bluetooth indicator light will flash, indicating pairing mode.
2. **Enable Bluetooth:** On your Bluetooth-enabled device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. **Pair Device:** Select "Victrola Highland" from the list of devices. Once paired, the Bluetooth indicator light will stop flashing and remain solid.
4. **Play Music:** You can now play music from your device through the record player's speakers.
5. **Adjust Volume:** Adjust the volume using the Volume Knob on the record player and/or your Bluetooth device.

### 5.3 FM Radio

1. **Select Mode:** Turn the Function Knob to the FM position.
2. **Tune Station:** Rotate the FM Tuner Dial to select your desired radio station. The LED lighting around the dial will

illuminate.

3. **Adjust Volume:** Rotate the Volume Knob to adjust the sound level.

### 5.4 Auxiliary Input

1. **Select Mode:** Turn the Function Knob to the AUX position.
2. **Connect Device:** Connect an external audio device (e.g., MP3 player, smartphone) to the 3.5mm AUX IN jack on the front of the unit using a 3.5mm audio cable (not included).
3. **Play Music:** Play audio from your connected device.
4. **Adjust Volume:** Adjust the volume using the Volume Knob on the record player and/or your connected device.

### 5.5 External Speaker Connection (RCA)

To connect the record player to external powered speakers or an amplifier:

1. **Connect RCA Cable:** Plug the RCA Line Output Cable (included) into the RCA jacks on the back of the record player. Match the red plug to the red jack (right channel) and the white plug to the white jack (left channel).
2. **Connect to External System:** Connect the other end of the RCA cable to the corresponding audio input jacks on your external amplifier or powered speakers.
3. **Power On:** Ensure your external audio system is powered on and set to the correct input.
4. **Adjust Volume:** Adjust the volume primarily through your external audio system. The record player's volume knob will still affect the output.

### 5.6 Headphone Use

For private listening, plug standard 3.5mm headphones (not included) into the HEADPHONE jack on the front of the unit. The internal speakers will be muted when headphones are connected.

## 6. Maintenance

Proper maintenance ensures the longevity and optimal performance of your record player.

### 6.1 Cleaning the Unit

- **Exterior:** Wipe the exterior surfaces with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents.
- **Dust Cover:** Keep the dust cover closed when not in use to prevent dust accumulation on the turntable.

### 6.2 Stylus Care

- **Cleaning:** Gently clean the stylus periodically with a soft brush, brushing from back to front.
- **Replacement:** The stylus has a limited lifespan (approximately 200-300 hours of play). Replace the stylus when you notice a decrease in sound quality or visible wear. Consult the manufacturer's website for replacement stylus information.




Image: A vinyl record cleaning kit, including a brush and cleaning solution, useful for maintaining records and stylus.

## 7. Troubleshooting

If you experience issues with your record player, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| No Power | Power adapter not connected or outlet not active. | Ensure power adapter is securely connected to the unit and a working wall outlet. |
| No Sound | Volume too low; incorrect function mode; headphones connected; external speakers not connected/powered. | Increase volume. Select correct function mode. Disconnect headphones. Check external speaker connections and power. |
| Record Skipping | Dirty or scratched record; dirty or worn stylus; unit not on a stable surface. | Clean record. Clean or replace stylus. Place unit on a stable, level surface. |
| Bluetooth Not Pairing | Unit not in Bluetooth mode; device too far; device already paired to another unit. | Ensure unit is in BLUETOOTH mode. Move device closer. Disconnect device from other Bluetooth units. |
| Poor Radio Reception | Weak signal. | Adjust the unit's position or orientation to improve reception. |

## 8. Specifications

| Feature | Detail |
|---|---|
| Model Name | Highland |
| Item Model Number | VTA-330B-FNT |
| Product Dimensions | 16.14 x 13.78 x 7.87 inches |
| Item Weight | 14.82 pounds |
| Brand | Victrola |
| Maximum Rotational Speed | 78 RPM |
| Motor Type | Belt-driven |
| Special Features | Bluetooth connectivity, FM radio with analog tuner, Aux-in |
| Material | Wood |
| Included Components | Manual, Power Adaptor, RCA Cable |

## 9. Warranty and Support

Victrola products are designed and manufactured to the highest quality standards. For specific warranty information, please refer to the warranty card included with your product or visit the official Victrola website.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Victrola customer service. Contact details can typically be found on the manufacturer's website or in the product packaging.

**Online Resources:** For additional support and FAQs, visit the official Victrola website:www.victrola.com

© 2025 Victrola. All rights reserved.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B07TVK9W6R**

More documents and user manuals: **https://manuals.plus/**