FavorCOOL FC-30T

FavorCOOL 3CFM 1/4HP Single Stage HVAC Vacuum Pump User Manual

Model: FC-30T

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your FavorCOOL 3CFM 1/4HP Single Stage HVAC Vacuum Pump. Please read it thoroughly before use to ensure proper function and longevity of the unit.

Safety Information

- Always wear appropriate personal protective equipment (PPE), including safety glasses and gloves, when operating or maintaining the vacuum pump.
- Ensure the pump is connected to a grounded power outlet with the correct voltage (110V/60Hz).
- Do not operate the pump without sufficient oil in the reservoir. Check the oil level before each use.
- Avoid touching hot surfaces during and immediately after operation. The pump can become hot.
- Keep the pump away from moisture and flammable materials.
- Disconnect power before performing any maintenance or repairs.
- Do not use the pump for purposes other than its intended use (HVAC evacuation, wine degassing, etc.).

Product Overview

The FavorCOOL 3CFM 1/4HP Single Stage HVAC Vacuum Pump is designed for efficient evacuation of HVAC and automotive AC systems. Key components are identified below:




Figure 1: Labeled diagram of the FavorCOOL Vacuum Pump, showing the handle, oil intake, sight glass, oil drain, fan cover, motor, and non-slip base.

The pump features a robust design with a lightweight cast aluminum structure for heat dissipation and corrosion resistance. It includes a visible oil window for easy monitoring and a non-slip base for stability.



Figure 2: Close-up view of the vacuum pump highlighting the oil reservoir sight glass for checking lubricant levels and mesh vents for efficient heat dissipation and motor protection.

Setup

1. **Add Vacuum Pump Oil:** Remove the oil fill cap and pour the provided vacuum pump oil into the reservoir until the level is between the "MIN" and "MAX" marks on the sight glass. Do not overfill.
2. **Secure Connections:** Ensure all connections to the system being evacuated are tight and leak-free. The pump features 1/4" flare intake ports.
3. **Power Connection:** Connect the pump to a standard 110V/60Hz electrical outlet.

Operating Instructions

Follow these steps for general operation of the vacuum pump:

1. Verify the oil level is correct before starting.
2. Ensure all valves on the manifold gauge set (if used) are closed.
3. Connect the vacuum pump to the system using appropriate hoses.
4. Turn on the vacuum pump using the ON/OFF switch.
5. Slowly open the manifold gauge set valves to begin evacuation.
6. Monitor the vacuum gauge until the desired vacuum level is reached (e.g., 37.5 microns or 5 Pa).
7. Once the desired vacuum is achieved, close the manifold gauge set valves, then turn off the vacuum pump.
8. Disconnect the hoses from the system.

Your browser does not support the video tag.

Video 1: An overview of the FavorCOOL 1/4 HP 3CFM Single Stage HVAC Vacuum Pump, demonstrating its features and general appearance.

Maintenance

- **Oil Level Check:** Regularly check the oil level through the sight glass. Maintain the oil level between the MIN and MAX indicators.
- **Oil Change:** Change the vacuum pump oil regularly, especially if it appears cloudy or discolored. To change oil, place a suitable container under the oil drain valve, remove the oil drain plug, and allow the old oil to drain completely. Replace the plug and refill with new vacuum pump oil through the oil intake.
- **Cleaning:** Keep the pump exterior clean and free from dust and debris to ensure proper heat dissipation.

Troubleshooting

Refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Pump does not start or hums but does not run.	Motor seized due to prolonged disuse or lack of lubrication.	1. Remove the fan cover. 2. Manually spin the fan blade. If it spins freely, the pump is likely functioning. 3. If the fan does not turn manually, remove the oil tank cover. 4. Loosen the bolts of the baffle and try manually rotating the fan. If it spins, the pump is likely functioning properly. 5. After operation is completed, assemble the pump back together.
Pump not achieving desired vacuum.	Leaks in the system, low oil level, or contaminated oil.	Check all connections for leaks. Verify oil level and quality; change oil if necessary.
Excessive noise or vibration.	Low oil level, worn components, or loose parts.	Check oil level and refill. Inspect for loose bolts or damaged components.

Your browser does not support the video tag.

Video 2: A guide on troubleshooting a vacuum pump that does not start after a period of disuse, demonstrating how to check and manually free the motor.

Specifications

Feature	Detail
Model	FC-30T
Flow Rate	3 CFM
Horsepower	1/4 HP
Voltage/Frequency	110V/60HZ
Ultimate Vacuum	37.5 microns (5 Pa)
Intake Ports	1/4" Flare
Oil Capacity	170 ml
Material	Aluminum, Copper, Glass, Plastic, Stainless Steel
Item Weight	9 Pounds
Product Dimensions	10 x 4 x 8 inches

Warranty and Support

The FavorCOOL 3CFM 1/4HP Single Stage HVAC Vacuum Pump comes with a strong 1-year warranty. For any questions, technical assistance, or warranty claims, please contact FavorCOOL's customer service. Our team is available 24/7 to provide professional support.
For further assistance, please visit the FavorCOOL Store on Amazon.

© 2026 FavorCOOL. All rights reserved.