Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Innsky 3.5L Air Fryer

Innsky 3.5L Air Fryer Instruction Manual

Model: 3.5L Air Fryer

1. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer support for assistance.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is for household use only.
- Ensure the appliance is placed on a stable, level, heat-resistant surface.
- Do not block any ventilation openings.
- The appliance is PSE certified for safety.

2. Product Overview

2.1 Components

- Main Unit
- Removable Basket Pan

- Removable Basket
- Handle
- LED Touch Display Panel
- Power Cord



Figure 2.1: Innsky 3.5L Air Fryer with its basket containing french fries, accompanied by a recipe book.



Figure 2.2: Detailed view of the removable basket and its non-stick interior, highlighting the smart design that pauses cooking when the basket is removed.

2.2 Specifications

Feature	Specification

Brand	Innsky
Model	3.5L Air Fryer
Capacity	3.5 Liters
Dimensions (D x W x H)	27.5 cm x 28 cm x 31.9 cm
Weight	4.5 kg
Color	Black/Gray
Control Method	Touch Panel
Minimum Temperature Setting	80 °C
Non-stick Coating	Yes
Dishwasher Safe (Basket/Grill Plate)	No (Hand wash recommended)
Safety Certification	PSE Certified, Overheat Protection



Figure 2.3: The 3.5L capacity air fryer with its physical dimensions indicated.

3. Setup

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Clean the basket pan and basket thoroughly with hot water, dish soap, and a non-abrasive sponge.

3. Wipe the inside and outside of the appliance with a damp cloth.
4. Place the appliance on a stable, level, heat-resistant surface, away from walls or other appliances, ensuring at least 10 cm of free space on the back and sides, and 10 cm of free space above the appliance.
5. Insert the basket pan with the basket into the main unit.
6. Plug the power cord into a grounded wall outlet.

4. Operating Instructions

4.1 Basic Operation

1. Place the food in the basket. Do not exceed the MAX fill line.
2. Slide the basket pan back into the air fryer.
3. Press the power button to turn on the appliance.
4. Select a preset function or manually set the desired temperature and time using the touch controls.
5. Press the start/pause button to begin cooking.
6. The air fryer will automatically pause when the basket is pulled out and resume when reinserted.
7. Once cooking is complete, carefully remove the basket pan and transfer the food.



Figure 4.1: The clear LED display with touch controls allows for easy selection of cooking presets and manual adjustments.

4.2 Preset Functions

The Innsky 3.5L Air Fryer features a clear LED display with various preset functions for common dishes. Simply select the icon corresponding to your food, and the appliance will automatically set the optimal temperature and time.

4.3 Temperature and Time Adjustment

- **Temperature Range:** 80°C to 200°C. Adjust using the temperature control buttons.
- **Time Range:** 0 to 60 minutes. Adjust using the time control buttons.
- The 360° high-speed air circulation technology ensures even cooking and reduces overall cooking time.



Figure 4.2: The 360° high-speed air circulation system ensures thorough and efficient cooking.

5. Cooking Guide

The Innsky 3.5L Air Fryer allows for healthy cooking without the need for excessive oil, utilizing the natural moisture and oil within the ingredients. A recipe book with 45 types of recipes is included to help you get started.

5.1 General Tips

- For best results, preheat the air fryer for 3-5 minutes before adding food.
- Shake the basket halfway through cooking for even browning, especially for smaller items like fries or nuggets.
- For crispy results, lightly brush or spray food with oil, even though it's an oil-free fryer.
- Do not overcrowd the basket; cook in batches if necessary to ensure even cooking.



Figure 5.1: The air fryer enables healthy cooking by utilizing super-heated air, allowing you to prepare fried foods without added oil.

6. Maintenance and Cleaning

Proper maintenance ensures the longevity and optimal performance of your Innsky Air Fryer.

1. Always unplug the appliance and allow it to cool completely before cleaning.

2. The basket pan and basket are designed with a non-stick fluororesin coating, making them easy to clean.
3. Clean the basket pan and basket with hot water, dish soap, and a non-abrasive sponge. Do not use metal scouring pads or abrasive cleaning materials.
4. Wipe the exterior of the appliance with a damp cloth. Do not immerse the main unit in water or any other liquid.
5. The basket and grill plate are not dishwasher safe; hand washing is recommended. The main unit is not washable.

7. Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in.	Ensure the power cord is securely plugged into a grounded outlet.
Food is not cooked evenly.	Basket is overcrowded.	Cook food in smaller batches. Shake the basket halfway through cooking.
White smoke comes from the appliance.	Grease from previous use is still in the basket.	Clean the basket pan and basket thoroughly after each use.
Appliance stops during operation.	Basket pan was removed.	Reinsert the basket pan to resume cooking. The appliance has a memory function.
Food is not crispy.	Not enough oil (for certain foods) or temperature too low.	Lightly spray or brush food with oil. Increase temperature or cooking time.

8. Warranty and Support

Innsky products are manufactured with high-quality materials and undergo rigorous quality checks. This product is covered by a standard manufacturer's warranty against defects in materials and workmanship from the date of purchase.

For warranty claims, technical support, or any questions regarding your Innsky 3.5L Air Fryer, please contact Innsky customer service through the retailer where the product was purchased or visit the official Innsky website for contact information.

Please retain your proof of purchase for warranty purposes.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07TWL86X2

More documents and user manuals: **https://manuals.plus/**