Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LIGE LG9866J

LIGE LG9866J Men's Chronograph Sport Watch User Manual

Model: LG9866J

1. Introduction

Thank you for choosing the LIGE LG9866J Men's Chronograph Sport Watch. This manual provides essential information for the proper setup, operation, maintenance, and care of your new timepiece. Please read it thoroughly to ensure optimal performance and longevity of your watch.





Image 1.1: The LIGE LG9866J Men's Chronograph Sport Watch, featuring a classic design with a white dial, silver-tone case, and a brown crocodile-patterned leather strap.

Package Contents:

- LIGE LG9866J Chronograph Watch
- Instruction Manual (this document)
- Warranty Card

2. Product Overview

Familiarize yourself with the components of your LIGE chronograph watch:



Image 2.1: A detailed diagram illustrating the various functions and controls of the LIGE chronograph watch, including the crown for time and date adjustments, pushers for chronograph operation, and the calendar window.

1. **A (Top Pusher):** Chronograph Start/Stop button.
2. **B (Crown):** Used for adjusting time and date.
3. **C (Bottom Pusher):** Chronograph Reset button.
4. **Calendar Window:** Displays the current date.
5. **Chronograph Minutes Sub-dial:** Measures elapsed minutes (typically up to 30 or 60 minutes).
6. **Chronograph Seconds Sub-dial:** Measures elapsed seconds (the main large second hand is usually for chronograph seconds).
7. **24-Hour Sub-dial:** Displays time in a 24-hour format, often synchronized with the main hour hand.

3. Initial Setup and Adjustments

3.1 Setting the Time

1. Pull the crown (B) out to the second click position.
2. Rotate the crown to move the hour and minute hands to the desired time.
3. Once the time is set, push the crown back into its normal position.

3.2 Setting the Date

1. Pull the crown (B) out to the first click position.
2. Rotate the crown clockwise or counter-clockwise (depending on the movement) to adjust the date in the calendar window.
3. Avoid setting the date between 9:00 PM and 3:00 AM, as this may interfere with the automatic date change mechanism.
4. Once the date is set, push the crown back into its normal position.

4. Operating the Chronograph Function

Your LIGE watch features a chronograph (stopwatch) function for measuring elapsed time.

1. **To Start:** Press the top pusher (A) once to start the chronograph. The large second hand and the chronograph sub-dials will begin to move.
2. **To Stop:** Press the top pusher (A) again to stop the chronograph. The elapsed time will be indicated by the chronograph second hand and the minute sub-dial.
3. **To Reset:** After stopping the chronograph, press the bottom pusher (C) to reset all chronograph hands back to their zero positions.

5. Care and Maintenance

5.1 Cleaning Your Watch

Wipe the watch case and crystal regularly with a soft, dry cloth. For the leather strap, avoid excessive moisture and harsh chemicals. If the watch is exposed to saltwater, rinse it gently with fresh water and dry thoroughly with a soft cloth (ensure the crown is pushed in completely before rinsing).

5.2 Water Resistance

Your LIGE LG9866J watch is rated for 3 ATM (30 meters) water resistance. This means it is suitable for daily use, such as accidental splashes, rain, and hand washing. **It is not suitable for showering, bathing, swimming, diving, or any water sports.** Always ensure the crown is fully pushed in to maintain water resistance.



Image 5.1: A visual summary of key features, including the 30M water resistance, luminous hands for visibility in low light, high-hardness mineral glass for durability, and the comfortable, durable leather strap.

5.3 Battery Replacement

The watch is powered by a quartz movement and requires one LR44 battery. When the watch stops or the second hand starts to skip, it indicates a low battery. Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

5.4 Leather Strap Care

Leather straps can be affected by sweat, moisture, and direct sunlight. To prolong the life of your leather strap, avoid prolonged exposure to water, direct sunlight, and harsh chemicals. Clean with a soft, damp cloth and allow it to air dry naturally.

6. Troubleshooting

Problem	Possible Cause	Solution
Watch has stopped or is running intermittently.	Low battery. Crown is pulled out.	Replace battery. Push crown fully in.
Time or date is incorrect.	Time/date not set correctly.	Refer to Section 3 to reset time and date.
Chronograph hands do not reset to zero.	Chronograph not properly reset.	Ensure chronograph is stopped, then press the bottom pusher (C) to reset. If issue persists, a service may be required.
Moisture or condensation under the crystal.	Exposure to extreme temperature changes or water ingress.	Immediately take the watch to a professional watch repair service. Avoid further exposure to water.

7. Specifications

Feature	Detail
Model Number	LG9866J
Movement Type	Quartz
Display Type	Analog
Case Material	Stainless Steel
Case Diameter	42 mm
Case Thickness	12 mm
Band Material	Genuine Leather
Band Width	22 mm
Water Resistance	3 ATM (30 Meters)
Crystal Material	Mineral Glass
Battery Type	1 x LR44 (included)
Weight	109 g

8. Warranty and Support

8.1 Limited Warranty

Your LIGE LG9866J watch comes with a limited warranty against manufacturing defects. Please refer to the included warranty card for specific terms, conditions, and duration of coverage. The warranty typically covers the watch movement, hands, and dial. It does not cover damage resulting from improper handling, accidents, normal wear and tear, or unauthorized repairs.

8.2 Customer Support

For any questions, service requests, or warranty claims, please contact your original retailer or visit the official LIGE website for support information. Ensure you have your proof of purchase and warranty card available when contacting support.

© 2026 LIGE. All rights reserved.

LIGE and the LIGE logo are trademarks of LIGE.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07TYF9CK7

More documents and user manuals: **https://manuals.plus/**