Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Glem AL966GI/FS

Glem Gas Stove AL966GI/FS User Manual

Comprehensive instructions for safe and efficient operation.

1. Introduction

This manual provides essential information for the installation, operation, and maintenance of your Glem Gas Stove AL966GI/FS. Please read these instructions carefully before using the appliance to ensure safe and optimal performance. Keep this manual for future reference.

2. Safety Information

Important: Improper installation, adjustment, alteration, service, or maintenance can cause injury or property damage. Refer to this manual. For assistance or additional information, consult a qualified installer, service agency, or the gas supplier.

- Ensure adequate ventilation in the kitchen area.
- Do not store flammable materials near the appliance.
- Keep children away from the appliance during operation.
- Always use oven mitts when handling hot items.
- Do not use water on grease fires. Smother the fire or use a dry chemical or foam-type extinguisher.
- If you smell gas, immediately turn off the gas supply, open windows, and do not operate any electrical switches. Contact emergency services.

3. Product Overview

The Glem Gas Stove AL966GI/FS is a freestanding cooking appliance featuring multiple cooking zones and a spacious oven. It is designed for household use.



Figure 3.1: Front view of the Glem Gas Stove AL966GI/FS, showcasing the oven door and control panel.

Key Features:

- **Cooking Zones:** 4 gas burners and 2 electric hobs.
- **Oven Capacity:** 122 liters.
- **Oven Interior:** Coated with titanium for easy cleaning.
- **Controls:** Knob-type controls for precise temperature and flame adjustment.
- **Construction:** Durable silver finish.
- **Dimensions:** Height 90 cm, Width 90 cm, Depth 60 cm.
- **Weight:** 49.8 kg.

4. Setup and Installation

The Glem Gas Stove AL966GI/FS is a freestanding appliance. Installation should be performed by a qualified technician in accordance with local regulations and gas/electrical codes.

4.1 Unpacking

- Carefully remove all packaging materials.
- Inspect the appliance for any damage incurred during transit. Report any damage to your retailer immediately.
- Remove any protective films or stickers from the surfaces.

4.2 Positioning

- Place the stove on a level, stable surface.
- Ensure adequate clearance from adjacent walls and cabinets as specified by local building codes.
- The appliance requires a 220-240V, 60 Hz electrical supply.
- Ensure proper gas line connection by a certified professional.

5. Operating Instructions

5.1 Using the Gas Burners and Electric Hobs



Figure 5.1: Top view of the cooking surface, showing the four gas burners and two electric hobs, along with the control knobs.

1. Place appropriate cookware on the desired burner/hob.
2. For gas burners, push in and turn the corresponding control knob counter-clockwise to the ignition position. Hold for a few seconds until the flame ignites. Adjust the flame size as needed.
3. For electric hobs, turn the corresponding control knob to the desired heat setting. The hob will heat up gradually.
4. After cooking, turn the control knob to the "OFF" position. Ensure gas flames are extinguished and electric hobs are cool before cleaning.

5.2 Using the Oven



Figure 5.2: Interior view of the oven, showing the racks and the bottom storage/broiler drawer.

1. Open the oven door and place food on the appropriate rack level.
2. Close the oven door.
3. Turn the oven control knob to the desired temperature. Allow the oven to preheat to the set temperature.
4. Monitor cooking progress through the oven door window.
5. When cooking is complete, turn the oven control knob to the "OFF" position.
6. Use oven mitts to carefully remove hot food from the oven.

6. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Glem Gas Stove.

- **Before Cleaning:** Always ensure the appliance is switched off and completely cool. Disconnect from the power supply if

possible.

- **Exterior Surfaces:** Wipe with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners or scouring pads.
- **Gas Burners:** Remove burner caps and grates. Clean with warm soapy water. Ensure they are completely dry before reassembling.
- **Electric Hobs:** Wipe with a damp cloth. For stubborn stains, use a non-abrasive hob cleaner.
- **Oven Interior:** The titanium-coated oven interior is designed for easy cleaning. Wipe spills immediately after the oven cools. For deeper cleaning, use oven cleaners specifically designed for self-cleaning or titanium-coated ovens, following the product instructions.
- **Oven Door:** Clean the glass with a glass cleaner.

7. Troubleshooting

Before contacting service, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Gas burner not igniting.	Gas supply off, burner cap/base wet or clogged, igniter faulty.	Check gas supply. Clean and dry burner components. Contact service if igniter is faulty.
Electric hob not heating.	No power, control knob not set correctly, element faulty.	Check power supply. Ensure knob is on a heat setting. Contact service if element is faulty.
Oven not heating.	No power, oven control not set, gas supply off (for gas oven), element faulty (for electric oven).	Check power/gas supply. Ensure oven control is set to a temperature. Contact service if element/igniter is faulty.
Unusual odor during first use.	Residual manufacturing oils burning off.	This is normal. Ensure good ventilation. The odor will dissipate.

If the problem persists after attempting these solutions, please contact Glem customer support or a qualified service technician.

8. Specifications

Feature	Detail
Model Number	AL966GI/FS
Brand	Glem
Type	Freestanding Gas Stove with Electric Hobs and Oven
Cooking Zones	4 Gas Burners, 2 Electric Hobs
Oven Capacity	122 Liters
Oven Interior Material	Titanium Coated
Color	Silver
Dimensions (H x W x D)	90 cm x 90 cm x 60 cm

Feature	Detail
Weight	49.8 kg
Voltage	220-240V AC
Frequency	60 Hz
Control Type	Knob
Installation Type	Freestanding

9. Warranty and Support

For warranty information, technical support, or to schedule service, please contact Glem customer service. Refer to your purchase documentation for specific warranty terms and contact details.

Glem Customer Service: Please visit the official Glem website or refer to the contact information provided with your appliance at the time of purchase.

© 2023 Glem. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07V1MZS7Y

More documents and user manuals: **https://manuals.plus/**