Thomas Sabo 1798-051-14

Thomas Sabo White Zirconia Anchor Charm

Model: 1798-051-14

Introduction

This manual provides instructions for the proper handling, attachment, maintenance, and care of your Thomas Sabo White Zirconia Anchor Charm, model 1798-051-14. Please read these instructions carefully to ensure the longevity and appearance of your charm.

Setup: Attaching the Charm

The Thomas Sabo Anchor Charm is designed with a lobster clasp for secure attachment to compatible charm bracelets or necklaces. Follow these steps to attach your charm:

1. **Identify the Attachment Point:** Locate an open link or designated charm holder on your Thomas Sabo bracelet or necklace.
2. **Open the Lobster Clasp:** Gently press the small lever on the side of the lobster clasp to open the mechanism.
3. **Attach the Charm:** While the clasp is open, hook it onto the desired link or charm holder.
4. **Secure the Clasp:** Release the lever to allow the clasp to close automatically, ensuring it is fully closed and secure. Gently tug on the charm to confirm it is firmly attached.



This image displays the Thomas Sabo White Zirconia Anchor Charm. It features a detailed anchor design adorned with white zirconia stones, attached to a lobster clasp for secure fastening to a bracelet or necklace.

Operating: Wearing and Handling

Once attached, the charm is ready to be worn. To ensure its longevity and prevent damage:

- **Avoid Snagging:** The anchor design, while robust, can catch on clothing or other items. Exercise caution during activities that might cause snagging.
- **Regular Inspection:** Periodically check the lobster clasp to ensure it remains securely closed. If the clasp feels loose or stiff, refer to the troubleshooting section.
- **Remove Before Activities:** It is advisable to remove the charm before engaging in strenuous activities, swimming, or showering to prevent potential damage or loss.

Maintenance: Cleaning and Care

Proper care will help maintain the charm's appearance:

- **Gentle Cleaning:** Clean the charm using a soft, lint-free cloth. For deeper cleaning, use a mild jewelry cleaner specifically designed for sterling silver and zirconia, following the product's instructions.
- **Avoid Harsh Chemicals:** Do not expose the charm to harsh chemicals, perfumes, hairsprays, or cosmetics, as these can dull the finish or damage the zirconia stones.
- **Storage:** When not in use, store the charm in a dry, airtight container or a soft pouch to prevent tarnishing and scratches. Keep it separate from other jewelry items that might cause abrasion.

Troubleshooting

If you encounter issues with your charm, consider the following:

- **Clasp Stiffness:** If the lobster clasp is stiff, ensure it is clean and free of debris. A very small amount of silicone-based lubricant (jewelry-safe) can be applied, but consult a professional if unsure. Avoid forcing the clasp.
- **Clasp Not Closing Securely:** Inspect the clasp mechanism for any visible damage or deformation. If the spring mechanism is faulty or the gap remains open, the charm may be at risk of falling off. In such cases, professional repair or replacement may be necessary.
- **Dull Appearance:** If the charm appears dull, it may be due to tarnish or residue buildup. Follow the cleaning instructions in the Maintenance section.

Specifications

Feature	Detail
Model Number	1798-051-14
Clasp Type	Lobster Clasp
Item Type	Charm
Color	Silver, White
Subject Character	Anchor
Item Shape	Circle (referring to the loop)
Stone Color	Silver (referring to zirconia)
Stone Shape	Anchor (referring to overall design)
Charm Design	Anchor
Item Weight	1.16 Grams
Metal Stamp	0.925 (Sterling Silver)
Attachment Options	Lobster Clasp
Compatibility	Thomas Sabo charm bracelets
Package Dimensions	3.94 x 2.36 x 0.39 inches

Care and Handling

To preserve the quality and appearance of your Thomas Sabo charm, handle it with care. Avoid dropping it or subjecting it to hard impacts. Regular cleaning and proper storage will help maintain its shine and prevent damage to the zirconia stones and metal.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question