JVC LT40N555

JVC 40 Inch Full HD LED TV - LT40N555 User Manual

Model: LT40N555

1. Introduction

Thank you for purchasing the JVC 40 Inch Full HD LED TV, model LT40N555. This television is designed to provide a high-quality viewing experience with its Full HD resolution and optimized picture and sound reproduction. This manual provides essential information for the safe and efficient use of your new television, including setup, operation, maintenance, and troubleshooting.

Please read this manual thoroughly before operating the TV and retain it for future reference.

2. Safety Information

General Safety Precautions

- Do not block ventilation openings. Ensure adequate space around the TV for proper airflow.
- Do not place the TV on an unstable cart, stand, tripod, bracket, or table.
- Do not expose the TV to rain or moisture to prevent fire or electric shock.
- Keep the TV away from direct sunlight, heat sources, and extreme temperatures.
- Do not place objects containing liquids, such as vases, on the TV.
- Do not open the TV casing. Refer all servicing to qualified service personnel.

Electrical Safety

- Ensure the power cord is not walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the TV.
- Unplug the TV during lightning storms or when unused for long periods.
- Do not overload wall outlets or extension cords.

3. Package Contents

Please check that all the following items are included in your package:

- JVC 40 Inch Full HD LED TV (LT40N555)

- TV Stand
- Remote Control (batteries not included)
- Power Cord
- User Manual (this document)

4. Setup

4.1 Unpacking

Carefully remove the TV from its packaging. It is recommended to keep the original packaging materials for future transport or servicing needs.

4.2 Stand Installation

To install the included stand:

1. Place the TV face down on a soft, clean surface to prevent screen damage.
2. Align the stand with the mounting holes on the bottom of the TV.
3. Secure the stand using the provided screws. Ensure the stand is firmly attached before placing the TV upright.

4.3 Connecting Devices

Your JVC TV offers various connectivity options. Refer to the image below for port locations and connect your external devices.



This image shows the front view of the JVC 40 Inch Full HD LED TV, model LT40N555, with its screen displaying a vibrant image of a wooden boat on calm, green water. The TV features a slim black bezel and two silver-colored stand feet at the bottom.

- **HDMI Inputs (x2):** Connect Blu-ray players, game consoles, cable/satellite boxes, or other HDMI-enabled devices.
- **USB Inputs (x2):** Connect USB storage devices to view photos, videos, or listen to music.
- **VGA Input (x1):** Connect a computer for use as a monitor.
- **PC Audio Input (x1):** For audio when using the VGA input.
- **AV Input (Composite) (x1):** Connect older devices using RCA cables (yellow, white, red).

5. Operating Instructions

5.1 Basic Operation

- **Power On/Off:** Press the power button on the remote control or on the TV.
- **Volume Control:** Use the VOL +/- buttons on the remote.
- **Channel Selection:** Use the CH +/- buttons or number buttons on the remote.

5.2 Input Selection

To switch between connected devices, press the 'Source' or 'Input' button on your remote control. A menu will appear on screen, allowing you to select from HDMI1, HDMI2, USB1, USB2, AV, PC, or VGA.

5.3 Picture Settings

Access the 'Picture' menu to adjust settings such as:

- **Picture Mode:** Standard, Dynamic, Movie, User.
- **Brightness:** Adjust the overall lightness or darkness of the image.
- **Contrast:** Adjust the difference between the brightest and darkest parts of the image.
- **Color:** Adjust the intensity of colors.
- **Sharpness:** Adjust the clarity of image edges.

5.4 Sound Settings

Access the 'Sound' menu to adjust settings such as:

- **Sound Mode:** Standard, Music, Movie, User.
- **Equalizer:** Adjust specific frequency bands.
- **Balance:** Adjust the sound output between left and right speakers.

6. Maintenance

6.1 Cleaning the TV

- Always unplug the TV before cleaning.
- Use a soft, dry cloth to wipe the screen and cabinet.
- For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive cleaner specifically designed for electronics.
- Never spray cleaner directly onto the screen or cabinet.

6.2 Storage

If you need to store the TV for an extended period, it is recommended to use the original packaging to protect it from dust and physical damage. Store in a cool, dry place.

7. Troubleshooting

Before contacting customer support, please refer to the following common issues and solutions:

Problem	Possible Solution
No power	Check if the power cord is securely plugged into the TV and the wall outlet. Try a different outlet.
No picture, but sound is present	Ensure the correct input source is selected. Check cable connections to external devices.

Problem	Possible Solution
No sound, but picture is present	Check the volume level and ensure the TV is not muted. Check audio cable connections.
Remote control not working	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.

8. Specifications

Key technical specifications for the JVC 40 Inch Full HD LED TV (LT40N555):

- **Model Name:** LT40N555
- **Screen Size:** 40 Inches (102 cm visible diagonal)
- **Display Technology:** LED
- **Resolution:** Full HD (1920 x 1080)
- **Aspect Ratio:** 16:9
- **Refresh Rate:** 120 Hz
- **Contrast:** 5000:1
- **Brightness:** 300 cd/m2
- **Connectivity:** 2 x HDMI, 2 x USB, 1 x VGA, 1 x PC Audio, 1 x AV (Composite)
- **Special Features:** Flat Panel Design
- **Included Components:** TV, Stand

9. Warranty and Support

For warranty information, please refer to the warranty card included with your product or contact your local JVC authorized dealer. For technical support or service inquiries, please visit the official JVC website or contact their customer service department.

© 2023 JVC. All rights reserved.