Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Wifehelper Wifehelper8mzpxt70y2

Wifehelper Universal Stainless Steel Bread Paddle Instruction Manual

Model: Wifehelper8mzpxt70y2

Introduction

Thank you for choosing the Wifehelper Universal Stainless Steel Bread Paddle. This replacement blade is designed for various bread machines, offering durability and efficient dough mixing. Made from high-quality, food-grade stainless steel, it is built for long-lasting performance. Please read this manual carefully before use to ensure proper installation and operation.

Safety Information

- Always unplug your bread machine before installing or removing the bread paddle.
- Ensure the bread paddle is securely attached before operating the bread machine.
- Keep out of reach of children.
- Handle with care; edges may be sharp.
- Do not use if the paddle is damaged or bent.

Product Overview

The Wifehelper bread paddle is a universal replacement part for bread makers. Its anti-stick design ensures easy cleaning and efficient dough kneading.



Image: The Wifehelper bread paddle, showing its dimensions (65mm/2.55in length, 38mm/1.49in height). This image illustrates the physical size and shape of the replacement part.



Image: A close-up view of the Wifehelper bread paddle, highlighting its textured surface and the shaft connection point. This image provides a detailed look at the paddle's construction.

Setup

1. **Unpack:** Carefully remove the bread paddle from its packaging.
2. **Inspect:** Check the paddle for any signs of damage or manufacturing defects. If damaged, do not use and contact customer support.
3. **Clean:** Before first use, wash the bread paddle with warm, soapy water and dry thoroughly.

Operating Instructions

Installation

1. **Ensure Safety:** Always unplug your bread machine from the power outlet before installation.
2. **Remove Old Paddle (if applicable):** If replacing an existing paddle, carefully remove it from the bread pan shaft.
3. **Insert New Paddle:** Align the opening at the base of the Wifehelper bread paddle with the shaft inside your bread machine's pan. Push down firmly until it clicks into place and feels secure.
4. **Verify Security:** Gently tug on the paddle to ensure it is properly seated and will not detach during operation.

[redacted]

Video: This video demonstrates the handling and inspection of a bread machine paddle. It shows how to hold and examine the paddle, ensuring it is ready for installation. (Source: Lisopiu)

[redacted]

Video: A short demonstration of the bread paddle's design and material. It highlights the paddle's structure and its suitability for bread making. (Source: Bewinner151)

Usage

Once installed, the bread paddle will automatically knead the dough according to your bread machine's selected program. Its anti-stick coating helps prevent dough from adhering excessively, ensuring smooth operation.



Image: The bread paddle shown alongside raw dough and various types of baked bread. This illustrates the paddle's function in the bread-making process, from kneading to the final product.



Image: A close-up of the bread paddle with hands kneading dough in the background. This visual emphasizes the paddle's role in the kneading process, suggesting its effectiveness.

Maintenance and Cleaning

1. **After Each Use:** After the bread machine has cooled down, remove the bread paddle from the pan.
2. **Cleaning:** Wash the paddle immediately with warm, soapy water. The anti-stick surface makes cleaning easy. Use a soft sponge or cloth to avoid scratching the coating.
3. **Stubborn Residue:** If dough is stuck, soak the paddle in warm water for a few minutes before cleaning. Do not use abrasive cleaners or metal scouring pads.
4. **Drying:** Dry the paddle thoroughly before storing to prevent water spots or corrosion.
5. **Storage:** Store the paddle in a dry place.

Care Instruction from Manufacturer: Clean with a dry cloth.

Troubleshooting

Problem	Possible Cause	Solution
Paddle not mixing dough effectively.	Paddle not properly installed or damaged.	Ensure paddle is securely seated on the shaft. Inspect for damage and replace if necessary.
Dough sticking to the paddle.	Excessive use without cleaning, or damaged anti-stick coating.	Clean paddle thoroughly after each use. If coating is damaged, consider replacement.
Paddle detaches during kneading.	Improper installation or worn shaft/paddle connection.	Re-install paddle, ensuring it clicks into place. If issue persists, the shaft or paddle may be worn and require replacement.

Specifications

Brand:	Wifehelper
Model Number:	Wifehelper8mzpxt70y2
Material:	Stainless Steel
Color:	Black
Product Dimensions:	12 x 7 x 4 cm (approximately 65mm length, 38mm height)
Item Weight:	18.1 g
UPC:	743562025813

Warranty and Support

The manufacturer, Wifehelper, offers a 100% customer satisfaction guarantee. For any issues or concerns, please contact the seller or manufacturer directly for a full refund or replacement. Refer to your purchase documentation for specific contact details.

© 2024 Wifehelper. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07V36617X

More documents and user manuals: **https://manuals.plus/**