Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Akai Professional AKBT150

AKAI AKBT150 COLOR MUSIC Wireless Bluetooth Speaker User Manual

Model: AKBT150

Product Overview

The AKAI AKBT150 COLOR MUSIC Wireless Bluetooth Speaker is a portable audio device designed for wireless music playback. It features Bluetooth connectivity, integrated LED lights with six different color tones, and a compact design, making it suitable for various environments. This manual provides essential information for setting up, operating, and maintaining your speaker.



Image: Front view of the AKAI AKBT150 COLOR MUSIC Wireless Bluetooth Speaker. The speaker is white with a black speaker grille and features a compact, cube-like design with rounded edges. The top panel shows control buttons.

What's in the Box

- AKAI AKBT150 Speaker
- USB Cable
- AUX Cable
- User Manual (this document)

Setup

Charging the Speaker

1. Locate the Micro USB port on the speaker.
2. Connect one end of the provided USB cable to the speaker's Micro USB port.
3. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer's USB port.
4. The charging indicator light (if present) will illuminate, typically red, during charging and turn off or change color when fully charged.
5. Allow approximately 2-4 hours for a full charge.

Initial Power On

- Press and hold the Power button (usually marked with a power symbol) on the speaker for a few seconds until you hear an audible prompt or see an indicator light.

Operating Instructions

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode. The speaker will typically indicate this with a flashing blue LED light or an audible prompt.
2. On your mobile device (smartphone, tablet, laptop), navigate to the Bluetooth settings.
3. Enable Bluetooth and search for available devices.
4. Select "AKBT150" from the list of found devices.
5. Once paired, the speaker will confirm with an audible sound, and the Bluetooth indicator light will typically become solid blue.
6. You can now play audio from your device through the AKAI AKBT150 speaker. The maximum communication range is approximately 8 meters (26 feet).

Using AUX Input

- Connect one end of the provided AUX cable to the speaker's AUX-in port.
- Connect the other end of the AUX cable to the headphone jack or audio output of your audio source (e.g., MP3 player, computer).
- The speaker will automatically switch to AUX mode or may require a mode button press.

Controlling LED Lights

The speaker features 6 different color tones for its LED lights. Refer to the speaker's physical buttons for light control. Typically, a dedicated button or a long press of a specific button (e.g., Play/Pause) cycles through light modes or turns them on/off.

Basic Controls

- **Power On/Off:** Press and hold the Power button.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Play/Pause:** Press the Play/Pause button.
- **Next Track:** Press and hold the '+' button (or a dedicated next track button).
- **Previous Track:** Press and hold the '-' button (or a dedicated previous track button).

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners, waxes, or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the speaker regularly, even if not in constant use.
- **Water Exposure:** This speaker is not waterproof. Avoid exposing it to water or high humidity.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker using the provided USB cable.
No sound from speaker.	Volume is too low or muted. Device not paired correctly (Bluetooth). AUX cable not fully inserted.	Increase volume on both speaker and connected device. Re-pair the Bluetooth device. Ensure AUX cable is securely connected.
Bluetooth connection unstable or drops.	Device is out of range. Interference from other devices.	Move the connected device closer to the speaker (within 8 meters). Move speaker away from other wireless devices.
LED lights not working.	Lights are turned off. Speaker malfunction.	Press the dedicated light control button or cycle through modes. Contact customer support if issue persists.

Specifications

Brand	Akai Professional
Model	AKBT150
Speaker Power Output	3W
Battery Type	Rechargeable Lithium Battery 3.7V 1200 mAh
Usage Time	2-4 Hours
Charging Voltage	DC 5V
Frequency Band	2.4 GHz
Connectivity	Bluetooth, Micro USB (charging/input), AUX In

Max Communication Range	8 meters (approx. 26 feet)
Color	White
Dimensions (Product)	127 x 128 x 120 mm (approx. 5 x 5 x 4.7 inches)
Weight	1 kg (approx. 2.2 lbs)
Compatible Devices	MP3 Player, Game Console, Karaoke System, Smartphone, Laptop, Television, Projector, Desktop Computer, Tablet, Home Theater
Additional Features	Bluetooth Connection, LED Lights (6 color tones)

Warranty and Support

The AKAI AKBT150 speaker comes with a limited warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Akai Professional website.
For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Akai Professional customer service. Contact information can typically be found on the product packaging or the official brand website:

Visit Akai Professional Official Website

© 2023 Akai Professional. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07V4S5FN1

More documents and user manuals: **https://manuals.plus/**