Noma B07VBB6HTX

Noma C9 LED Quick Clip Christmas Lights Instruction Manual

Model: B07VBB6HTX
Brand: Noma

1. Introduction

Welcome to your Noma C9 LED Quick Clip Christmas Lights. This manual provides essential information for the safe and efficient use of your new lighting product. Please read these instructions carefully before installation and retain for future reference.

These 16-foot string lights feature 24 pure white and blue LED bulbs with built-in spring-loaded clips for easy installation. Designed for outdoor use, they offer end-to-end connectivity, allowing multiple strands to be linked.

2. Important Safety Information

Always follow basic safety precautions when using electrical products to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before use.
- Do not install near gas or electric heaters.
- Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- Do not let lamps rest on the supply cord or on any wire.
- Disconnect the product from power when leaving the house, when retiring for the night, or if left unattended.
- This is an electrical product, not a toy! To avoid risk of fire, burns, personal injury and electric shock, it should not be played with or placed where small children can reach it.
- Do not use this product for other than its intended use.
- Do not hang ornaments or other objects from cord, wire, or light string.
- Do not cover the product with cloth, paper, or any material not part of the product when in use.

- Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- This product is equipped with push-in type lamps. Do not twist lamps.
- This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless the plug can be fully inserted. Do not alter the plug.
- This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit condition. If the fuse blows, unplug the product from the outlet. Also unplug any additional strings or products that may be attached. Replace the fuse as per the instructions.
- For outdoor use, connect the product to a Ground Fault Circuit Interrupter (GFCI) protected outlet. If one is not provided, contact a qualified electrician for proper installation.

3. Package Contents

Your Noma C9 LED Quick Clip Christmas Lights package includes:

- 1 x 16-foot string of C9 LED lights with 24 pure white and blue bulbs
- Built-in spring-loaded clips (pre-attached)
- Re-usable storage container

4. Setup and Installation

Follow these steps for easy installation of your Noma C9 LED Quick Clip Christmas Lights.

1. **Unpack the Lights:** Carefully remove the light strand from its reusable storage container. Ensure the cord is untangled.
2. **Inspect for Damage:** Before plugging in, visually inspect the entire light strand, bulbs, and clips for any signs of damage. Do not use if damaged.
3. **Plan Your Display:** Determine where you want to hang the lights. The built-in clips are designed for easy attachment to branches, rooflines, railings, and gutters.
4. **Attach the Lights:**
    - Position a light bulb where desired.
    - Press the spring-loaded clip to open it.
    - Securely attach the clip to the desired surface (e.g., gutter edge, tree branch, railing).



Image: A hand demonstrating how to open the spring-loaded clip on a C9 LED light bulb to attach it to a surface. This clip design allows for quick and easy installation.

5. **Adjust Light Position:** The clips feature 180-degree rotation, allowing you to adjust the direction of each light bulb for optimal display.



Image: A diagram illustrating the 180-degree rotation feature of the light clips, enabling flexible light positioning.

6. **Connect Multiple Strands (Optional):** Each 16-foot strand has plug-ins at both ends. You can link up to 90 strands (totaling 2,160 lights) end-to-end. Ensure the total wattage does not exceed 216 Watts.
7. **Secure Connections:** Ensure all connections are tight and protected from moisture, especially for outdoor use.
8. **Power Connection:** Plug the light strand into a suitable electrical outlet. For outdoor use, always use a GFCI-protected outlet.



Image: Noma C9 LED Quick Clip Christmas Lights securely installed along a snowy roofline, showcasing the alternating blue and pure white bulbs.

5. Operating Instructions

Once installed and plugged into a power source, your Noma C9 LED Quick Clip Christmas Lights will illuminate.

- **Power On/Off:** The lights are controlled by plugging and unplugging them from the power outlet. For convenience, you may use an outdoor-rated timer (sold separately).
- **Energy Efficiency:** These LED bulbs are energy-efficient and remain cool to the touch during operation, reducing power usage compared to traditional incandescent lights.
- **Weather Resistance:** The durable acrylic resin, drain-holes, and weather-sealed sockets are designed to withstand various weather conditions.

6. Care and Maintenance

Proper care and maintenance will extend the lifespan of your Noma C9 LED Quick Clip Christmas Lights.

- **Cleaning:** Disconnect from power before cleaning. Wipe bulbs and cords with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Bulb Replacement:** These are LED bulbs and are generally not user-replaceable. If a bulb fails, the entire strand may need to be replaced or serviced by a qualified technician.
- **Fuse Replacement:** If the entire strand goes out, check the fuse in the plug.
  - Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
  - Open fuse cover. Slide open the fuse access cover on top of the attachment plug towards the blades.
  - Remove fuse carefully.
  - Replace fuse only with 3 Amp, 125 Volt fuse (provided with product).
  - Close fuse cover. Slide closed the fuse access cover on top of the attachment plug.
- **Storage:** When not in use, store the lights in their original reusable packaging in a cool, dry place, away from direct sunlight and extreme temperatures.



Image: The Noma C9 LED Quick Clip Christmas Lights neatly stored in their clear, reusable plastic container, designed for convenient off-season storage.

7. Troubleshooting

If your Noma C9 LED Quick Clip Christmas Lights are not functioning as expected, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Lights do not turn on.	No power to the outlet. Blown fuse in the plug. Loose connection.	Check if the outlet is working. Replace the fuse as per Maintenance section. Ensure all plugs are fully inserted.
Only part of the strand is lit.	Damaged bulb or wiring section.	Inspect the unlit section for visible damage. If a section is out, the entire strand may need replacement.
Lights flicker.	Loose connection or faulty bulb.	Ensure all connections are secure. If flickering persists, the strand may be faulty.
Clips do not hold securely.	Improper attachment or surface too thick/thin.	Ensure the clip is fully engaged with the surface. Adjust the position or choose a more suitable attachment point.
Water inside bulbs/sockets.	Improper installation or extreme weather.	Disconnect from power immediately. Allow to dry completely. Ensure drain-holes are clear. If damage persists, discontinue use.
Lights are too dim.	Expected brightness for LED C9 bulbs.	The brightness is inherent to the product design. Ensure all bulbs are clean for maximum light output.

8. Product Specifications

- **Model:** B07VBB6HTX
- **Brand:** Noma
- **Light Type:** C9 LED Quick Clip String Lights
- **Bulb Count:** 24
- **Light Color:** Pure White & Blue
- **Strand Length:** 16 feet
- **Bulb Spacing:** 8 inches (approx.)
- **Bulb Dimensions:** 1.25 inches diameter, 2.5 inches tall (approx.)
- **Connectivity:** End-to-end connectable (up to 90 strands / 2,160 lights)
- **Maximum Compatible Wattage:** 216 Watts
- **Power Source:** Corded Electric
- **Voltage:** 120 Volts
- **Wattage:** 2.4 watts (per strand)
- **Indoor/Outdoor Usage:** Outdoor
- **Special Features:** Built-in spring-loaded clips, 180-degree rotation, weather-sealed sockets, drain-holes.
- **Material:** Acrylic (bulbs), GPPS (shade)
- **Item Weight:** 2.14 pounds
- **Average Life:** 1000 Hours
- **Water Resistance Level:** Water Resistant

9. Warranty and Customer Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Noma website. Keep your purchase receipt as proof of purchase.

Manufacturer: NOMA

Website: Visit the Noma Store on Amazon (for product information)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question