Noma 1513680

Noma C9 LED Quick Clip Christmas Lights Instruction Manual

Brand: Noma | Model: 1513680

1. Introduction

This manual provides essential instructions for the safe and effective installation, operation, and maintenance of your Noma C9 LED Quick Clip Christmas Lights. Please read this manual thoroughly before use and retain it for future reference.

2. Safety Information

WARNING: To reduce the risk of fire, electric shock, or injury to persons, follow these instructions:

- Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
- This product is for seasonal installation and removal. Do not install permanently.
- Do not mount or place near gas or electric heaters, fireplaces, candles, or other similar sources of heat.
- Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- Do not let lamps rest on the supply cord or on any wire.
- Unplug the product when leaving the house, when retiring for the night, or if left unattended.
- Do not use this product for other than its intended use.
- Do not hang ornaments or other objects from cord, wire, or light string.
- Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- Do not cover the product with cloth, paper, or any material not part of the product when in use.
- Read and follow all instructions that are on the product or provided with the product.

3. Package Contents

Your Noma C9 LED Quick Clip Christmas Lights package includes:

- 1 x 16-foot light strand with 25 pre-installed pure white LED C9 bulbs and built-in Quick Clips.
- Reusable storage container.

4. Setup and Installation

The Noma C9 LED Quick Clip Christmas Lights are designed for easy installation on various surfaces.

4.1 Attaching the Lights

Each C9 bulb features a built-in spring-loaded clip for secure attachment. These clips are designed to simplify installation on branches, rooflines, and railings.



Image: A hand demonstrating the use of the built-in spring-loaded clip for quick attachment.

To attach:

1. Open the spring-loaded clip by pressing the two sides together.
2. Position the clip over the desired surface (e.g., gutter edge, tree branch, railing).
3. Release the clip to secure the light in place.



Image: Noma C9 LED lights securely clipped to a roof gutter, demonstrating outdoor installation.



Image: Noma C9 LED lights clipped onto a tree branch, showcasing versatile attachment options.

4.2 Adjusting Light Position

The patented Quick-Clip technology allows for 180-degree rotation of the bulbs. This enables you to adjust the lights to face your desired direction for optimal display.



Image: Diagram illustrating the 180-degree rotational capability of the C9 LED bulbs on their clips.

4.3 Connecting Multiple Strands

Each 16-foot strand is equipped with plug-ins at both ends, allowing for end-to-end connectivity. You can link up to 90 strands together, totaling 2,160 lights, from a single power outlet. Ensure the total wattage of connected strands does not exceed 216 Watts.

5. Operating Instructions

Once installed, plug the light strand into a standard 120V electrical outlet. The lights will illuminate. Unplug the strand from the outlet to turn the lights off.
These LED bulbs are energy-efficient and remain cool to the touch during operation.

6. Maintenance and Storage

6.1 Cleaning

To clean the lights, ensure they are unplugged from the power source. Wipe bulbs and wires with a soft, damp cloth. Do not immerse the lights in water or use harsh chemicals.

6.2 Bulb Replacement

The LED bulbs are designed for long life and are not typically user-replaceable. If a bulb fails, the entire strand should generally continue to function due to the series-parallel wiring. If a section or the entire strand fails, inspect for loose connections or damage to the wire.

6.3 Off-Season Storage

For optimal longevity, store the lights in their original compact, reusable packaging during off-seasons. This helps prevent tangling and protects the bulbs and clips from damage.



Image: The Noma C9 LED lights neatly stored in their provided reusable plastic container.

7. Troubleshooting

- **Lights do not turn on:**
  - Ensure the power plug is fully inserted into a functional electrical outlet.
  - Check if the outlet is receiving power (test with another appliance).
  - Inspect the entire length of the strand for any visible damage to the wire or bulbs.

- If connecting multiple strands, ensure the total wattage does not exceed the maximum compatible wattage (216 Watts).

- **Some bulbs are not lit:**
  - LED bulbs are designed to operate independently. If a single bulb fails, the rest of the strand should remain lit. If a section is out, check for loose connections or damage within that section.

8. Specifications

Brand	Noma
Model Number	1513680
Light Type	LED C9
Bulb Quantity	25
Light Color	Pure White
Color Temperature	13000 Kelvin
Luminous Flux	5 Lumen (per bulb)
Bulb Shape Size	C9 (1.25" diameter, 2.5" tall)
Bulb Spacing	8 inches
Strand Length	16 feet
Power Source	Corded Electric
Voltage	120 Volts
Wattage	2.4 Watts (total for 25 bulbs)
Max. Connectable Wattage	216 Watts (up to 90 strands)
Indoor/Outdoor Use	Yes, Water Resistant
Bulb Features	Not Dimmable, Energy Efficient
Average Life	1000 Hours
Material	Acrylic (bulbs)
Item Weight	2.29 pounds (1.04 kg)

9. Warranty Information

For detailed warranty information regarding your Noma C9 LED Quick Clip Christmas Lights, please refer to the manufacturer's official website or contact Noma customer service directly. Warranty terms and conditions may vary.

10. Customer Support

If you require assistance, have questions about your product, or need to report an issue, please contact Noma

customer service. You can find contact information on the official Noma website or through your retailer.
Visit the official Noma Store: Noma Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question