Rii RK907

Rii RK907 Wired USB Keyboard User Manual

Model: RK907

Introduction

Thank you for choosing the Rii RK907 Wired USB Keyboard. This manual provides detailed instructions for setting up, operating, and maintaining your keyboard to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.



Image: Top view of the Rii RK907 Wired USB Keyboard, showcasing its full layout with QWERTZ keys and multimedia function keys.

Package Contents

- Rii RK907 Wired USB Keyboard
- User Manual (this document)

Setup

System Requirements

- Operating System: Windows 98 / XP / 7 / 8 / 10 / Vista, Mac OS
- Available USB Port

Connecting the Keyboard

1. Locate an available USB port on your computer (desktop, laptop, or compatible device).
2. Insert the USB cable of the Rii RK907 keyboard into the USB port.
3. The keyboard is plug-and-play; no additional software or drivers are required. Your system should automatically recognize the device.



Image: Side view of the Rii RK907 keyboard, highlighting its slim profile and the 1.5m cable length for easy connection.

Operating Instructions

Basic Typing

The Rii RK907 features a standard 105-key layout with full-size F-keys and a numeric keypad, providing a comfortable and

efficient typing experience for daily use, whether for work or gaming.



Image: A person's hands positioned comfortably on the Rii RK907 keyboard, demonstrating its ergonomic design for smooth typing and reduced fatigue during long work sessions.

Multimedia Shortcuts

The keyboard includes 12 multimedia shortcut keys (FN+F1 to F12) for quick access to various functions. To use these shortcuts, press and hold the **FN** key, then press the desired**F-key**.

Multimedia Function Keys

Key Combination	Function
FN + F1	Media Player
FN + F2	Volume Down
FN + F3	Volume Up

Key Combination	Function
FN + F4	Mute
FN + F5	Previous Track
FN + F6	Next Track
FN + F7	Play/Pause
FN + F8	Stop
FN + F9	Home Page
FN + F10	Email
FN + F11	My Computer
FN + F12	Favorites



Image: Close-up view of the Rii RK907 keyboard's function row, illustrating the dedicated multimedia keys for convenient control of audio and system functions.

Ergonomic Design

The keyboard features a short keycap design for incredible feedback and a comfortable fit. Adjustable, foldable tilt feet allow you to maintain a more comfortable typing position, reducing hand fatigue during extended use.



Image: Underside view of the Rii RK907 keyboard, showing the foldable and adjustable tilt feet that help achieve a more comfortable typing angle.

Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to wipe the keyboard surface. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid excessive moisture.
- **Spill Resistance:** The keyboard is designed to be splash-resistant with drain holes to handle accidental spills. However, it is not waterproof. **Do not immerse the keyboard in liquid.** If a spill occurs, unplug the keyboard immediately and allow it to dry completely before reconnecting.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Durability:** The robust ABS keys are designed for up to 10 million keystrokes without wear, ensuring long-term durability.



Image: The Rii RK907 keyboard displayed with text indicating its durability and robust construction, designed for millions of keystrokes.

Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution
Keyboard not responding.	Loose USB connection, faulty USB port, system driver issue.	◦ Ensure the USB cable is securely plugged into the computer. ◦ Try plugging the keyboard into a different USB port. ◦ Restart your computer. ◦ Check Device Manager (Windows) or System Information (Mac) to see if the keyboard is recognized.

Problem	Possible Cause	Solution
Keys are sticky or unresponsive.	Dirt or debris under keys, liquid damage.	◦ Unplug the keyboard and gently shake it to dislodge debris. ◦ Use compressed air to clean between keys. ◦ If liquid damage is suspected, ensure the keyboard is completely dry before use.
Multimedia keys not working.	Incorrect key combination, software conflict.	◦ Ensure you are pressing the **FN** key simultaneously with the desired F-key. ◦ Check your operating system's settings for multimedia key conflicts.

Specifications

Feature	Detail
Model	RK907
Connectivity	Wired USB
Number of Keys	105
Key Type	ABS
Color	Black
Special Feature	Splash-resistant
Compatible Devices	PC, Laptop
Operating Systems	Windows 98 / XP / 7 / 8 / 10 / Vista, Mac OS
Cable Length	Approx. 1.5 meters
Dimensions (L x W x H)	44.5 x 14.5 x 2 cm



Image: Diagram showing the precise dimensions of the Rii RK907 keyboard, including length, width, and height.

Warranty Information

Rii products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Rii website. Keep your purchase receipt as proof of purchase for warranty claims.

Support

If you encounter any issues or have questions regarding your Rii RK907 keyboard that are not covered in this manual, please contact Rii customer support through their official website or the contact information provided with your product packaging.

For more information about Rii products, visit: www.riitek.com

© 2025 Rii. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question