Whirlpool MWP101SB

Whirlpool MWP 101 Solo Microwave Oven User Manual

Model: MWP101SB

Introduction

This manual provides comprehensive instructions for the safe and efficient operation, installation, and maintenance of your Whirlpool MWP 101 Solo Microwave Oven. Please read this manual thoroughly before using the appliance and retain it for future reference.
The Whirlpool MWP 101 SB is a 20-liter countertop solo microwave oven with 700W power, designed for reheating, cooking, and defrosting various food items.

Setup and Installation

Unpacking

Carefully remove the microwave oven and all packing materials from the carton. Check the oven for any damage, such as dents or a broken door. Do not operate the oven if it is damaged. Contact your retailer immediately.
Ensure all accessories are present:

- Glass turntable
- Turntable support ring
- Instruction manual

Placement

Place the microwave oven on a flat, stable surface that can support its weight and the heaviest food item likely to be cooked in it. Ensure adequate ventilation around the oven.

- Leave a minimum of 20 cm (8 inches) of space above the oven.
- Leave a minimum of 10 cm (4 inches) of space at the rear and sides.
- Do not block any ventilation openings.



Image: Front view of the Whirlpool MWP 101 Solo Microwave Oven, showcasing its black finish and control panel.

Electrical Connection

Plug the power cord into a properly grounded electrical outlet. Ensure the voltage and frequency match the specifications on the rating label of the oven. Do not use extension cords or adapters.

Operating Instructions

Control Panel Overview

The Whirlpool MWP 101 features two rotary knobs for control:

- **Upper Knob:** Power Level Selection (e.g., 150W, 300W, 500W, 700W, Defrost)
- **Lower Knob:** Timer Setting (up to 30 minutes)



Image: Angled view of the microwave, highlighting the control panel with its two rotary knobs for power and time settings.

Basic Microwave Cooking

1. Place the food in a microwave-safe container on the glass turntable.
2. Close the oven door securely.
3. Turn the **Upper Knob** to select the desired power level (e.g., 700W for full power).
4. Turn the **Lower Knob** to set the cooking time. The oven will start automatically.
5. When the cooking time is complete, the oven will emit an audible signal and turn off.
6. Carefully remove the food. Be aware that the container and food will be hot.



Image: The microwave oven with its door open, showing a dish of food placed on the glass turntable inside the cooking cavity.

Defrosting

The defrost function allows for quick and efficient thawing of frozen foods.

1. Place the frozen food on the glass turntable.
2. Turn the **Upper Knob** to the defrost symbol (often represented by a snowflake or specific defrost setting).
3. Turn the **Lower Knob** to set the defrosting time. Refer to food packaging for recommended defrosting times or use general guidelines.
4. During defrosting, it may be necessary to turn the food over or separate pieces to ensure even thawing.

Safety Precautions During Operation

- Do not operate the oven empty.
- Do not heat sealed containers or bottles with narrow necks, as they may explode.
- Always use microwave-safe cookware.
- Stir or shake liquids and baby bottles after heating to avoid scalding.
- Do not use the microwave for deep-frying.
- Never attempt to tamper with or repair the oven yourself.

Maintenance and Cleaning

Cleaning the Oven Interior

Regular cleaning helps maintain the oven's performance and extends its lifespan.

- **Daily Cleaning:** Wipe the interior surfaces, including the door seals and turntable, with a soft cloth dampened with mild detergent after each use.

- **Stubborn Stains:** For dried-on food spills, place a bowl of water with a few lemon slices inside the oven and heat on high for 2-3 minutes. The steam will loosen the spills, making them easier to wipe away.
- Do not use abrasive cleaners, steel wool, or harsh chemicals, as they can damage the oven's surfaces.

Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. Avoid getting water into the ventilation openings.

Turntable and Support Ring

The glass turntable and support ring can be removed for cleaning. Wash them in warm, soapy water or in a dishwasher. Ensure they are completely dry before placing them back in the oven.

Troubleshooting

If you encounter issues with your microwave oven, refer to the following table before contacting customer service.

Problem	Possible Cause	Solution
Oven does not start	• Power cord not securely plugged in. • Door not closed properly. • Fuse blown or circuit breaker tripped.	• Ensure power cord is firmly plugged into an outlet. • Close the door firmly until it latches. • Check household fuse/circuit breaker.
Food not heating	• Incorrect power level selected. • Cooking time too short. • Using non-microwave-safe cookware.	• Select a higher power level. • Increase cooking time. • Use only microwave-safe dishes.
Turntable not rotating	• Turntable or support ring not correctly placed. • Food item too large or heavy, obstructing rotation.	• Ensure turntable and ring are seated correctly. • Reduce food quantity or use a smaller dish.
Excessive steam inside oven	• High moisture content in food.	• This is normal for foods with high moisture. Wipe the interior after use.

Product Specifications

Feature	Detail
Brand	Whirlpool
Model Number	MWP101SB
Type	Solo Microwave Oven

Feature	Detail
Installation Type	Freestanding
Capacity	20 Litres
Power Output	700 Watts
Voltage	230 Volts
Control Type	Knob
Dimensions (L x W x H)	36.5 x 45.2 x 26.2 cm
Weight	12 Kilograms
Color	Black
Material	Glass (interior and exterior elements)
Noise Level	10 Decibels
Defrost Type	Manual Defrost

Warranty and Support

Specific warranty details for your Whirlpool MWP 101 Solo Microwave Oven are typically provided with your purchase documentation or can be found on the official Whirlpool website for your region. Please retain your proof of purchase for warranty claims.

For technical support, service, or to inquire about spare parts, please contact Whirlpool customer service in your country. Contact information can usually be found on the Whirlpool official website or in the documentation included with your appliance.

Note: Information regarding spare parts availability was not provided in the product data.

© 2023 Whirlpool Corporation. All rights reserved.
This manual is for informational purposes only. Whirlpool reserves the right to make changes to products without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question