Safeguard Supply SS110

Wireless Door Bell - Safeguard Supply SS110

User Manual

Introduction

The Safeguard Supply SS110 Wireless Doorbell Chime is a dependable and versatile system designed to provide a clear and loud alert for your home or business. With its long-range signal, extensive melody options, and adjustable volume, it ensures you never miss a visitor. This manual provides detailed instructions for setup, operation, and maintenance of your SS110 doorbell system.



Image: The Safeguard Supply SS110 Wireless Doorbell Chime (receiver) and its corresponding push button (transmitter).

Product Components

Your Safeguard Supply SS110 Wireless Doorbell system includes the following components:

- **Transmitter:** The wireless push button unit.
- **Receiver:** The plug-in chime unit.
- **Battery:** One CR2 battery (included) for the transmitter.
- **Manual:** This instruction manual.



Image: Detailed view of the receiver highlighting its LED light melody indicator, plug, volume control, and melody selection buttons.

Setup and Installation

The SS110 doorbell system is designed for quick and easy installation, typically taking less than a minute.

1. Transmitter (Push Button) Installation:

1. **Battery Insertion:** The transmitter comes with a CR2 battery included. Ensure it is properly inserted, observing polarity.
2. **Mounting Location:** Choose a flat, clean surface near your door where the push button will be easily accessible to visitors. Ensure the surface is free of dust and moisture for optimal adhesion.

3. **Attachment:** Use the provided adhesive backing or screws (if applicable, not specified but common) to securely attach the transmitter to the chosen surface.



Image: Close-up of the wireless doorbell push button (transmitter).

2. Receiver (Chime Unit) Installation:

1. **Power Source:** The receiver is a plug-in unit. Select a standard electrical outlet in a central location within your home or business where the chime can be easily heard.
2. **Plug In:** Simply plug the receiver into the chosen outlet. The unit will power on automatically.
3. **Range Consideration:** While the system offers a long range, avoid plugging the receiver into outlets directly behind large metal objects or thick concrete walls that could potentially interfere with the wireless signal.



Image: The back of the Safeguard Supply SS110 receiver showing its plug, ready to be inserted into an electrical outlet.

Operating Instructions

1. Changing Melodies:

The SS110 offers 52 distinct melodies to choose from. To cycle through the melodies:

- Locate the "Forward" and "Backward" melody selection buttons on the side of the receiver unit (refer to the "Product Components" image).
- Press the **Forward** button to advance to the next melody.
- Press the **Backward** button to go back to the previous melody.
- The receiver will play a short preview of each melody as you cycle through them. Stop when you find your preferred chime.

2. Adjusting Volume:

The chime unit features 4 adjustable volume levels, with a maximum output of 110dB. To adjust the volume:

- Locate the "Volume Control" button on the side of the receiver unit (refer to the "Product Components" image).
- Press this button repeatedly to cycle through the 4 volume levels (low, medium, high, maximum).
- Select the volume level that best suits your environment.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your Safeguard Supply SS110 doorbell system.

- **Cleaning:** Wipe both the transmitter and receiver units with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these can damage the surface or internal components.
- **Battery Replacement:** The transmitter uses one CR2 battery. If the push button stops working or its range decreases significantly, it may be time to replace the battery. Open the transmitter casing carefully, remove the old battery, and insert a new CR2 battery, ensuring correct polarity. Dispose of old batteries responsibly.
- **Environmental Conditions:** While the transmitter is designed for outdoor use, extreme weather conditions (heavy rain, direct prolonged sunlight, extreme temperatures) can affect its performance and lifespan. Consider placing it in a sheltered location if possible.

Troubleshooting

If you encounter issues with your SS110 doorbell, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Doorbell does not chime when button is pressed.	Transmitter battery is dead or low. Receiver is unplugged or not powered. Interference from other wireless devices. Distance between transmitter and receiver is too great.	Replace the CR2 battery in the transmitter. Ensure the receiver is securely plugged into a working electrical outlet. Move the receiver or transmitter away from other electronics or large metal objects. Relocate the receiver closer to the transmitter.
Chime sound is distorted or too low/high.	Volume setting is incorrect. Receiver speaker obstruction.	Adjust the volume using the volume control button on the receiver. Ensure the speaker grille on the receiver is not blocked.
Doorbell rings intermittently or without being pressed.	External interference. Faulty transmitter button.	Try changing the melody to see if it resolves the issue (some interference might be frequency-specific). Contact Safeguard Supply customer support if the issue persists after battery replacement and relocation.

Specifications

Feature	Detail
Manufacturer	Safeguard Supply
Model Number	SS110
Item Weight	0.16 ounces

Feature	Detail
Package Dimensions	3.78 x 3.62 x 3.11 inches
Color	White
Power Source	Plug-in (Receiver)
Sound Level	Up to 110 dB
Melodies	52 selectable chimes
Volume Control	4 levels
Transmitter Battery	1 x CR2 (included)
Certification	UL Listed
Special Features	Loud, Easy to Install
Included Components	Transmitter, Receiver, Battery, Manual

Warranty and Support

Safeguard Supply stands behind the quality of the SS110 Wireless Doorbell Chime. Your purchase is backed by a satisfaction guarantee.

- **Satisfaction Guarantee:** If you are not satisfied with your SS110 doorbell, you may return it for a replacement or a full refund of your purchase price.
- **Customer Support:** For any questions, technical assistance, or warranty claims, please refer to the contact information provided with your product packaging or visit the official Safeguard Supply website.

© 2024 Safeguard Supply. All rights reserved.
Model: SS110

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question