Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TopWit GLH-200B

TOPWIT 2.0L Stainless Steel Electric Kettle

Model: GLH-200B

1. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions carefully before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for assistance.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Always ensure the lid is securely closed during operation.
- Do not overfill the kettle above the MAX fill line or underfill below the MIN fill line.
- This kettle is equipped with **Auto Shut-off** and **Boil-dry Protection** for your safety.

2. Product Overview

The TOPWIT 2.0L Stainless Steel Electric Kettle is designed for rapid boiling and safe operation. Familiarize yourself with its components:

- **Kettle Body:** Made from 100% food-grade stainless steel.
- **Lid:** Stainless steel inner lid for pure water contact.
- **Handle:** Ergonomically designed, stays cool to the touch.
- **On/Off Switch:** Located on the handle, with an indicator light.
- **Spout with Filter:** Integrated stainless steel filter to prevent scale from pouring out.
- **Power Base:** 360° swivel base with cord storage.



Image 1: Overview of the TOPWIT 2.0L Stainless Steel Electric Kettle.



Image 2: Detailed view of the 100% stainless steel interior, including the inner lid, filter, and spout.

3. Setup

1. **Unpack:** Carefully remove the kettle and its power base from the packaging. Remove any protective materials.
2. **Initial Cleaning:** Before first use, wipe the exterior of the kettle with a damp cloth. Do not immerse the kettle or power base in water.
3. **First Use Boil Cycles:** To ensure cleanliness and remove any manufacturing residues, perform the following steps:
    - Fill the kettle with clean water up to the MAX fill line.
    - Boil the water (refer to Operating Instructions).
    - Discard the boiled water.
    - Repeat this process 2-3 times.

4. Operating Instructions

Using your TOPWIT Electric Kettle is simple and efficient:

1. **Place the Base:** Position the power base on a dry, flat, stable, and heat-resistant surface.
2. **Fill the Kettle:** Open the lid and fill the kettle with the desired amount of fresh water. Ensure the water level is between the MIN and MAX fill lines. Close the lid securely.
3. **Position on Base:** Place the kettle firmly onto the power base.
4. **Plug In:** Plug the power cord into a standard electrical outlet.
5. **Start Boiling:** Press the ON/OFF switch down. The indicator light will illuminate, signaling that the kettle is heating.
6. **Automatic Shut-off:** The kettle will automatically turn off once the water reaches a rolling boil, and the indicator light will extinguish.
7. **Pour:** Carefully lift the kettle from the base and pour the hot water. The handle is designed to remain cool.
8. **Unplug:** For safety and energy saving, unplug the kettle from the outlet when not in use.



Image 3: The kettle features 1000W power for rapid boiling, typically within 5 minutes.



Image 4: Details of the one-touch ON/OFF button, durable cool-touch handle, and convenient cord storage in the base.

5. Maintenance and Cleaning

Regular cleaning helps maintain the performance and longevity of your kettle.

Exterior Cleaning:

- Always unplug the kettle and allow it to cool completely before cleaning.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the stainless steel finish.
- Ensure the power base and electrical connections remain dry.

Interior Descaling:

Mineral deposits (limescale) can build up inside the kettle, especially in hard water areas. Descale regularly to ensure optimal performance.

1. **Prepare Solution:** Fill the kettle with water up to the MAX line and add either 1 tablespoon of baking soda or the juice of one lemon.
2. **Boil and Soak:** Boil the solution and then let it sit in the kettle for 20-30 minutes.
3. **Rinse:** Discard the solution and rinse the interior thoroughly with fresh water several times.
4. **Wipe:** Use a soft cloth to wipe the interior dry.



Image 5: Visual guide for easy cleaning and descaling using baking soda or lemon juice.

6. Troubleshooting

If you encounter any issues with your kettle, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in; power outage; kettle not properly seated on base; ON/OFF switch not pressed.	Check power connection; ensure kettle is correctly placed on base; press ON/OFF switch firmly.
Water not boiling.	Kettle not turned on; insufficient water; lid not closed.	Ensure ON/OFF switch is down; fill water between MIN and MAX lines; close lid securely.
Kettle turns off too quickly.	Limescale buildup; kettle is empty (boil-dry protection activated).	Descale the kettle; ensure sufficient water is added.
Water has an unusual taste.	First-time use residue; limescale buildup.	Perform initial boil cycles; descale the kettle.

If the problem persists, please contact customer service.

7. Specifications

Model Number	GLH-200B
Capacity	2.0 Liters (2.1 Quarts)

Material	Stainless Steel
Voltage	110 Volts
Wattage	1000 Watts
Dimensions (L x W x H)	8.05" x 6.05" x 8.88"
Item Weight	2 pounds
Special Features	Auto Shut-off, Boil-dry Protection, BPA-Free, No Plastic Contact



Image 6: Dimensions of the TOPWIT 2.0L Electric Kettle.

8. Warranty and Support

TOPWIT is committed to providing high-quality products and excellent customer service. If you have any questions,

concerns, or require assistance with your electric kettle, please do not hesitate to contact our customer service team.

Please refer to your purchase documentation or the TOPWIT official website for specific warranty details and contact information.

© 2023 TopWit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07VW35BQC

More documents and user manuals: **https://manuals.plus/**